

NASA Tech Briefs

Transferring Technology to
American Industry
and Government

June 1989
Volume 13
Number 6


State Of The Heart



In space: looking back to look forward.

What can the nature and origin of the universe tell us about the future of Earth? To help answer that question, we make craft and instruments for traveling billions of miles in space and seeing as far as 15 billion years back in time. Martin Marietta was the integrator and builder of two Viking landers, which sent back remarkable photos of the surface of Mars, examined soil samples, and studied Martian weather and seismic activity. For the Voyagers we provided instrumentation that

reported on electromagnetic activity near Jupiter and Saturn—Voyager 2 went on to Uranus, some 2 billion miles from Earth. That was nine years after launch; next destination, Neptune, in 1989. These are but a few results of Martin Marietta's ability to create survivable, mystery-solving craft and their instruments—from concept through mission completion.




Magellan Spacecraft

Mission: map Venus.

From orbit, Magellan's radar will penetrate the planet's thick, gaseous cloud cover and send back photo-like images of nearly 90% of its surface. Our role: design, integrate, build and test the craft.


Viewing the infant universe.

For the Hubble Space Telescope we are providing the Faint Object Spectrograph (FOS), which will see objects up to 15 billion light-years away. Since the universe is estimated to be 18-20 billion years old, astronomers will witness events close to its birth.



The fine points of fine pointing.

Precisely controlled, space-spanning energy delivery and collection systems create difficult pointing and retargeting challenges, which we can now simulate. This new lab is working toward the precision to zero in on a football-size object 3,000 miles away, in support of the Strategic Defense Initiative research program.



Masterminding tomorrow's technologies

MARTIN MARIETTA

6801 Rockledge Drive, Bethesda, Maryland 20817, USA

Sometimes, the difference in encoders is too small to measure ... or is it?



Shown above are our 1.5 inch and 2.3 inch absolute model encoders.

These BEI encoders measure up by providing a low-cost solution to applications requiring low power dissipation and nonvolatile angular output data.

They are typically found in airborne applications such as LANTIRN and

Pioneer RPV as well as land-based applications such as tank turrets, radar systems and robotic installations.

Additionally, BEI encoders are available with resolutions up to 2,000,000 absolute positions per turn and accuracy to 0.6 arcsecond.

MIL-SERIES ABSOLUTE

- ☐ 13, 14, 15, 16, or 17 bit resolutions
- ☐ Accuracy to 0.2 arcminute
- ☐ Nonvolatile Output
- ☐ Interrogation Rate...8 kHz max.
- ☐ Single LED Read Stations
- ☐ Microprocessor interface capability
- ☐ MTBF 300,000 hours
- ☐ Count direction CW or CCW
- ☐ Meets MIL-I-45208 and MIL-Q-9858 quality requirements

MIL-SERIES INCREMENTAL

- ☐ Resolution to 10,160 pulses per turn
- ☐ Starting torque less than 1.00 oz-in.
- ☐ Single Solid-State LED light source
- ☐ Incremental output code of two signals phased 90 elec. deg. apart
- ☐ Single-substrate photocell array
- ☐ Variety of disk resolutions
- ☐ Zero-reference signal
- ☐ Optional shaft seal
- ☐ MTBF...1,800,000 hours

By any measure, BEI excels in producing products of extreme accuracy and dependability. Call us when you need solutions to precise motion control.




BEI MOTION SYSTEMS COMPANY
Digital Products Division

P.O. Box 3838 ■ Little Rock, AR 72203 ■ (501) 851-4000

When your specs call for emission control, call for Emcor's *EMI/RFI series*


FCC Level

Emcor offers shielding solutions. Shown at left is an Emcor EMI/RFI enclosure —designed for commercial applications and tested to MIL STD 285. Fabricated with 14-gauge cold-rolled steel, these enclosures have the rigidity to maintain shielding continuity. They are also fully zinc-plated — both frame and external components — and come with a full complement of accessories.



Tempest Style

To meet the most demanding levels of shielding often required by the military, Emcor offers its Tempest style line of enclosures as shown in the top photo. Also tested to MIL STD 285, this line combines high strength with modular options and attractive esthetics. Features include a rigid, 12-gauge frame plus a unique latching system and door design (patent pending). These enclosures are nickel-plated with copper finger stock gasketing.



Contact Emcor to discuss your EMI/RFI needs. Our engineering staff has the knowledge and experience to help solve your shielding problems. We can also design modified and custom products.



Crenlo, Inc.


1600 - 4th Ave. N.W.
Rochester, MN 55901
Phone 507-289-3371
FAX #507-287-3405

EMCOR®

Emcor is listed under GSA contract #GS-07F-17241.

See us at AFCEA, Booth #3214

Circle Reader Action No. 460



Before he pushes the edge, IBM takes you beyond it.

From miles away and thousands of feet below, you know exactly what he's feeling.

Using an IBM 3090 with supercomputer power, you've pushed your design through relentless iterations of finite element modeling and fluid dynamics analysis. You've defined the edge.

The IBM 3090 with Vector Facility, for its part, has redefined supercomputer performance, combining up to six vector processors with one of the industry's fastest scalar processors and most efficient memory management systems, parallel processing capabilities, and full IBM System/370 compatibility.

The result is balanced supercomputer performance that can improve your job turnaround by eliminating data bottlenecks, and save the added expense of a separate



front-end processor. Plus, the IBM Vector Facility's modular design lets you start with just the computer power you need today, and make economical in-field upgrades as your needs grow. And that gives the IBM 3090VF a big edge over more expensive and less flexible vector processors.

IBM's integrated system approach combines the power of the IBM 3090VF with the advantages of a single operating environment, low entry cost, low software and maintenance costs, a wide variety of application programs, and IBM support to create a winner in total cost-of-computing.

To find out more, or to arrange to have your IBM Marketing Representative contact you, simply call 1-800-IBM-2468, ext. 20.



SPECIAL FEATURES

Space-Age Vision Aids	16
Mission Accomplished	117

TECHNICAL SECTION














 New Product Ideas	12
 NASA TU Services	14
 Electronic Components and Circuits	22
 Electronic Systems	34
 Physical Sciences	48
 Materials	64
 Computer Programs	68
 Mechanics	72
 Machinery	82
 Fabrication Technology	86
 Mathematics and Information Sciences	98
 Life Sciences	106
 Subject Index	111



Photo courtesy NASA

A simulation tool originally developed for the Space Shuttle program is now aiding research on mechanical hearts. The computer simulation shown above illustrates the geometry used in analyzing fluid flow through a model of the Penn State artificial heart. For more on this Mission Accomplished story, turn to page 117.

DEPARTMENTS

On The Cover: Using powerful supercomputers, NASA scientists have simulated the complex flow of blood in an artificial heart. The cover image shows particle traces color-coded by the height of the point at which they were released from the heart's inflow valve.

New Literature . . . 107

New on the Market 108

Advertisers' Index 118



Photo courtesy NASA

NASA is designing high-tech sunglasses to improve low-vision eyesight. See page 16.

ABP **BPA**

This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor anyone acting on behalf of Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy is paid directly to the Copyright Clearance Center (21 Congress St., Salem, MA 01970). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/89 \$3.00 + .00.

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright © 1989 in U.S., is published monthly by Associated Business Publications Co., Ltd. 41 E. 42nd St., New York, NY 10017-5391. The copyrighted information does not include the individual Tech Briefs which are supplied by NASA. Editorial, sales, production and circulation offices at 41 E. 42nd Street, New York, NY 10017-5391. Subscriptions for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$125.00 for 2 years; \$200 for 3 years. Single copies \$10.00. Remit by check, draft, postal or express orders. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 41 E. 42nd Street, New York, NY 10017-5391. Second-class postage paid at New York, NY and additional mailing offices.

POSTMASTER: please send address changes to NASA Tech Briefs, 41 E. 42nd Street, Suite 921, New York, NY 10017-5391.

Build Your
Future
with
Newport

For ultimate laser spectral resolution, read between the lines with SuperCavity™


NEW!

Up to 200 times the spectral resolution of ordinary cavities

When you're analyzing laser mode structure, you've got to have the best possible spectral resolution. The SuperCavity consistently delivers 25 to 200 times the resolution of ordinary Fabry-Perot cavities, revealing mode structure details previously hidden from other optical analyzers.

Our exclusive super-polished, ultralow-scatter mirrors make it possible. With an RMS surface roughness of less than 2 angstroms, they reflect over 99.99 percent of the incident beam for the ultimate in high finesse and throughput.

Five SuperCavity models cover the major visible and near-IR laser wavelengths.



Actual oscilloscope output of HeNe laser mode structure shows the powerful resolving capabilities of the SR-130 SuperCavity.

Each is available with either a 6-GHz free spectral range for narrow-bandpass filtering, or an 8,000-GHz range for general diagnostics. SuperCavities provide guaranteed finesse of more than 10,000 and efficiency greater than 10 percent. Center-wavelength finesse typically exceeds 40,000.

New 1.3-micron cavity

For infrared diagnostics, we've just introduced a 1.3-micron SuperCavity optimized for more than 63 percent throughput and finesse greater than 5,000 at 1320 nm.


If you need better spectral resolution for laser diagnostics, read between the lines with SuperCavity. To order, call our instrument specialists at (714) 965-5406.



Newport

Unshakeable Quality

Newport Corporation
18235 Mt. Baldy Circle
Fountain Valley, CA 92708
Europe: Newport GmbH
Ph. 06151-26116
U.K.: Newport Ltd.
Ph. 05827-69995



©1989-04891-A
Newport Corporation

Circle Reader Action No. 510

MATLABTM

THE HIGH-PERFORMANCE COMPUTATION SYSTEM FOR SCIENCE AND ENGINEERING

- MATRIX COMPUTATION
- SIGNAL PROCESSING
- LINPACK AND EISPACK ALGORITHMS
- 2-D and 3-D GRAPHICS

MATLAB is an interactive system for scientific and engineering numeric computation. Problems and solutions are expressed just as they are written mathematically -- *without traditional programming*. As a result, you can solve numerical problems in a fraction of the time required to write a program in Fortran, Basic, or C.

MATLAB has rapidly become an industry standard for engineering and scientific research. Its unique interactive interface, algorithmic foundation, easy extensibility, and speed make MATLAB the software system of choice for *high productivity and high creativity* research.


Over 200 Built-in Functions

- eigenvalues
- least squares
- inverse
- pseudoinverse
- cubic splines
- quadrature
- convolution
- interpolation
- curve fitting
- singular value decomposition, *and more*
- 1-D and 2-D FFTs
- matrix arithmetic
- complex arithmetic
- multivariate statistics
- polynomial arithmetic
- nonlinear optimization
- differential equations
- linear equation solving
- windowing functions

2-D and 3-D Color Graphics

With MATLAB, you can create high-resolution, publication-quality 2-D, 3-D, linear, log, semilog, polar, and contour plots on your plotters, dot-matrix printers, and laser printers.

3-D Mesh Surface Plots



AT is a trademark of IBM. Macintosh is a trademark of Apple Computer. Sun is a trademark of Sun Microsystems. Apollo is a trademark of Apollo Computers. VAX and VMS are trademarks of DEC. Unix is a trademark of AT&T. MATLAB is a trademark of The MathWorks, Inc.

Computers

- ✓ PC and AT Compatibles
- ✓ 80386 Computers
- ✓ Macintosh
- ✓ Sun Workstations
- ✓ Apollo Workstations
- ✓ VAX/VMS and Unix
- ✓ Other Computers

Open and Extensible

MATLAB is a fully extensible environment. Create functions and programs rapidly -- without the time-consuming compiling, linking, and complex syntax of traditional languages. Our open-system philosophy gives you access to algorithms and source code so you can edit functions or add your own.

Optional *Toolboxes* extend MATLAB by providing application-specific capabilities, such as parametric modelling and control system design.

Fast, Accurate, and Reliable

MATLAB's import/export facilities provide access to *your* data. MATLAB can handle lots of data -- and do it *fast*, fully utilizing all available floating point hardware for maximum performance. You won't have to question the results either -- the algorithms have been programmed by leading experts in mathematical software.

Benchmarks (20 MHz 386-based PC)

20x20 matrix multiply	0.05s
20x20 inverse	0.11s
20x20 eigenvalues	0.6s
1024 point FFT	0.16s

MATLAB is the teaching and research system chosen by Computer Science, Engineering, and Mathematics departments at most top universities. These creative researchers use MATLAB to design algorithms that are at the cutting edge of technology. As a result, you are assured of an exciting future of new developments, implemented with the speed, power, and flexibility that have made MATLAB a standard.

Please provide additional information!

Name _____
Company _____
Dept. _____
Addr. _____
City _____
State, Zip _____
Tel. _____
Computer _____

The
**MATH
WORKS**
Inc.

21 Eliot Street
South Natick, MA 01760
(508) 653-1415
Telex 910-240-5521

NASA 6-89

**Now:
Monarch™ GPS
navigation puts 3-D
accuracy onboard.**



The Monarch 6-channel GPS spaceborne user receiver enables continuous autonomous spacecraft navigation with order-of-magnitude improvements in position, velocity, and timing accuracy. Radiation-hardened ASICs and high levels of digital integration produce lower cost mission flexibilities. To put improved, lightweight 3-D navigation aboard spacecraft call 602/732-3018 or write Box 2606, Scottsdale, AZ 85252.



MOTOROLA INC.
Government Electronics Group

Circle Reader Action No. 655



VIDEOTAPE FROM YOUR COMPUTER GRAPHICS DISPLAY

**THE RGB/VIDEOLINK™
SCAN CONVERTER**

**THE LINK BETWEEN
COMPUTER GRAPHICS
AND TELEVISION (NTSC OR PAL) VIDEO
FOR VIDEO TAPING, VIDEO PROJECTION
AND VIDEO TRANSMISSION**



RGB TECHNOLOGY
2550 NINTH STREET BERKELEY, CA 94710
TEL: (415) 848-0180 FAX: (415) 848-0971

NASA Tech Briefs

National Aeronautics and
Space Administration

ABP **BPA**

NASA Tech Briefs:

Published by **Associated Business Publications**
Editor-in-Chief/Publisher **Bill Schnirring**
Associate Publisher **Frank Nothaft**
Associate Publisher **Robin J. DuCharme**
Managing Editor **R. J. Laer**
Associate Editor **Joseph T. Pramberger**
Technical Advisor **Dr. Robert E. Waterman**
Production Manager **Rita Nothaft**
Traffic Manager **James E. Cobb**
Circulation Director **Anita Weissman**
Marketing Research Manager **Leo D. Kluger**
Advertising Coordination Manager **Erving Dockery, Jr.**
Telecommunications Specialist **Evelyn Mars**
Reader Service Manager **Sylvia Ruiz**

Technical Staff:

Briefs provided to National Aeronautics and Space Administration by
International Computers & Telecommunications, Inc., NY, NY with
assistance from **Logical Technical Services, NY, NY**
Technical/Managing Editor **Ted Selinsky**
Art Director **Ernest Gillespie**
Administrator **Elizabeth Texeira**
Chief Copy Editor **Lorne Bullen**
Staff Writers/Editors **Dr. James Boyd, Dr. Larry Grunberger,**
Dr. Theron Cole, Jordan Randjelovich,
George Watson, Oden Browne
Graphics **Luis Martinez, Vernald Gillman,**
Charles Sammartano
Editorial & Production **Bill Little, Ivonne Valdes, Frank Ponce**

NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space
Administration, Technology Utilization Division, Washington, DC:
Administrator **Dr. James C. Fletcher**
Assistant Administrator for Commercial Programs **James T. Rose**
Deputy Assistant Administrator (Programs) **Henry J. Clarks**
Deputy Director TU Division (Publications Manager) **Leonard A. Ault**
Manager, Technology Utilization Office, NASA Scientific and
Technology Information Facility **Walter M. Heiland**

Associated Business Publications

41 East 42nd Street, Suite 921, New York, NY 10017-5391
(212) 490-3999 FAX (212) 986-7864

President **Bill Schnirring**
Executive Vice President **Frank Nothaft**
Vice President **Domenic A. Mucchetti**
Vice President Marketing **Mark J. Seltman**
Controller **Felecia Lahey**

Advertising:

New York Office: (212) 490-3999 FAX (212) 986-7864

Sales Manager **James G. McGarry**
Regional Sales Manager (South) **Robin DuCharme**
Regional Sales Manager (Mid-Atlantic) **Michelle Larsen**
Account Executive **Debby Crane** at (201) 967-9838
Account Executives (Midwest) **Jack Cartwright** or **Paul Leshner**
at (312) 501-4140
Account Executives (Eastern MA, NH, ME, RI) **Lee Arpin** or **Paul Gillespie**
at (617) 899-5613; **Bill Doucette** at (617) 278-7792
Account Executive (Western MA, CT, VT) **George Watts** or **David Hagggett**
at (413) 253-9881
Account Executive (No. Calif., WA, OR) **Janice Richey King**
at (415) 656-3613
Account Executives (So. Calif., AZ, NV, NM) for Area Codes 818/213/805
Thomas Stillman or **Melanie Binkley**
and for Area Codes 619/714—**Leslie Alley** at (213) 372-2744

NTBM-Research Center



Account Supervisor **Lourdes Del Valle**

THE AMCO COMBINATION CABINET/COOLING SYSTEM

Better Fit, Better Performance, Lower Cost and Less Problems.

AMCO manufactures both cooling devices and enclosures at the same location. So with one call you can get enclosures that are ready for business; Equipped with fans, blowers, and accessories for your application. You're assured of perfect fit, plus cost savings through our Combination Cabinet/Cooling System discounts and Free Blower Installation.

Blowers are SCFM rated with 20K-50K life expectancies depending on temperature and conditions. Infinite enclosure selections of Type, Style and Color —Nearly Five Decades of Leadership.



Call for free, full color catalogs; #800A on AMCO Modular Enclosure Systems, and #850 on Cooling Systems and/or our Catalog 500B Fast Delivery Program. Call 1-800-833-3156 In Illinois, 1-312-671-6670*

AMCO Engineering Co.
3801 N. Rose Street
Schiller Park, IL 60176-2190



AMCO

®

AMCO GETS THERE FIRST

Circle Reader Action No. 500

*As of November 11, 1989—New Area Code will be 708.



New Product Ideas

New Product Ideas are just a few of the many innovations described in this issue of *NASA Tech Briefs* and having promising commercial applications. Each is discussed further on the referenced page in the appro-

priate section in this issue. If you are interested in developing a product from these or other NASA innovations, you can receive further technical information by requesting the TSP referenced at the end of the full-

length article or by writing the Technology Utilization Office of the sponsoring NASA center (see page 14). NASA's patent-licensing program to encourage commercial development is described on page 14.

Three-Dimensional Robotic Vision System

A digital image-processing system would act as an "intelligent" automatic machine-vision system by processing views from stereoscopic television cameras into

three dimensional coordinates of a moving object in view. The stereoscopy and the effects of motion on the two images would complement each other in providing clues to the natures and locations of principal features. (See page 43).

Energy-Efficient, Continuous-Flow Ash Lockhopper

Energy efficiency of a continuous-flow ash lockhopper has been increased by preventing hot gases from escaping out of a reactor vessel through the ash-hopper outlet and carrying away heat energy. Hot gases are contained via equalized pressure, which, in addition to conserving heat, prevents useful reaction product gases or polluting gases from escaping. (See page 83).

Robot Hand Grips Cylinders Securely

A robot hand includes two pairs of parallel jaws that can grasp rods, pipes, tubes, struts, and other long, heavy cylindrical objects. The hand features a compact rotary drive and a butterfly configuration that simplify robot maneuvers. (See page 82).

Advanced Fuel-Cell Modules

A stack of alkaline fuel cells is based on modules, each of which consists of three fuel cells and a cooler. Each cell has an active area of .1 ft² (0.09 m²). The materials and configurations of the parts were chosen to extend life expectancy, reduce weight and manufacturing cost, and increase reliability. (See page 28).

Thermal Brushes for Memory-Metal Actuators

Proposed thermoelectric elements with wire-brush contacts would remove or add heat to memory-metal actuators and thereby enable them to respond faster than previously possible. A memory-metal actuator is formed to a shape while hot, then to another shape while cold. (See page 84).

Continuously-Variable Vernier Scale

The continuously-variable vernier scale is designed to provide greater accuracy to scientists and technologists in reading numerical values from graphical data. It is placed on the graph and used to interpolate the coordinate value of a point on a curve or a plotted point on a figure. (See page 98).



The business-to-business forum for Technology Transfer, Licensing and Invention.

September 7-8, 1989
Anaheim Marriott Hotel

Join in one of the specialized pavilion areas: Electronics, Energy, Aerospace, Communications, Materials, Pharmaceuticals, Medical Devices, Agriculture, Environment or Individual Inventors.

For more information about exhibiting or attending, call 1-800-243-2815; (203-853-0400 in Connecticut or outside the U.S.) or send the coupon below.

InvenTech Expo is sponsored by Inventors Workshop International and the Technology Transfer Society.

EDGELL
EXPOSITIONS

InvenTech
Expo

Send to:

InvenTech Expo
Edgell Expositions
50 Washington Street, 10th Floor
Norwalk, CT 06854


EDGELL
EXPOSITIONS

A Division of Edgell Communications, Inc.

- ☐ Yes, I'd like more information about exhibiting.
☐ Yes, I'd like more information about the conference.

Name _____
Title _____
Company _____
Address _____
City _____
State/Zip _____
Telephone () _____

NTB



Sarnoff's Centers of Excellence Offer Innovative Research Answers. Let Our Contract Research Solve Your Problems.

The powerful new laser pictured here — called a Grating Surface Emitting Array (GSE) — is 100 times brighter than any previous device.

This new semiconductor diode laser technology was developed at the David Sarnoff Research Center, which has been in the forefront of major advances in diode laser devices for the past 25 years.

Some day circuits will talk to each other by means of light because of what Sarnoff researchers in interdisciplinary "centers of excellence" have accomplished in optoelectronics.

The Sarnoff Research Center, today a thriving contract research facility in Princeton, NJ, and a subsidiary of

SRI International, had its genesis as RCA Laboratories. Internationally known for its pioneering development of all-electronic, compatible color television, it has a worldwide reputation in electronics, communications, and solid state physics. Many of the electronic advances of the past 45 years had their birth in Sarnoff's Princeton laboratories.

The GSE laser is but one example of the creativity of Sarnoff scientists. We at Sarnoff are in the problem-solving business. What others may consider problems, our researchers consider as challenges to their imagination and ingenuity.

We perform innovative contract research and development on the frontiers of technology. So, challenge us with your problems and let us transform them into solutions!

DAVID
Sarnoff
RESEARCH CENTER
Subsidiary of SRI International

To learn more about us, contact Market Development,
at the David Sarnoff Research Center, CN 5300,
Princeton, NJ 08542-5300. Toll-free (800) 734-2553.

Heads in the clouds, feet on the ground.



HOW YOU CAN BENEFIT FROM NASA'S TECHNOLOGY UTILIZATION SERVICES

If you're a regular reader of TECH BRIEFS, then you're already making use of one of the low- and no-cost services provided by NASA's Technology Utilization (TU) Network. But a TECH BRIEFS subscription represents only a fraction of the technical information and applications/engineering services offered by the TU Network as a whole. In fact, when all of the components of NASA's Technology Utilization Network are considered, TECH BRIEFS represents the proverbial tip of the iceberg.

We've outlined below NASA's TU Network—named the participants, described their services, and listed the individuals you can contact for more information relating to your specific needs. We encourage you to make use of the information, access, and applications services offered by NASA's Technology Utilization Network.

How You Can Utilize NASA's Industrial Applications Centers—A nationwide network offering a broad range of technical services, including computerized access to over 100 million documents worldwide.

You can contact NASA's network of Industrial Applications Centers (IACs) for assistance in solving a specific technical problem or meeting your information needs. The "user friendly" IACs are staffed by technology transfer experts who provide computerized information retrieval from one of the world's largest banks of technical data. Nearly 500 computerized data bases, ranging from NASA's own data base to Chemical Abstracts and INSPEC, are accessible through the ten IACs located throughout the nation. The IACs also offer technical consultation services and/or linkage with other experts in the field. You can obtain more information about these services by calling or writing the nearest IAC. User fees are charged for IAC information services.

Aerospace Research

Applications

Center (ARAC)

Indianapolis Center for Advanced Research

611 N. Capitol Avenue
Indianapolis, IN 46204

Dr. F. Timothy Janis, Director
(317) 262-5036

Rural Enterprises, Inc.

Central Industrial Applications

Center/NASA (CIAC)

P.O. Box 1335
Durant, OK 74702

Steve R. Hardy, President
(405) 924-5094

North Carolina Science and

Technology Research Center

(NC/STRC)

Post Office Box 12235

Research Triangle Park, NC

27709

H. Lynn Reese, Director
(919) 549-0671

NASA Industrial Applications

Center

823 William Pitt Union

University of Pittsburgh

Pittsburgh, PA 15260

Dr. Paul A. McWilliams,

Exec. Director

(412) 648-7000

NASA/Southern Technology

Applications Center

Box 24

Progress Ctr., One Progress Blvd.

Alachua, FL 32615

J. Ronald Thornton, Director

(904) 462-3913

(800) 354-4832 (FL only)

(800) 225-0308 (toll-free US)

NASA/UK Technology

Applications Program

University of Kentucky

109 Kinkead Hall

Lexington, KY 40506-0057

William R. Strong, Director

(606) 257-6322

NERAC, Inc.

One Technology Drive

Tolland, CT 06084

Dr. Daniel U. Wilde, President

(203) 872-7000

Technology Application Center

(TAC)

University of New Mexico

Albuquerque, NM 87131

Dr. Stanley A. Morain, Director

(505) 277-3622

NASA Industrial Applications

Center (WESRAC)

University of Southern California

Research Annex

3716 South Hope Street, Room

200

Los Angeles, CA 90007-4344

Radford G. King, Exec. Director

(213) 743-8988

(800) 642-2872 (CA only)

(800) 872-7477 (toll-free US)

NASA/SU Industrial Applications

Center

Southern University Department

of Computer Science

P.O. Box 9737

Baton Rouge, LA 70813-9737

Dr. John Hubbell, Director

(504) 771-6272

If you represent a public sector organization with a particular need, you can contact NASA's Application Team for technology matching and problem solving assistance. Staffed by professional engineers from a variety of disciplines, the Application Team works with public sector organizations to identify and solve critical problems with existing NASA technology. **Technology Application Team, Research Triangle Institute, P.O. Box 12194, Research Triangle Park, NC 27709. Doris Rouse, Director, (919) 541-6980**

How You Can Access Technology Transfer Services At NASA Field Centers:

Technology Utilization Officers & Patent Counsels—Each NASA Field Center has a Technology Utilization Officer (TUO) and a Patent Counsel to facilitate technology transfer between NASA and the private sector.

If you need further information about new technologies presented in NASA Tech Briefs, request the Technical Support Package (TSP). If a TSP is not available, you can contact the Technology Utilization Officer at the NASA Field Center that sponsored the research. He can arrange for assistance in applying the technology by putting you in touch with the people who developed it. If you want information about the patent status of a technology or are interested in licensing a NASA invention, contact the Patent Counsel at the NASA Field Center that sponsored the research. Refer to the NASA reference number at the end of the Tech Brief.

Ames Research Ctr.

Technology Utilization

Officer: Laurance Milov

Mail Code 223-3

Moffett Field, CA 94035

(415) 694-4044

Patent Counsel:

Darrell G. Brekke

Mail Code 200-11

Moffett Field, CA 94035

(415) 694-5104

Lewis Research Center

Technology Utilization

Officer: Daniel G. Soltis

Mail Stop 7-3

21000 Brookpark Road

Cleveland, OH 44135

(216) 433-5567

Patent Counsel:

Gene E. Shook

Mail Code 301-6

21000 Brookpark Road

Cleveland, OH 44135

(216) 433-5753

John C. Stennis

Space Center

Technology Utilization

Officer: Robert M.

Barlow

Code HA-00, Bldg. 1103

Stennis Space Center,

MS 39529

(601) 688-1929

John F. Kennedy

Space Center

Technology Utilization

Officer: Thomas M.

Hammond

Mail Stop PT-PMO-A

Kennedy Space

Center, FL 32899

(407) 867-3017

Patent Counsel:

James O. Harrell

Mail Code PT-PAT

Kennedy Space

Center, FL 32899

(407) 867-2544

Langley Research Ctr.

Technology Utilization

Officer: John Samos

Mail Stop 139A

Hampton, VA 23665

(804) 864-2484

Patent Counsel:

George F. Helfrich

Mail Code 279

Hampton, VA 23665

(804) 864-3523

Goddard Space Flight

Center

Technology Utilization

Officer: Donald S.

Friedman

Mail Code 702.1

Greenbelt, MD 20771

(301) 286-6242

Patent Counsel:

R. Dennis Marchant

Mail Code 204

Greenbelt, MD 20771

(301) 286-7351

Jet Propulsion Lab.

NASA Resident Office

Technology Utilization

Officer: Gordon S.

Chapman

Mail Stop 180-801

4800 Oak Grove Drive

Pasadena, CA 91109

(818) 354-4849

Patent Counsel:

Paul F. McCaul

Mail Code 180-801

4800 Oak Grove Drive

Pasadena, CA 91109

(818) 354-2734

Technology Utilization

Mgr. for JPL: Dr. Nor-

man L. Chaffin

Mail Stop 156-211

4800 Oak Grove Drive

Pasadena, CA 91109

(818) 354-2240

George C. Marshall

Space Flight Center

Technology Utilization

Officer: Ismail Akbay

Code AT01

Marshall Space Flight

Center,

AL 35812

(205) 544-2223

FAX (205) 544-3151

Patent Counsel:

Bill Sheehan

Mail Code CC01

Marshall Space Flight

Center,

AL 35812

(205) 544-0021

Lyndon B. Johnson

Space Center

Technology Utilization

Officer: Dean C. Glenn

Mail Code IC-4

Houston, TX 77058

(713) 483-3809

Patent Counsel:

Edward K. Fein

Mail Code AL3

Houston, TX 77058

(713) 483-4871

NASA Headquarters

Technology Utilization

Officer: Leonard A. Ault

Code CU

Washington, DC 20546

(202) 453-2636

Assistant General

Counsel for Patent

Matters: Robert F.

Kempf, Code GP

Washington, DC 20546


(202) 453-2424

A Shortcut To Software: COSMIC®—For software developed with NASA funding, contact COSMIC, NASA's Computer Software Management and Information Center. New and updated programs are announced in the Computer Programs section. COSMIC publishes an annual software catalog. For more information call or write: **COSMIC®** 382 East Broad Street, Athens, GA 30602 John A. Gibson, Dir., (404) 542-3265


If You Have a Question . . . NASA Scientific & Technical Information Facility can answer questions about NASA's Technology Utilization Network and its services and documents. The STI staff supplies documents and provides referrals. Call, write or use the feedback card in this issue to contact: **NASA Scientific and Technical Information Facility**, Technology Utilization Office, P.O. Box 8757, Baltimore, MD 21240-0757. **Walter M. Heiland, Manager**, (301) 859-5300, Ext. 242, 243

**INTEL HAS
A REAL-TIME
SOLUTION FOR
PRACTICALLY
EVERY
APPLICATION.**

**HOW COULD
WE POSSIBLY
IMPROVE?**



NASA Technology Plays Key Role In Vision Research



The Low Vision Enhancement System, to resemble wraparound sunglasses when completed, will custom-tailor images of the outside world for low-vision patients.

Space-Age Vision Aids

Using space-based imaging techniques, NASA will develop a device designed to improve the eyesight of some 2.5 million Americans who suffer from low vision, a condition that cannot be corrected medically, surgically, or with

prescription eyeglasses.


The project, a collaborative effort with the Johns Hopkins Wilmer Eye Institute in Baltimore, MD, is expected to take at least five years and cost a minimum of \$5 million in its initial stages. Funding will be provided by

Wilmer and NASA's Technology Utilization Office.

The Stennis Space Center's Earth Resources Laboratory will coordinate the project for NASA, with potential technical contributions from the Jet Propulsion Laboratory (JPL), Ames Research Center, and the Johnson Space Center. All three feature strong vision research programs.

The invention, dubbed the Low Vision Enhancement System, will employ digital image processing technology—originally developed at JPL to enhance photographs of the moon and Mars captured by distant spacecraft. Experimentors will apply such processing techniques as magnification, spatial distortion, and contrast adjustment to compensate for blind spots in the patient's visual field.

As now conceived, the device will resemble mirrored wraparound sunglasses. Low-vision patients will view the outside world on color flat-panel television screens located in the lens



SIMPLE.



System 120. The first integrated real-time system based on the AT-bus with iRMX® software.

With the addition of the System 120, Intel now offers the widest range of dedicated real-time products.

The System 120 brings the power of iRMX and the 386™ microprocessor to a cost-effective AT-bus system.

Because of iRMX, the System 120 gives you the same optimized real-time response and unique programming features already used in over half a million CPUs.

What's more, System 120 applications can migrate to the world's most popular single board computer family, Multibus® I.

Without recompiling.

Or move distributed real-time applications to Multibus II for a quantum improvement in performance and functionality. So, one development effort lets you span two orders of magnitude in performance.

To learn more about the System 120, call Intel at 800-548-4725, Dept. AA02.

It's that simple.

The Intel logo, consisting of the word 'intel' in a lowercase, sans-serif font, with a registered trademark symbol (®) to its upper right.

New Power in Waveform Acquisition and Analysis

Unique software helps make the System 500 "turn-key" ready

At first glance, Nicolet Instrument's unveiling of its new System 500 seems newsworthy because of the 500's industry-leading hardware. Indeed, in the world of waveform acquisition and analysis, where more is better, the System 500 is in a class by itself. The 500 has more channels, more memory, more speed and more resolution.

Each digitizer board, with its own independent trigger circuitry, time base and up to 1 megasample record length, is worthy of a full review. This multi-channel system can be configured to have as many inputs you need — up to several hundred. The digitizer boards are designed to be the equivalent of having a 12 bit digital scope on a card.

Turn-key system

But after you get your hands on the System 500, the the most important news becomes apparent. Someone has finally developed a very powerful, competitively priced system for waveform acquisition and analysis that truly is a "turn-key" system.

You literally can take this system out of the box, plug in the power cord, connect the GPIB cable between the acquisition unit and the controller, and turn it on. The System 500 is now ready to take data. This turn-key readiness promises to save time by considerably reducing the learning curve needed to perform complex waveform acquisition and analysis.

Intuitive windows software

The primary reason for System 500's easy operation is Nicolet's unique software which operates under Microsoft Windows/386®. The powerful Nicolet software can easily be controlled through pulldown menus that can be accessed by mouse or keyboard.

Measuring waveforms becomes as simple as pointing to the data point of interest on a waveform and clicking the mouse — the voltage and time values for the selected point is

immediately displayed on the screen. By using the Delta Numerics function relative measurements like peak to peak or rise time can easily be made.

Also, Nicolet's unique software, combined with the System 500's built-in processor and co-processor, make incredibly fast waveform processing and analysis possible.

Local processing

While other data acquisition systems need to transfer data to another computer for analysis, Nicolet has built calculation capabilities into the new System 500. Complex calculations can be performed on acquired data as it resides in the digitizer's memory.

There is no need to transfer data to a computer for analysis, no need for complex programming to handle normalizing sets and long record lengths. Functions are performed on the powerful 32 bit processors with a few clicks of the mouse. This local processing of data greatly decreases the time it takes to generate answers.

The bottom line is that the System 500 is a unique turn-key waveform acquisition system. For full details you'll need to read the product brochure.

**Call Nicolet Test Instruments
(800) 356-3090**



The new Nicolet System 500 offers multi-channel flexibility with up to 10 MegaSamples/Second digitizing rates.

portion of the glasses. Lenses and glass fibers will be embedded on each side of the wraparound section, where the front and ear pieces join. The lenses will transport images along the fibers to a miniature solid-state camera carried in a belt or shoulder pack. Images will be processed by a battery-powered computer in the pack and then transported via fiber back to the display screens for viewing.

The vision system may incorporate a programmable remapper developed at the Johnson Center to perform real-time spatial remapping between input and output video. The Remapper would "wrap" images around the patient's blind spot, warping the image so that it is pulled, like a rubber sheet, away from the blind area and magnified.

NASA expects a lightweight prototype to be ready in about five years, with clinical testing to follow soon after. The first head-mounted model may be similar to an imaging system invented by Ames scientists for human factors research (NTB Vol. 12, Num. 7). This "Virtual Workstation" combines three-dimensional graphics, wide field-of-view optics, and advanced eye-tracking techniques to create a stereoscopic experience that gives the user a sense of being inside the display.

A Dynamic Vision Aid

The Low Vision Enhancement System should benefit patients with central vision loss, the part of vision normally used for reading. These patients may have macular degeneration associated with aging, or diabetic retinopathy, in which diabetes causes swelling and leakage of fluid in the center of the retina. It also could help patients with impaired side vision due to eye diseases such as retinitis pigmentosa.

"This system won't restore lost vision," said Dr. Robert Massof, Director of Wilmer's Vision Research and Rehabilitation Center. "Rather, it will help patients make the best use of their remaining vision."

Ongoing Wilmer research supported by the National Eye Institute will provide information on how images must be changed and enhanced for the low-vision sufferer. "The effect of visual impairment on reading, face and object recognition, orientation, and mobility are important research areas that will guide us in developing the Low Vision Enhancement System," said Dr. Gary Rubin, an assistant professor of ophthalmology at Wilmer.

The First Step

NASA first will assemble a basic research system for Wilmer that will



Sometimes overnight is absolutely, positively too late.

We're not knocking the other guys, but sometimes you need to get it there right away. The very same day. Today, not tomorrow.

With TWA's Next Flight Out® delivery service, you're in business.

Even as you read this, TWA planes are about to take off. We can make sure your small package is on the next flight out to any one of over 100 U.S. cities. And we'll deliver it door-to-door or airport-to-airport. Same day. Seven days a week.

We'll give you our money-back guarantee and Frequent Flight Bonus miles, too (exciting details when you call).

We also deliver next day to Europe and second day to the Middle East.

So for anything up to 70 pounds domestic and 50 pounds international, just call the 800 number. It's that easy. It's *not* that expensive. And most of all, it's fast—very, very fast.

1-800-638-7380

For information or immediate pick-up, ask for Agent 194.



JPL's High-Tech Reading Machine


The first computerized reading aid for low-vision sufferers is nearing completion at NASA's Jet Propulsion Laboratory (JPL), Pasadena, California. Expected on the market by 1991, the system changes the spatial contrast of printed material to compensate for maculopathies, or central vision losses. Maculopathy patients, mostly elderly, can no longer see fine detail or read due to the breakdown of key cells in the retina.

"Until now," said Dr. Teri Lawton, the system's inventor, "there's been virtually nothing to help people with central vision problems." Because maculopathy is a degeneration of nerve cells rather than a problem of the lens or other parts of the eye, it does not respond to conventional treatment or corrective lenses. Powerful magnifiers, which spread a few fuzzy letters over the entire visual field, provide minimal relief.

Like the Low Vision Enhancement System, Lawton's invention is based on digital image processing technology. She uses a computer workstation to test the patient's visual acuity and then, with customized image processing software, to enlarge and filter printed words on a closed-circuit television screen so they have the right amount of brightness for the patient to read clearly.

In recent experiments using the screening method, patient reading speeds increased from two to four times—with up to 70 percent less magnification needed for word recognition—compared to reading unfiltered text.

"The next step," Lawton said, "is to incorporate this technology in a desktop system, something like a microfilm or microfiche reader. I'd like to get some of these



out to low-vision clinics for evaluation." Books and magazines would be inserted and moved past the TV camera's lens for reading.

JPL is collaborating with Visualtek, Inc., a leading manufacturer of reading aids based on closed-circuit TV technology, to produce an inexpensive commercial model that should be available within two years.

"Our ultimate goal," Lawton said, "is to develop a portable reading machine in the form of eyeglasses. We'll need liquid

Dr. Lawton's filtered images appear slightly blurred to the ordinary observer, but are more easily readable by the person for whom the enhancement formula was made.

crystal displays with higher contrast than what's available today, so we're probably looking five or ten years down the road." □

Dr. Teri Lawton is a psychologist and mathematician researching fundamental vision functions in JPL's Robotics, Teleoperators, and Human Factors Research Group. For more on her work, turn to the tech brief on page 36.

include a general-purpose computer for real-time image processing. The computer will be connected to image processing workstations with multiple input and output devices, enabling Wilmer researchers to simultaneously perform a variety of experiments.

"The idea is to first get a working image processing system going and then to add on new and better pieces of technology as they evolve," explained Dr. Douglas Rickman, who is

heading the low vision project at Stennis. "We'll use feedback from the experimentors to make hardware modifications and to design the finished software."


The software environment will be highly flexible, according to Rickman. "In the past," he said, "vision scientists had to build specialized hardware tools to perform experiments. We want to give them a generalized software tool that will allow them to create, edit, and manipulate images in

many different ways."

Building Better Robots

NASA scientists hope this research will one day help them to build robots with improved "eyesight" for teleoperations in space. "During the course of this project we may gain a better understanding of how the human brain handles visual data," explained Rickman, "which could prove useful in designing improved ma-

(Continued on page 112)



They don't put it to the test in space until we help put it to the test on Earth.

When your product's in space orbit 300 miles above the Earth, structural integrity takes on a whole new meaning.

Which is precisely the reason so many contractors back on Earth use Bruel & Kjaer test, measurement and stress analysis equipment.

They know Bruel & Kjaer high-performance test equipment offers unparalleled accuracy, reliability and consistency. They also know Bruel & Kjaer instruments and systems are engineered and built to the most exacting

standards in the world. With a 45-year reputation of excellence behind them.

From vibration testing to modal analysis, from sound and noise measurement to environmental monitoring. On land, sea, air or, for that matter, in space, no one helps you get from 'mission possible' to 'mission accomplished' like Bruel & Kjaer.

For our most recent catalog, or to discuss a specific application, call us.


Brüel & Kjaer 

Bruel & Kjaer Instruments, Inc.

185 Forest Street, Marlborough, Massachusetts 01752 • 508-481-7000 • FAX: 508-485-0519

MA - 508-481-7737 NJ - 201-227-6100 MD - 301-948-0494 GA - 404-422-5200 MI - 313-522-8600 IL - 312-358-7582 TX - 214-751-1700;
CA - 714-978-8066 CA - 415-574-8100 WA - 206-324-5905 OH - 513-831-8878 AZ - 602-431-1606 CO - 303-469-7914 NM - 505-242-0316

Circle Reader Action No. 319



Electronic Components and Circuits

Hardware Techniques, and Processes

- 22 Ultra-Stable Superconducting-Maser Oscillator
- 24 High-Performance Power-Semiconductor Packages

- 26 Asymmetrical SRAM Cells for Radiation Tests
- 28 Advanced Fuel-Cell Modules
- 28 Monolithic III-V/Silicon Spatial Light Modulator
- 30 Stabilizing Semiconductor Devices With Hydrogen

Books and Reports

- 32 Advanced Small Rechargeable Batteries
- Computer Programs
- 68 Computer-Aided Engineering of Cabling
- 70 Designing Corrector Optics

Ultra-Stable Superconducting-Maser Oscillator

Frequency fluctuations would be reduced to as little as 2×10^{-19} .

NASA's Jet Propulsion Laboratory, Pasadena, California

dressed to
Edward Ansell
Director of Patents and Licensing
Mail Stop 301-6

California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125

Refer to NPO-17090, volume and number of this NASA Tech Briefs issue, and the page number.


Unprecedented stability of frequency in a superconducting, triple-cavity ruby maser oscillator would be achieved by the incorporation of a proposed amplitude-control subsystem. At present, fluctuations in frequency of 10^{-16} represent the state of the art. The new design should enhance ultra-stable measurements of time by reducing the fluctuations to 2×10^{-19} routinely, and to as little as 10^{-20} in exceptional cases.

Fluctuations in the amplitude of the oscillator signal cause fluctuations in the polarization magnetic field in the ruby, which is the active element of the oscillator. Because the magnetic field affects the frequency of oscillation, the amplitude fluctuations result in frequency fluctuations; in fact, the change in frequency is a known function of the change in amplitude. Heretofore, amplitude (and, therefore, frequency) fluctuations have been controlled by placing a power detector and an electronically variable attenuator at room temperature in the pump-signal transmission line. However, this configuration is insensitive to changes in amplitude that occur in the transmission line beyond the power detector or in the ruby itself.

In the new system (see figure) currents are induced in a superconducting pickup coil by changes in the magnetic field in the ruby. The currents from the coil are fed to a superconducting quantum-interference device (SQUID) magnetometer, the output of which is used to generate the control signal for the electronically variable attenuator. Thus, the attenuator varies the pump-signal amplitude in response to the magnetic-field fluctuations in the ruby. A very high feedback-loop gain is used for sensitivity of control and adequate compensation of fluctuations.

This work was done by Donald M. Strayer and G. John Dick of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 149 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be ad-



In the **Ultra-Stable Superconducting-Maser Oscillator**, the amplitude (and, therefore, the frequency) of oscillations is controlled in response to the condition of the active ruby element at low temperature. In the previous design, the amplitude was stabilized at a point in the transmission line, at room temperature.

TEAC. BECAUSE IT TAKES ALL KINDS.



If you need to measure the bumps, the shakes, the beats, the pressure, or the heat, TEAC makes a data recorder in the right size and format to meet your needs. In fact, we make so many different kinds of data recorders you almost need a data recorder to keep track of them all.

We made the first, and we offer the most extensive line of VHS data recorders. For ease of operation, economy, and convenience of media, the VHS format is the best.

We make the world's smallest 9-channel portable Philips cassette data recorder.

And we make a comprehensive line of reel-to-reel data recorders with extended recording times and up to 28 channels available.

We offer the widest selection of cassette data recorders from 1- to 9-channel models, from pocket-sized to sturdy laboratory and field systems.

Our new portable data recorders incorporating DAT technology are the leading edge in instrumentation recorders.

If you can't find the data recorder in the format you need from TEAC, then it doesn't exist.

And if it doesn't exist it's because TEAC hasn't built it yet.



TEAC®

Instrumentation Data Recorder Division.

© 1989 TEAC AMERICA, INC., 7733 TELEGRAPH ROAD, MONTEBELLO, CA 90640 (213) 726-0303

Circle Reader Action No. 344

High-Performance Power-Semiconductor Packages

A diode and a transistor satisfy stringent design criteria.

Lewis Research Center, Cleveland, Ohio


A 600-V, 50-A transistor and a 1,200-V, 50-A diode in rugged, compact, lightweight packages are intended for use in inverter-type power supplies that have switching frequencies up to 20 kHz. The packages provide low-inductance connections, low loss, electrical isolation, and a long-life hermetic seal. The design of the packages solves the historical problem of separation of the electrical interface from the thermal interface of a high-power semiconductor device.

The low inductance is achieved by making all electrical connections to each package on the same plane (see figure). This also reduces high-frequency losses by reducing coupling into the inherent shorted turns in the packaging material around the conductor axes. Stranded internal power conductors aid conduction at high frequencies, where the skin effect predominates. Other conductors are large and made of oxygen-free, high-conductivity copper for low electrical resistance. All conductors are made as short and thick as possible to minimize inductance. The insulators have high dielectric strength and a low dissipation factor.

The semiconductor device is electrically isolated from the package by a beryllia pad. The prime consideration in the design is the transfer of heat generated by the device to the heat sink, and beryllia was chosen because it provides the requisite electrical insulation yet is sufficiently thermally conductive. This feature also reduces the capacitance between the device and the heat sink, thereby reducing both the radiation of electromagnetic interference and common-mode currents in the heat sink.

Both semiconductor devices have glass-passivated junctions. All electrically active components are isolated from the main body of each package by insulation designed to withstand a potential of 2,500 V between the bottom plate of the package and the collector of the transistor or the anode of the diode. The hermetic seal of the package retains an atmosphere of nitrogen. All of the interior surfaces are coated with an extra insulating layer of parylene. If the hermetic seal is broken, this coat enables the device to passthrough the Paschen minimum-breakdown voltage without failure and protects the electrical parts from the environment.

Each package fits within a rectangular parallelepiped of 1.445 by 2.250 by 1.640 in. (36.7 by 57.2 by 41.7 mm). The complete diode and transistor packages weigh 84.5




All Electrical Connections are made on a plane at the upper end of the package. This reduces inductance and the losses due to the shorted-turn effect of the package materials.

and 86.0 g, respectively.

This work was done by David Renz and Irving Hansen of **Lewis Research Center** and Albert Berman of Microsemi Corp. Further information may be found in NASA CR-180829 [N87-28825], "Space Station Power Semiconductor Package Development."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700. LEW-14818

A photograph of the Space Shuttle Columbia during launch, viewed from a low angle looking up. The orbiter is attached to the external tank and solid rocket boosters. The orbiter's nose and wing are visible, with the USA flag and "USA" text on the wing. The boosters are firing, creating large plumes of white smoke and fire at the bottom. The background is a clear blue sky.

Precision Timing for the World's Most Demanding Applications

Odetics' Kode division is the technological leader for products that measure, record and generate time.

- ☐ GPS-Synchronized Time and Frequency Systems
- ☐ Time Code Generators
- ☐ Time Code Translators
- ☐ Time Code Generators/Translators
- ☐ Synchronous Time Code Generators
- ☐ Countdown Systems
- ☐ Remote Time Displays
- ☐ Video Time Inserters
- ☐ Automatic Tape Search Systems
- ☐ Master Timing Systems
and
- ☐ Time Interval Analyzers

Odetics

Kode Division

1515 South Manchester Avenue
Anaheim, California 92802-2907

☎ 714-758-0400

FAX 714-535-8532

Circle Reader Action No. 346

Asymmetrical SRAM Cells for Radiation Tests

Features of circuits are altered to increase or decrease sensitivity to radiation.

NASA's Jet Propulsion Laboratory, Pasadena, California

The features of static random-access memory (SRAM) integrated circuits can be altered to increase or decrease the susceptibility of memory cells to single-event upsets — changes in logic states induced by impacts of energetic charged particles. The ability to do this is important for the design of radiation-detecting integrated circuits (deliberately made more sensitive to ionizing radiation) and "radiation-hardened" integrated circuits — those intended to be relatively invulnerable to intense radiation.

As the drain of a transistor is enlarged, it can intercept more radiation, thus becoming more susceptible to single-event upsets.

However, the capacitance of the affected circuit node also increases, thus decreasing the change in drain voltage caused by the deposition of a given amount of charge from an impact, and this effect decreases the susceptibility to single-event upsets. Because these two competing effects occur to different degrees in different transistors of a memory cell, they can be traded off against each other. Selected areas of different transistors can be enlarged by different proportions that result in a specific overall increase or decrease in the susceptibility to single-event upsets.

For example, in the SRAM cell of Figure 1, the rate of upsets can be increased by

the use of asymmetrically enlarged drain regions in pullup transistor Q_2 and pull-down transistor Q_5 . For a given level and type of radiation, this design is estimated to increase the rate by a factor of about 3 over that of a symmetrical design.

The rates of upsets can be estimated by a state-space-analysis technique based on the use of a mathematical model of the memory cell with drains of various sizes. The technique is illustrated in Figure 2, where the horizontal and vertical axes represent the voltages on nodes b and a of Figure 1, respectively. If the voltage on node a is initially made higher than the critical voltage by a pulse of ionizing radiation,




Figure 1. This **Six-Transistor SRAM Cell** was made in versions with different sizes of the areas sensitive to single-event upsets (cross hatched areas).

tion, the cell will change state. For example, if node a is initially held at a low voltage and is suddenly raised past the critical voltage by the impact of an energetic ion, then the logic state of the cell will change from "zero" to "one".

In general, the critical deposited charge that causes a given kind of upset depends on these voltage-state-space relationships and the capacitances of the nodes. The sizes and asymmetry of the drains can be chosen not only to make the cell less sensitive (higher critical charge) but also to make one-to-zero upsets more likely than zero-to-one upsets (or vice versa).

This work was done by Martin G. Buehler of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 95 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Edward Ansell
Director of Patents and Licensing
Mail Stop 305-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125

Refer to NPO-16890, volume and number of this NASA Tech Briefs issue, and the page number.





Figure 2. **State-Space Analysis** is used to analyze the single-event-upset behavior of a memory cell like that shown in Figure 1. When the voltage on node a is set at one of the indicated initial values V_{ao} and then released, the voltages on nodes a and b then follow the indicated trajectory to a final logic "one" or logic "zero" state.



Sometimes it's just not convenient to bring the job to the test bench.

Cabtron has an enclosure for everyone who's ever had to wait days for the space to run an hour's worth of tests. It's the MTC Mobile Test Cart—a heavy duty enclosure designed specifically for portable use.


With the MTC, you can bring a complete test bench to the job. It's ideal for manufacturing, flight lines, test engineering, quality assurance, or any job where stationary equipment is normally used. The MTC also allows one set of test equipment to be used in several areas, reducing overhead while increasing efficiency.

Best of all, its advanced design and rugged construction allow it to be used even with sensitive test equipment. A heavy duty, prime 14 gauge steel frame protects against bumps and jars. And the entire

circuit is protected by 15 amp fuse to help guard against damaging voltage spikes.

You can even customize the MTC to fit your specific requirements with a large selection of accessories and a choice of single or dual bay models in 10 standard colors.

Put an end to test space delays by bringing the test bench to the job with the MTC. For more information, contact your Cabtron representative or call 1-312-498-6090.



CABTRON

Cabtron Systems, Inc.
200 Anets Drive
Northbrook, IL 60062
1-312-498-6090

Advanced Fuel-Cell Modules

Modules are designed for long life, light weight, reliability, and low cost.

Lyndon B. Johnson Space Center, Houston, Texas

A stack of alkaline fuel cells is based on modules, each of which consists of three fuel cells and a cooler (see figure). Each cell has an active area of 1 ft² (0.09 m²). The materials and configurations of the parts were chosen to extend life expectancy, reduce weight and manufacturing cost, and increase reliability.


Each cell includes the following components:

- a ribbed carbon fine-pore anode electrolyte-reservoir plate,
- a platinum-on-carbon catalyst anode,
- a potassium titanate matrix bonded with butyl rubber,
- gold-plated nickel-foil electrode substrates, and
- a silver-plated, gold-flashed molded polyphenylene sulfide cell holder.

The materials were chosen for resistance to corrosion. Structural components are generally molded to reduce costs. A simple cell-edge seal further reduces costs. The use of carbon for the electrolyte-reservoir plate and a thin nickel-foil electrode substrate help to keep weight low.

Electrical current passes through the silver plating of the molded cell holder to the adjacent cell. With a current of 140 A, the voltage across the internal cell resistance is only 1.5 mV.

Manifolds in the molded cell plate and the ribbed carbon electrolyte-reservoir plate allow the circulation of oxygen and hydrogen. Manifolds in the cooler plate provide for the circulation of coolant.



A Stack of Cells on a Cooler constitutes a fuel-cell module. Oxygen flows through the upper part of a cell, and hydrogen flows through the lower part.

Metering ports in the plates ensure the uniform distribution of the hydrogen, oxygen, and coolant. Seals molded in the plates prevent leakage. A thin nickel foil 5 mils (0.13 mm) thick separates the oxygen and hydrogen cavities.

This work was done by William F. Bell III,

Ronald E. Martin, Albin J. Struning, and Robert Whitehill of International Fuel Cells for Johnson Space Center. For further information, Circle 121 on the TSP Request Card.
MSC-21338

Monolithic III-V/Silicon Spatial Light Modulator

A silicon-based version provides for a choice of auxiliary on-chip circuitry.

NASA's Jet Propulsion Laboratory, Pasadena, California

Current techniques for the growth of device-quality GaAs on silicon substrates should enable the fabrication of a proposed silicon-based version of a photodiode-coupled spatial light modulator. High-density, two-dimensional arrays of picture-element modulators (e.g., a 1,000- by 1,000-element array on a 2-cm-square chip) could be used for real-time processing of images or parallel processing of arrays of data at very high throughput rates. The use of silicon would make available a wider range of auxiliary on-chip signal-processing circuitry for the coding and decoding of data, the addition or subtraction of brightness levels, spatial reformatting, and rescaling.

The proposed modulator would be a layered structure grown on a silicon substrate (see figure). First, a p-doped/intrinsic/n-doped (PIN) photodiode would be formed on the silicon substrate. Then a GaAs buffer layer would be grown over the silicon to form a suitable base for the growth of the InAs/GaAs multiple-quantum-well (MQW) PIN diode structure.

The relative positions of the two diodes would be reversed from those in the original version of the GaAs-based modulator (NPO-16298). The principle of operation is the same, however. The photo-carriers produced by the absorption of the modulating signal (photons of energy greater than

the 1.1-eV band gap of Si) in the PIN diode would change the voltage on the MQW diode, and thus the field acting on the MQW's, controlling its transmission of the signal to be modulated (photons of energy near the MQW exciton level and less than the Si band gap). As in the original modulator, the use of InAs/GaAs allows the modulated light signal to pass freely through the substrate and offers the flexibility of tailoring the quantum level of the MQW structure to adjust the wavelength of the modulated beam to values often used with fiber optics; e.g., 1.3 or 1.5 μ m.

The confinement of misfit dislocations generated by the 4-percent mismatch be-

TEAM WORK



ZB-A1

© PUBLICIS

THE COOPERATION OF 5 COUNTRIES HAS ASSURED EFFICIENCY ON THE GROUND AND RELIABILITY IN THE AIR: AIRBUS WAS DESIGNED AND EQUIPPED THROUGH THE COOPERATION AND PARTNERSHIP OF 4 EUROPEAN COUNTRIES AND THE U.S.A. THE ENGINES AND AVIONICS FOR EXAMPLE, ARE PARTLY DESIGNED AND BUILT IN COOPERATION WITH THE AMERICANS. AIRBUS ANSWERS THE PRECISE REQUIREMENTS OF AMERICAN, PAN AM, NORTHWEST, EASTERN, CONTINENTAL, AIR CANADA AND CANADIAN INTERNATIONAL, WHO FLY AND WILL FLY THEIR COLORS. THE QUALITY OF THE WORK AND THE ORIGINALITY OF THE CREATIVE EFFORT KEEPS US UP THERE — MEET THE TEAM.



aerospatiale

AEROSPATIALE INC. 1101 15TH STREET NW WASHINGTON DC 20005
PHONE: 202 293 0650

Circle Reader Action No. 658


tween the GaAs and Si lattices and the critical problem of control of the initial nucleation of GaAs on Si is being solved in several laboratories world-wide by using modulated-beam epitaxy and related vapor-phase deposition techniques.

This work was done by Joseph Maserjian and Sverre T. Eng of Caltech for **NASA's Jet Propulsion Laboratory**. For further information, Circle 98 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Edward Ansell
Director of Patents and Licensing
Mail Stop 301-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125

Refer to NPO-16916, volume and number of this NASA Tech Briefs issue, and the page number.



A Monolithic Photodiode-Coupled Light-Modulator Array could be constructed on a silicon substrate by growing InAs/GaAs multiple-quantum-wells over a silicon PIN diode layer. An intermediate GaAs buffer layer would confine lattice-misfit dislocations to the vicinity of the silicon.

Stabilizing Semiconductor Devices With Hydrogen

Damage by radiation would be healed rapidly.


NASA's Jet Propulsion Laboratory, Pasadena, California

Palladium would be incorporated into semiconductor devices to store hydrogen near the active regions, according to a proposal. This feature would provide the continuous, rapid recovery of the devices from degradation caused by hot electrons, photons, and ionizing radiation.

In a metal-oxide/semiconductor device, ionizing radiation degrades performance by causing charges to be trapped in the oxide and by generating undesired interface states at the Si/SiO₂ interface. In a very-large-scale integrated circuit with channel lengths of about 1 μm or less, the injection of hot carriers from the channels into the oxide also generates interface states, which can degrade the characteristics of transistors to the point of failure. In amorphous-silicon solar cells, ionizing radiation gives rise to electronic traps and recombination centers in the active region, which decrease the energy-conversion efficiency.

In these devices, the damage involves the breaking of existing bonds between hydrogen and silicon atoms or the creation of new unsaturated bonds between silicon atoms. The deleterious effects can be reversed quickly by providing atomic hydrogen to passivate the unsaturated silicon bonds. The hydrogen can be stored in palladium, which also catalyzes the dissociation of hydrogen from the diatomic

hydrogen and silicon atoms or the creation of new unsaturated bonds between silicon atoms. The deleterious effects can be reversed quickly by providing atomic hydrogen to passivate the unsaturated silicon bonds. The hydrogen can be stored in palladium, which also catalyzes the dissociation of hydrogen from the diatomic



Hydrogen Could Be Stored in palladium catalysts at one of the candidate sites shown in heavy colored lines.

TEAM WORK



WE PLAY OUR PART IN DEFENDING THE FREE WORLD. IN FRANCE, AEROSPATIALE HAS UNIQUE RESPONSIBILITY AS PRIME CONTRACTOR FOR BOTH STRATEGIC NUCLEAR IRBM AND SLBM MISSILE SYSTEMS, THE HEART OF THE FRENCH DETERRENT FORCE. AEROSPATIALE ALSO BUILDS SUCH MISSILES AS EXOCET, ERYX AND ASTER AND PARTICIPATES IN COMMON RESEARCH AND DEVELOPMENT PROGRAMS FOR MAJOR SYSTEMS, THUS SHARING RESPONSIBILITY FOR THE FREE WORLD'S DEFENSE. THIS ESSENTIAL COOPERATIVE EFFORT REQUIRES A PARTNERSHIP OF CONFIDENCE. MEET THE TEAM.



aerospatiale

AEROSPATIALE INC. 1101 15TH STREET NW WASHINGTON DC 20005
PHONE: 202 293 0650

molecular to the monatomic form.

The figure shows several candidate sites for palladium film catalysts, which would be inserted during manufacture as integral parts of the devices. The palladium films could be made by evaporation, sputtering, or chemical-vapor deposition. If additional storage were required, a thick layer of palladium could be plated on the inside of the package that surrounds the device. The hydrogen would be stored by exposing the palladium to hydrogen gas just before the package is sealed hermetically.

This work was done by Albert W. Overhauser and Joseph Maserjian of Caltech for NASA's Jet Propulsion Labora-

tory. For further information, Circle 25 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Edward Ansell
Director of Patents and Licensing
Mail Stop 301-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125.

Refer to NPO-17187, volume and number of this NASA Tech Briefs issue, and the page number.

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Advanced Small Rechargeable Batteries

Lithium-based units may offer the highest performance.

A paper reviews the status of advanced, small rechargeable batteries. It covers aqueous systems including lead/lead dioxide (better known as "lead/acid"), cadmium/nickel oxide, hydrogen/nickel oxide, and zinc/nickel oxide, as well as nonaqueous systems. All based on lithium anodes, the nonaqueous systems include solid-cathode cells (lithium/molybdenum disulfide, lithium/titanium disulfide, and lithium/vanadium oxide); liquid-cathode cells (lithium/sulfur dioxide cells); and a new category, lithium/polymer cells.

The use of rechargeable batteries continues to expand as their specific energies and volumetric energy densities increase. In consumer applications particularly, greater volumetric energy densities translate into smaller sizes of equipment.

The latest interest focuses on the nonaqueous lithium systems. They offer substantially higher specific energies (100 to 125 watt-hours/kilogram) and volumetric energy densities (150 watt-hours/liter) than aqueous systems. Lithium systems are still largely experimental. Only one, the lithium/molybdenum disulfide ("Molicel") type, is being manufactured in a commercial pilot plant and is available only as samples for evaluation. The most promising development in lithium nonaqueous systems is the use of polymer electrolytes instead of liquid electrolytes. The solid polymer eliminates leakage and makes it possible to produce batteries on a continuous assembly line with a minimum of handling.

Many advanced types of aqueous batteries are readily available. The best known of these are the small sealed lead/lead oxide and nickel/cadmium. Less well known are the nickel/hydrogen versions, most of which are too large and expensive for use by consumers.

The paper reviews the criteria for the selection of a battery and describes packages for small batteries. It reports on aqueous technology, noting several important innovations, including notably the bipolar versions of the sealed lead/lead oxide battery. These versions are designed for high pulsed power and deep discharge.

This work was done by Gerald Halpert of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the paper, "Advanced Small Rechargeable Batteries," Circle 139 on the TSP Request Card. NPO-17396

NASA Tech Briefs, June 1989

Time interval measurement. \$3850.



4 ps single-shot resolution
1.3 GHz frequency response
Statistics, analysis, and graphics


Finally, high resolution time interval measurement at an affordable price. The SR620 Universal Time Interval Counter offers 4 ps single-shot LSD on time intervals, and 11 digits of frequency resolution in one second. With powerful arming, gating, and triggering modes, the SR620 can measure time interval, frequency, period, pulse width, and phase, as well as rise and fall times.

The SR620 has built-in statistical functions, including mean, min, max, standard deviation, and Allan variance

for up to 1 million samples. Results may be displayed on the front panel, and graphed in histogram or strip chart form on an X-Y oscilloscope. Hardcopy is directly available on a plotter, printer, or chart recorder.

With both RS-232 and GPIB interfaces standard, the SR620 is also ideal for ATE applications.

Whatever your time or frequency measurement needs may be, the SR620 is the answer. For more information, call us at (408) 744-9040.



The SR620 provides graphic display of histograms and strip charts on any X-Y oscilloscope. With Autoscale and Zoom, graphics can be easily scaled. Attach a dot matrix printer or an HP-GL plotter and obtain hardcopy of any graph.

SR620 \$3850

Single-shot resolution	4 ps
Time interval jitter	20 ps rms
Maximum time interval	1000 s
Maximum frequency	1.3 GHz
Frequency resolution	10 ⁻⁶ Hz
Phase resolution	0.001°

Statistics	Mean, Min, Max, Std. Dev, and Allan Var.
Sample size	1 to 10 ⁶
Analyzer	Display on X-Y scope
Graphics	Histogram and Strip Chart
Hardcopy	Printer/Plotter
Interfaces	GPIB and RS-232

Oven Timebase (5x10⁻¹⁰/day) \$950



STANFORD RESEARCH SYSTEMS

1290 D Reamwood Avenue, Sunnyvale, CA 94089
TEL (408) 744-9040 FAX 4087449049 TLX 706891 SRS UD

NOW WORK OUR TEAM

ZB-A5

© PUBLICIS

OUR PARTNERSHIP CAN START RIGHT HERE. AS A MEANS TO SUCCESS, WE ARE EAGER TO DISCUSS A PARTNERSHIP IN ANY AREA OF MUTUAL INTEREST: SPACE, HELICOPTERS, AIRCRAFT AND DEFENSE. COMBINING OUR AEROSPACE TECHNOLOGY WITH YOUR EXPERTISE CAN ONLY RESULT IN OPENING NEW FRONTIERS. USE THIS SPACE TO WRITE TO US ABOUT YOUR AREA OF INTEREST, AND PLEASE ATTACH YOUR BUSINESS CARD. WE INVITE YOU TO MEET YOUR AEROSPATIALE TEAM.



aerospatiale

AEROSPATIALE INC. 1101 15TH STREET NW WASHINGTON DC 20005
PHONE: 202 293 0650



Electronic Systems

Hardware Techniques, and Processes

34 Counterrotator and Correlator for GPS Receivers

36 Image-Enhancement Aid for the Partially Sighted

38 Airplane-Acceleration Display for Low-Gravity Research

40 Chip Advancer for GPS Receiver

43 Three-Dimensional Robotic Vision System

44 Experimenting with Multiprocessor Simulator Concepts

Books and Reports

44 Passivity in Analysis of Robustness of a Control System

45 Absolute Stability and Hyperstability in Hilbert Space

47 Pilot Delays for Three Cockpit Controllers

Counterrotator and Correlator for GPS Receivers

All-digital design provides high accuracy and reduces cost.

NASA's Jet Propulsion Laboratory, Pasadena, California

An accurate, all-digital, high-speed processor comprising a correlator and down-converter has been developed for receivers in the Global Positioning System (GPS). This processor reduces roundoff and commensurability errors to extremely small values. The use of digital chip and phase advancers provides outstanding control and accuracy in phase and feedback. Great flexibility is imparted by the provision for arbitrary starting time and integration length. A minimum-bit design requires a minimum number of logical elements, thereby reducing the size, power, and cost.

The digital baseband processor in a GPS receiver (see Figure 1) consists of two major components: the tracking processor and the high-speed digital processor (see Figure 2). Control information sent by the tracking processor consists of the starting time, the sum interval length, the initial phase and phase rate, and the initial delay and delay rate. Based on this input, the high-speed digital processor accepts input data sampled at 1.5 to 2 MHz for the C/A channel and 15 to 20 MHz for the P channel and counterrotates the carrier, cross-correlates with the pseudorandom code, and accumulates the result over a nominal 20-ms interval.

All high-speed components are timed by the P or C/A sampling clock. The resulting correlation sums are collected by the tracking processor and reduced to extract measured phase, delay, and data bits. The tracking processor analyzes these phase and delay values, averages them to obtain feedback values to drive the digital equipment, and averages them over longer time intervals to reduce the output data rate.

Because all operations, including carrier downconversion, are digital, the phase and delay can be tracked and measured with extremely small errors. Great flexibility in control is provided by the fact that this design requires user-supplied values for starting time, integration length, phase, phase rate, delay, and delay rate. Another flexible feature of this design is the sampling rate. The design itself does not restrict the rate range of the sampling clock.




Figure 1. The **Digital Baseband Processor** in a GPS receiver recovers weak signals modulated by pseudorandom sequences.

Limits on the sampling rate will be set by the speed range of the specific equipment.

Even though the basic design would apply to any number of levels per sample, the minimum-bit design has been illustrated in Figure 2. In this design, there is a voltage loss of 4 percent in the voltage signal-to-noise ratio (SNR) due to three-level quantization of the downconversion sinusoids and a 20-percent loss if two-level sampling of the baseband signal is used. If three-level sampling is used, there is a loss of approximately 10 percent. If these small losses are acceptable in a given application, one can implement the minimum-bit de-

sign and arrive at a digital logic with a minimum number of logical elements, thereby greatly reducing the size, power consumption, and cost of the chip(s) fabricated to carry out these operations.

The design can also be used for quadrature processing, even though Figure 2 illustrates a single nonquadrature channel. To process complex signals, the operations are applied separately to each quadrature channel in parallel equipment channels. Both quadrature channels can be served by the same circuitry for generation of the delay code and counterrotation phasers. At the end of an integration inter-

SOLID STATE RELAY

Now a cheap off-the-shelf SSR that puts you in control. It lets you control the cost and the system's function in military applications.


**#2
IN A SERIES**

Here's what you get.

- Short Circuit Protection
- Status Indication
- Current Overload Protection
- Optical Isolation
- TTL & CMOS Compatible Control
- Built to meet the requirements of MIL-R-28750.
- Cost Effective



ACTUAL SIZE
CERAMIC PACKAGE




PART # CD21CDW

Review the electrical characteristics and call us for immediate application assistance.*

ELECTRICAL CHARACTERISTICS (-55°C to +105°C unless otherwise noted)				
	Min	Max	Units	
Bias Voltage (V_{BIAS})	3.8	6.0	V_{DC}	See Note 1
Bias Current (I_{BIAS})		15.0	mA	$V_{BIAS} = 5V_{DC}$
Control Voltage (V_{IN})	0	18.0	V_{DC}	
Control Current (I_{IN})		250	μA	$V_{IN} = 5V_{DC}$
Turn-Off Voltage ($V_{IN(OFF)}$)	3.2		V_{DC}	
Turn-On Voltage ($V_{IN(ON)}$)		0.3	V_{DC}	
Continuous Load Current		1.2	A	-55°C to +25°C
I_{LOAD} @ 60VDC		0.7	A	+85°C
Output Trip Current (I_{TRIP})	2.4 (Typ.)		A	+25°C, 100ms
On-Resistance (R_{ON})		0.65	Ohms	
Turn-On Time (T_{ON})		1.5	ms	
Turn-Off Time (T_{OFF})		0.25	ms	
Status Voltage (V_{STATUS})	1	18	V_{DC}	
Status Current (I_{STATUS})		2	mA	$V_{SAT} \leq 0.3V_{DC}$ See Note 2

Notes: 1. Series resistor is required for bias voltages above 6V_{DC}. $R_S = (V_{BIAS} - 6V_{DC})/15\text{ mA}$
 2. A pull up resistor is required for the status output. $R_{STATUS} = (V_{STATUS} - 0.3)/I_{STATUS}$
 3. Output will drive loads connected to either terminal (sink or source).
 4. Status circuit is a built-in test feature checking the input circuitry of the relay. Status output is low (on) when the input is on.

All power FET relays may drive loads connected to either positive or negative referenced power supply lines (source or sink modes).



TELEDYNE SOLID STATE
A Division of Teledyne Relays

*For immediate application assistance call 1-800-284-7007.

Teledyne Solid State, 12525 Daphne Avenue, Hawthorne, California 90250.




Figure 2. The **High-Speed Digital Processor** is accurate, flexible in operation, compact, conservative of energy, and relatively low in cost.

val, subsequent processing combines the complex sums with appropriate signs for the real and imaginary parts.

This work was done by J. Brooks Thomas, Jeffrey M. Srinivasan, and Thomas K. Meehan of Caltech for **NASA's Jet Propulsion Laboratory**. For further information, Circle 148 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Edward Ansell
 Director of Patents and Licensing
 Mail Stop 301-6

California Institute of Technology
 1201 East California Boulevard
 Pasadena, CA 91125

Refer to NPO-16998, volume and number of this NASA Tech Briefs issue, and the page number.

Image-Enhancement Aid for the Partially Sighted

Digital filtering would enhance the ability to read and to recognize objects.

NASA's Jet Propulsion Laboratory, Pasadena, California

An experimental digital electronic image-processing system may eventually assist partially sighted people in reading and in recognizing objects or small visible features. The system is intended primarily to help individuals who have central vision losses such as age-related maculopathies. These disorders degrade the high resolution central vision, forcing one to rely on the lower resolution peripheral areas of the retinas to recognize patterns. It should be


possible to construct a portable vision aid by combining miniature video equipment to observe the scene and display the images with very-large-scale integrated circuits to implement real-time digital image-data processing.

In effect, the system is digitally "fitted" to each eye. First, the patient's contrast-sensitivity function would be measured by asking the person to look at and detect patterns of various spatial frequencies and

contrasts in a visual testing and training instrument. The contrast-sensitivity function maps out the range of one's visible spatial frequencies. Generally, the afflicted observers can see only low and intermediate spatial frequencies (below about 8 cycles per degree).

The clarity of the perceived image can be partly restored by enhancing those spatial-frequency components that are less visible to the afflicted than to a normal observer of the same age. A measure of the required enhancement as a function of

When it comes to meeting your video needs...



Production


For sophisticated productions Panasonic has just what you need. Including a wide variety of single chip and three-chip cameras as well as special effects generators and 1/2" editing systems—both VHS and S-VHS.

For documentation, there are a variety of lightweight cameras and portable VHS recorders and camcorders. All with features to make documentation simple and fast. Like One-Touch Recording, Auto-White Balance and Auto-Focus.

When you come to Panasonic for your industrial video requirements you're getting more than the world's largest selection of video components and accessories. You're also getting the quality and reliability that has long been a trademark of Panasonic.



One number fits all - Panasonic GS00K88AGS0130.



Surveillance

For your security and surveillance operations Panasonic offers a wide choice of CCTV components. Choose from cameras in both color and black and white. There are also small and ultra-durable solid-state color and black and white cameras, time-lapse VCR's and, of course, monitors in virtually every size and configuration.

By now it should be clear: there's only one number you need to know when it comes to industrial video. GS00K88AGS0130.

Distribution

For your video networks Panasonic offers a multitude of VHS recorders and players. There are even video decks and monitors combined in a single unit. And of course you can't find a larger selection of black and white or color monitors.



For more information contact your local Panasonic Industrial Video Dealer. Federal Government Agencies: For your copy of the Authorized Communications Schedule Price List call or write the Government Marketing Department, Panasonic AVSG, 52 West Gude Drive, Rockville, Maryland 20850. 301/738-3840.

Panasonic
Industrial Company




Figure 1. A **Digital Filter in the Spatial-Frequency Domain** is derived from the afflicted observer's normalized contrast-sensitivity function (NCSF) and used to enhance the spatial frequencies that appear less visible.




Figure 2. The **Filtered Image** of the word is more easily recognized by an afflicted observer than is the unfiltered image.

spatial frequency is provided by the reciprocal of the afflicted observer's normalized contrast-sensitivity function (NCSF), which is the afflicted patient's contrast-sensitivity function divided by the contrast-sensitivity function of the normal observer. The reciprocal of the NCSF is limited to the spatial frequencies between the lowest and highest spatial frequencies visible to the afflicted observer.

The digital compensating filter derived from the NCSF is implemented as a transfer function that multiplies a fast Fourier transform of the scene in spatial-frequency space (see Figure 1). The individualized compensation filter that is marketed will be filtering in the spatial domain for fast, inexpensive image enhancement. The compensating filter includes a gain term that controls the compromise between enhancement of resolution and rejection of noise. The fast Fourier transform is then inverted, and the contrast of the resulting processed image (see Figure 2) is adjusted to prevent clipping at the bright and dark extremes of the scene.

An afflicted observer could view the scene through a magnifier to shift the spatial frequencies downward and thereby improve the perceived image. However, the less the magnification needed, the larger the scene that can be observed. Thus, one measure of the effectiveness of the new system is the amount of magnification required with and without it. In a series of tests, it was found that 27 to 70 percent more magnification was needed for the afflicted observers to recognize unfiltered words than to recognize filtered words.

This work was done by T. A. Lawton and D. B. Gennery of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 44 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

*Edward Ansell,
Director of Patents and Licensing
Mail Stop 301-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125*

Refer to NPO-17307, volume and number of this NASA Tech Briefs issue, and the page number.

Airplane-Acceleration Display for Low-Gravity Research

A bar-graph display facilitates precise control of trajectories.

Lewis Research Center, Cleveland, Ohio

An acceleration display for an airplane helps the pilot to fly trajectories that produce the effect of zero gravity or fractions of Earth gravity (g) within the airplane. With

the help of the display, the pilot can adhere to a predetermined fraction of g, with minimal lateral acceleration.

Developed for a Learjet used for micro-

gravity research, the display consists of light-emitting-diode (LED) bar graphs (see figure). A pitch-axis bias switch lets the pilot select one of nine settings for the zero reference of the display so that any of the following trajectories can be flown: 0 g, $\frac{1}{20}$ g, $\frac{1}{10}$ g, $\frac{1}{6}$ g (Lunar gravity), $\frac{1}{5}$ g, $\frac{1}{4}$ g, $\frac{1}{3}$ g (Martian gravity), $\frac{1}{2}$ g, and $\frac{3}{4}$ g. The accelera-

tions can be sustained within 0.01 g for 5 s, 0.02 g for 7 s, and 0.04 g for 20 s.


Three LED bar displays present acceleration in the x (thrust), y (lateral), and z (pitch) axes. The pitch and lateral displays are located in front of the pilot, who controls the yoke and rudder. The thrust display is located in front of the copilot, who controls the throttles.

In comparison with the usual needle displays, the LED bar-graph displays take up less panel space and are easier to align with the axes they represent. They have no moving parts and are not subject to parallax. However, they are not legible in direct Sunlight and have resolution limited by the finite sizes of the individual LED's.


The overall display system includes an

accelerometer block, a power-supply-and-interface box, the thrust-axis display, and the pitch-and-lateral-axes display. The accelerometer block includes three servoaccelerometers orthogonally mounted on an adjustable triaxial base that allows fine alignment of the accelerometers with respect to the airplane. The accelerometer block and the power-supply-and-interface box are located near the center of gravity of the airplane in the luggage area.

The pitch-axis bar graph has two regions. The innermost LED's (10 positive and 10 negative) have a high-resolution logarithmic scale. The outermost LED's (10 positive and 10 negative) have a low-resolution linear scale. The inner LED's are set to correspond to a range of 0.06 g and the



PILOT'S SIDE



COPILOT'S SIDE

The Pilot, Who Controls Pitch and Yaw, views the display of pitch and lateral accelerations. The copilot, who controls the throttles, views the thrust-acceleration display.

DISCOVER THE ADVANTAGE

Low Thermal Conductivity
Chemical Attack Resistant
Uses To 2200°C

Our zirconia fiber materials offer benefits you can't get from other products. Ranging from flexible cloths and felts to rigid boards and cylinders, our varied product line can help you overcome your toughest application problems. So Discover the Advantage and call us today.

Zircar
FIBROUS CERAMICS

ZIRCAR Products, Inc.
P.O. Box 458, Florida, New York 10921
914-651-4481 • Telex 996608 • Telefax 914-651-3192

outer stacks to a range of 3 g. The inner LED's are driven by comparators with logarithmic increments to provide finer resolution about zero than would otherwise be possible with a linear scale.

This work was done by Marc G. Millis of

Lewis Research Center. Further information may be found in NASA TM-87358 [N87-18801/NSP], "Acceleration Display System for Aircraft Zero-Gravity Research."

Copies may be purchased [prepayment required] from the National Technical In-

formation Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700. LEW-14650

Chip Advancer for GPS Receiver

Instrumental errors can be made negligible.

NASA's Jet Propulsion Laboratory, Pasadena, California

In a Global Positioning System (GPS) receiver, a pseudorandom code sequence can be generated by simple digital logic that incorporates the effects of time, the delay, and the rate of change of the delay. For each integration interval, both the delay and the rate of change of the delay can be initialized to a small fraction of a chip — for example, to the order of 10^{-7} — thereby making feedback control and the extraction of delay highly accurate and flexible. With appropriate selection of the sampling rate relative to the chip rate, commensurability errors can be reduced to extremely small levels.

By supplying the proper initial integer chip value to initialize the code generator and the proper fractional chip and chip rate for the chip advancer, external hardware or software can control a code sequence that starts at a fraction of a given chip and advances at the selected chip rate. In a GPS receiver, the initial chip value (integer plus fractional parts) would be based on the starting time and the feedback delay, while the chip rate would be equal to the sum of the rate of change of the delay and the fundamental chip rate divided by the sample rate. The chip advancer is activated and deactivated by a "start" line. Over a correlation interval, the model delay consists of a linear time function.

As illustrated in the figure, the chip advancer is initialized by external hardware or software that supplies an initial fractional-chip value in the form of an integer equal to the fractional chip times 2^N and a chip rate in the form of an integer equal to the chip rate (in chips per sample point) times 2^N , where N is the number of bits in the fractional-chip register. Simultaneously, the external device also initializes the registers of the code generator so that the code generator will produce the correct code sign for the first sample point.

When processing is started, the chip advancer is clocked by the sampling clock. For each new sample point, the chip advancer adds the number in the rate register to the number in the fractional-chip register. When the fractional-chip register overflows, indicating a transition to a new chip, a pulse is generated. That pulse triggers enabling logic circuitry that lets the concurrent sampling clock advance the code generator to the next chip. If the code

generator does not receive a new-chip-advance signal for a given sample point, the previous code sign persists for that sample.

If selected sampling rate is effectively incommensurate with the fundamental chip rate, the integrated error due to discrete sampling of the model code sequence can be reduced to negligible levels after integration over a fairly short time. In selecting a sampling rate, it is advisable to choose a value that is sufficiently removed from highly commensurate ratios (e.g., $2/1$, $3/2$, etc.) so that the Doppler shift cannot change the chip rate to a value highly commensurate with the sampling rate.

An important option in using the chip advancer is that the starting chip value, including the fractional chip, can be set exactly every sum interval. Thus, the measured delay will be corrupted by roundoff errors at the level of 2^{-N} or less, which is less than 100 nanochips for a 24-bit chip advancer. The buildup of the roundoff error due to roundoff in the rate register can be eliminated by computing the roundoff accumulation and offsetting the initial delay to


compensate. Further, the flexibility of accurately resetting the chip and the chip rate for each correlation interval is very useful in many applications; for example, those involving multiplexing schemes. The flexibility in the starting time and the sum interval is very useful in aligning the correlation interval with the beginnings and endings of data bits.

This work was done by Thomas K. Meehan, Jeffrey M. Srinivasan, and J. Brooks Thomas of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 147 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to


Edward Ansell
Director of Patents and Licensing
Mail Stop 301-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125.

Refer to NPO-16996, volume and number of this NASA Tech Briefs issue, and the page number.



The **Chip Advancer**, part of a correlating receiver, advances a pseudorandom sequence of data in small increments.

IN CASE OF EXTREME TEMPERATURE AND HIGH LOADS...



Get your own *free copy* of this informative brochure, "VESPEL," by completing the postpaid card at right and dropping it in the mail. For more information, turn the page.




NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 4 BLOOMFIELD HILLS, MI

POSTAGE WILL BE PAID BY ADDRESSEE



Du Pont VESPEL® Product Information
P.O. Box 1138
Bloomfield Hills, Michigan 48303-1138




ORDER YOUR *FREE BOOK* ON **VESPEL® POLYIMIDE PARTS FROM DU PONT.**

VESPEL parts can pay for themselves many times over by providing high reliability while keeping assembly costs, maintenance costs and warranty claims low.

Du Pont and VESPEL give you custom-made quality parts together with professional assistance and single-source accountability from resin to parts — something you just don't get from other materials suppliers.

VESPEL parts can resist both wear and creep at continuous temperatures ranging from cryogenic to 550°F (288°C) while withstanding excursions to 900°F (482°C). VESPEL parts will not soften or melt — continuing to excel as tough thermal and



electric insulators at temperatures that turn many other high-performance plastics to puddles. This thermal stability helps

VESPEL parts perform at very high pressure velocities (PVs). In fact, VESPEL parts have demonstrated the ability to perform at PVs of up to 1,000,000 psi x fpm with lubrication, and 300,000 PV psi x fpm without external lubrication.

Of course, PV limits and maximum continuous use temperatures of virtually any material will vary from application to application depending upon a number of different factors. The only sure way to determine how VESPEL parts will perform in your application is to test them in your application.

VESPEL polyimide parts, made by DuPont, have 25 years of proven performance — extending service life, reducing component failure and cutting warranty costs in thousands of critical applications.

Hundreds of millions of VESPEL



Our VESPEL product team assists you from selection of composition and engineering of your custom part through prototyping and on-time, on-spec delivery of parts manufactured under strict SPC conditions.

washers, thrust buttons, spacers, flanged bushings, valve seats and other mechanical or electronic parts are in use today in the demanding environments of jet engines, office machines, motor vehicles and manufacturing equipment.

☐ **YES**, I am interested in learning more about DuPont VESPEL polyimide parts. Please send me my free copy of "VESPEL" right away.

Name _____

Title _____

Company Name _____

Address _____

City _____

State _____

ZIP _____

() _____

Phone _____

**Send for your
free copy of
"VESPEL" today!**

Don't wait until you need a part with the strength and durability of VESPEL. Return the attached post-paid card now for 12 colorful, fact-filled pages on VESPEL polyimide parts by DuPont. Or, if you prefer, call *toll-free* 1-800-426-7246.



Three-Dimensional Robotic Vision System

Stereoscopy and motion would provide clues to the outlines of objects.

Marshall Space Flight Center, Alabama

A proposed robotic vision system would analyze views from two television cameras to detect rigid three-dimensional objects and reconstruct them numerically in terms of the coordinates of corner points. The stereoscopy and the effects of motion on the two images would complement each other in providing the image-analyzing subsystem with clues to the natures and locations of principal features.

The brightnesses of picture elements would be turned into information about the object in view by three digital processes (see Figure 1): a low-level process to extract the corner points, a middle-level process to establish the correspondences between points in the stereoscopic (spatial) and motional (temporal) modalities, and a high-level process to compute the three-dimensional coordinates of the corner points by integration of the spatial and temporal correspondences.

Corner points would be detected by the Zuniga-Haralick corner-detecting algorithm, in which a step-edge operator based on zero crossings of second directional derivatives of brightness provides a measure of the "cornerness" of a point. The spatial correspondence of the corner points from two stereoscopic images would be found by the epipolar-line technique (see Figure 2), in which a point in the left (or right) image is tentatively said to correspond to a point in the right (or left) image if it lies close to the imaginary line (the epipolar line) in the left (or right) image that represents the line of sight from the right (or left) camera to the point in the right (or left) image. The ambiguities would be resolved and tentative identifications affirmed or denied in the higher level processes.

The temporal correspondence between points in successive images would be found by a cooperative-relaxation matching algorithm, which selects matching according to the consistencies of points and distances between points at successive image times. The temporal correspondence from two successive pairs of images would be used to resolve the ambiguities in the spatial correspondence by a two-step integration of the spatial and temporal correspondences to produce a cooperative and consistent correspondence for each pair of successive images. In the first step, matching points would be required to satisfy both spatial and temporal correspondences. In the second step, matching points would be required to exhibit the least deviation from rigidity.




Figure 1. This **Digital Image-Processing System** would act as an "intelligent" automatic machine-vision system by processing views from stereoscopic television cameras into three-dimensional coordinates of a moving object in view.




Figure 2. The **Epipolar-Line Technique** would be used to find corresponding points in stereoscopic views. Points close to the epipolar line in the left view are tentatively identified as corresponding to points on the line of sight in the right view.

Once the final correspondence is established, the corner points in three-dimen-

sional space could be determined easily as the intersections of the lines of sight to the

points in the right and left views. The motion of the object could then be estimated as an affine transformation that uses the least-squares method based on the com-

puted points of the object in two consecutive frames.

This work was done by *Thinh V. Nguyen* of *Multisignal Technology Corp.* for **Mar-**

shall Space Flight Center. For further information, Circle 48 on the TSP Request Card.

MFS-27191

Experimenting With Multiprocessor Simulator Concepts

A system helps users develop equipment and programs.


Lewis Research Center, Cleveland, Ohio

A multiple microcomputer system is used to investigate the application of parallel processing to real-time simulation. The system, called the real-time multiprocessor simulator (RTMPS), is a tool for developing low-cost, portable, user-friendly simulators.

RTMPS includes off-the-shelf microcomputer boards and minimal custom interface circuitry to provide as many interprocessor communication paths as possible. This approach allows the emphasis to be placed on the development of software, which is a critical element in parallel processing. Among the software issues that RTMPS can address are high-level programming languages, scheduling the transfer of data between computers, the partitioning of programs, and support by an operating-system program.

The system can be based on a variety of microcomputer types. The characteristics of the hardware of each type are accounted for in a system executive program, a set of macroinstructions, and a target-computer-definition file. The system executive program performs such rudimentary functions as initialization, transfer of data, and handling of interruptions. The system macroinstructions define basic mathematical and data-transfer operations for the target hardware. The target-definition file provides information in high-order language about the microcomputer programming model. The system translates the high-order language into a time-efficient Assembler source program.

To retarget the system to a different microcomputer, changes are made only in the system executive program, the macroinstructions, and the target-computer-definition file. The bulk of the software remains unchanged.



With **Dual-Bus Architecture**, each microcomputer communicates with a corresponding microcomputer on the opposite bus through a dual-port interface memory. Transfers of data to and from the front-end processor occur on the interactive information bus. Transfers of data related to simulation calculations occur on the real-time-information bus.

The system is based on a dual-bus architecture with multiple microcomputers on each bus (see figure). The front-end processor is the main processor: It is the interface between the user and the system and handles such operations as the loading of programs into each of the simulation processors; control of modes of simulation; and the handling, output, and display of data. An analog input/output interface enables the connection of such devices as sensors, actuators, and analog computers.

This work was done by *Richard A. Blech*

and *Anthony D. Williams* of **Lewis Research Center.** Further information may be found in NASA TM-38802 [N86-28651/NSP], "Hardware Configuration for a Real-Time Multiprocessor Simulator."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700. LEW-14617

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Passivity in Analysis of Robustness of a Control System

A robustness margin (a measure of the degree of passivity) is defined.

A paper presents a new approach to the analysis of the stability of a multivariable feedforward-and-feedback control system that consists of an exponentially stable linear time-invariant (LTI) feedforward subsystem and a nonlinear time-varying (NTV) or a dynamic feedback subsystem. Whereas older methods of analysis are based on

small-gain conditions (e.g., maximum and minimum singular conditions, H_∞ norm, and μ measure), the new method is based on the notion of passivity, which is quantified by a robustness margin. In effect, this margin provides a bound on the magnitudes of perturbations, below which the perturbations will not make the system unstable.

The feedforward subsystem is assumed given, and the problem is to characterize a class of feedback subsystems that pre-

serve the exponential stability of the system. By finding as large a stability region as possible under the nominal control, the controller can be tuned to enhance the robustness margin by effectively moving the nominal feedback system to a different point.

The measures of robustness used in the small-gain methods involve only the magnitude (but not the phase) information of the feedforward subsystem. Based on experience in the design and analysis of classical compensators, it is known that the phase of the nominal controlled system is frequently of critical importance. Ignoring this information can sometimes lead to conservative design. The argument of passivity is motivated by this observation.

The characterization of robustness involves the Hermitian part of a transfer function, which contains both the gain and phase information. The importance of passivity lies in the concept of energy. The condition for the stability of the system can be stated as follows: If energy generated by one block can be dissipated by the other block, the system is stable. The amount of energy generated or dissipated by a system is characterized by a quantity called the ν index, which is a measure of the minimum amount of parallel dissipation required to render a system passive. This energy-transfer perspective is powerful because nonlinear systems can be considered within

the same context. Thus, hitherto inadmissible perturbations like saturation of actuators, coulomb friction, stiction, and hysteresis can all be analyzed.

Three classes of perturbations are considered: memoryless, NTV, exponentially stable LTI, and general nonlinear dynamic. The theoretical basis of the stability condition is on the theorem of absolute stability for the first class of perturbations and the theorem of hyperstability for the latter two. These perturbations are represented in terms of a lower bound involving an inner product and an upper bound on the norm. The stability condition then shows trade-offs between the two bounds. When only the bound on the norm is imposed, the H_∞ stability criterion is recovered. Because the Lyapunov technique is used rather than the multivariable Nyquist theorem, nonlinear perturbations (both memoryless and dynamic) are permitted. For nonlinear dynamic systems, the small-gain condition involves truncated L_2 norms.

When the perturbation is characterized by a matrix that contains additional block diagonal structure, a robustness margin is derived for each block. The derivation is based on the generalization of the Gorshgorin theorem to block-diagonal matrices. If each of the diagonal blocks is of size one, then a margin for positive and negative variations of each diagonal element can be obtained by repeated application of the

passivity argument to the feedforward subsystem with signs of some of its columns and rows reversed. An upper bound for the μ measure is easily computed by use of the same analysis.

This work was done by John Ting-Yung Wen of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Robustness Analysis Based on Passivity," Circle 81 on the TSP Request Card.


NPO-17589

Absolute Stability and Hyperstability in Hilbert Space

Theorems on the stabilities of feedback control systems are proved.

A paper presents recent developments regarding the theorems of the absolute stability and the hyperstability of a feedforward-and-feedback control system. These theorems are applied in the analysis of nonlinear, adaptive, and robust control. In this paper, the theorems are extended to provide sufficient conditions for stability in a system that includes a nonlinear feedback subsystem and a linear time-invariant (LTI) feedforward subsystem, the state space of which is a Hilbert space, and the input and output spaces of which have fi-

Technical furniture is not office furniture.



It's something else altogether.

FlexTech technical furniture is built to accommodate the costly equipment it must support and the valuable personnel who will use it. At Kewaunee, all we make is technical furniture. And we've made it best for 80 years, with attributes that include:

- **worksurface supports over 1000 pounds vibration free**
- **easy to assemble, disassemble, and store**
- **manages all utilities: electricity, air, water and gas**



KEWAUNEE Scientific Corporation

For further information about technical workstations from Kewaunee, please call 800/824-6626. In Texas 512/398-5292

nite numbers of dimensions. (In the case of absolute stability, the feedback subsystem is memoryless and possibly time varying. For hyperstability, the feedback system can be a dynamical system.)

It had been shown previously (by the positive-realness lemma) that a sufficient condition for closed-loop exponential stability is the positive realness of some transfer function involving the feedforward subsystem. Later, this result was generalized to the case of a dynamic feedback subsystem. This generalization, termed hyperstability, has become the cornerstone of the field of adaptive control.

Positive realness is typically stated as a

frequency-domain condition of the non-negativity of the Hermitian part of the transfer function of a given stable LTI system. It can be shown that if a system is positive real, then it cannot generate energy. If, furthermore, the system is strictly positive real, it dissipates energy. From the energy point of view, the theorems of absolute stability and hyperstability simply state the conditions under which the system dissipates energy and thus is stable. Specifically, if both the feedforward and the feedback subsystems dissipate energy, the system must be stable.

In this paper, the proofs of stability in the infinite-dimensional Hilbert space are based

on a Lyapunov type of analysis that incorporates energylike quadratic Lyapunov functions similar to those used in the finite-dimensional case. Essentially, it is shown that if the state belongs to L_2 under any L_2 input, then the state is strongly asymptotically stable. Using the foregoing result, it is shown that if the feedforward subsystem is strictly positive real and the feedback subsystem is characterized by a nonnegative operator, then the system is exponentially stable. If the feedback subsystem is dissipative in the sense of Popov's inequality, then the interconnected system is asymptotically stable. If a stronger exponential Popov's inequality is satisfied, the interconnected system attains exponential stability.

When the feedforward system is not strictly positive real and/or the feedback system is not dissipative, one would expect intuitively that if one of the subsystems dissipates "more energy" than the other could generate, stability would be preserved. This heuristic notion is rigorized by the introduction of an index, called the ν index for convenience, that measures the closeness of a given system to positive realness in terms of the minimum amount of additional parallel dissipation needed for the system to be positive real. General conditions for the stability of the system can then be stated in terms of the ν index.

The amount of energy that the feedforward subsystem can generate is bounded by its ν index. Hence, if the feedback subsystem under positive feedback by an amount equaling the ν index of the forward subsystem remains dissipative (in the sense of nonnegativity of the inner product of its input and output), the interconnected system is exponentially stable. The theorem of hyperstability states the same result except that the energy-dissipation criterion used for the feedback subsystem is in the sense of the L_2 inner product between its input and output (i.e., via the Popov inequality). The type of stability of this more general characterization of energy dissipation is weakened to asymptotic stability unless a stronger exponential Popov inequality is satisfied, in which case exponential stability obtains.

The ν index is a time-domain characterization, which, in general, is difficult to calculate directly. It is shown via the Hilbert-space version of the positive-realness lemma that the ν index is equivalent to a frequency-domain attribute, called the ν_F index, which is based on the Hermitian part of the transfer function. Because the input and output spaces are finite-dimensional, the ν_F index, and hence the ν index, can be easily computed. The utility of these results is demonstrated in an application to the analysis of the robustness of an infinite-dimension linear quadratic regulator. It is shown that the generalization of the classical $(\frac{1}{2}, \infty)$ gain margin and $(-\frac{\pi}{3}, \frac{\pi}{3})$ phase margin hold for this case. It is further

Advanced coating and laminating technology

Rexham custom coats and laminates flexible films, foils, and papers for use in electronics, aerospace materials, reprographics, and other high-performance applications.

You find resources developed during 30 years' work with high-precision projects—

- Coating accuracy capabilities in the millionths

- Clean room manufacturing
- Sophisticated on-line quality inspection
- Extensive analytical capabilities


Call for our Credentials Package. Complete confidentiality guaranteed.

Rexham Industrial

P.O. Box 368
Matthews, NC 28106
(704) 847-9171

Coating and laminating precision without compromise.

Coating/laminating lines (4 plants)	15
+ new plant (1990)	2
Clean rooms (4 plants)	8 Class 10,000 to Class 1,000
+ new plant	2 Class 100



shown, by a modified design, that the gain margin can be widened to (γ, ∞) and $(-\frac{\pi}{2} + \eta, \frac{\pi}{2} - \eta)$ for any $\gamma > 0$ and $\eta > 0$.

This work was done by John Ting-Yung Wen of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Absolute Stability and Hyperstability in Hilbert Space," Circle 143 on the TSP Request Card.
NPO-17590

Pilot Delays for Three Cockpit Controllers

The pilot effective delay increases with the system delay.

A report compares the pilot effective time delays measured in simulations of aircraft-control systems equipped with a Space Shuttle rotational hand controller and with two versions of a conventional stick-type hand controller. The report should be of interest to those concerned with the design of multiple-axis controllers in aircraft, armored vehicles, industrial machinery, and remote manipulators: the operator response or delay is critical to the stable and accurate operation of such systems.

Each of the three controllers was installed in a Space Shuttle cockpit simulator. The Space Shuttle hand controller had three degrees of freedom and nonlinear gearing. The more-conventional two-degree-of-freedom control stick had linear gearing and was equipped first with a stiff set of springs (heavy conventional stick), then with a softer set of springs (light conventional stick). The signal from the control stick was processed through the cockpit simulator with a 40-ms frame time, then sent to the critical-task tester. The total inherent delay between the pilot and the critical-task tester was 46 ms: 20 ms of sampling delay plus 26 ms of computation time.

The critical-task tester is a specialized electronic subsystem used to measure the pilot effective delay, τ_e , in response to a simulated first-order, closed-loop, compensatory tracking task. The critical task involves an unstable controlled element, the instability of which increases with time. Eventually, the system reaches a critical point beyond which the unstable system cannot be controlled. The amount of instability at that point gives a measure of τ_e .

The critical-task tester was used to measure the τ_e values in the roll and pitch axes in each of the three control configurations. Measurements in each case were made without additional system delay and with 250 ms of additional system delay. Thus, the total system delays were 46 and 296 ms, respectively. The test subjects were four test pilots and one nonpilot engineer.

The test data indicate that the heavy conventional stick had the lowest pilot effective time delays in both axes, both with and without the added system delay. The light conventional stick had τ_e values similar to those of the Space Shuttle controller. With all three controllers, τ_e increased with the added system delay. The increases in τ_e caused by the increase in system delay were more significant than the differences in τ_e among the three controllers: apparently, at large system delays one controller is about as good as another.

This work was done by Cynthia M. Privoznik and Donald T. Berry of Ames Research Center. Further information

may be found in NASA TM-86030 [N86-19324/NSP], "Comparison of Pilot Effective Time Delay for Cockpit Controllers Used on Space Shuttle and Conventional Aircraft."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Ames Research Center [see page 14]. Refer to ARC-11797.


A system suitable for your application



The "PSO 7010" is a combination between an 8 channel digital memory oscilloscope and the flexibility of a MS-DOS-computer

PSO 7010

- 2 - 8 channels
- 8 Mwords data memory
- Sample rates up to 20 MHz per channel
- CPU 80 286/12 MHz
- 50 MByte hard disk drive
- 1.44 MByte Floppy disk drive
- Internal analysis programs



Convince your self of our variety and capacity in measurement and data aquisition systems. Our specialist will give you the support you need for your special measurement problem. Ask for your new general catalogue.


Measurement technology by Krenz - Quality you should go for.

Krenz

Electronics

KRENZ ELECTRONICS INC.
940 Calle Amanecer, Suite P
San Clemente, CA 92672

Tel.: 71 43 61 68 66
Telex: 910 250 3320
Telefax: 71 43 61 68 67



Hardware Techniques, and Processes

- 48 Long-Wavelength Infrared Detector
- 50 Thermal Analysis for Reluctant Glass Formers
- 54 Dynamic-Range Compression for Infrared Imagery
- 55 Making Durable Specimens for Electron Microscopy

55 Isothermal Equation of State for Compressed Solids

- 56 Equation of State With Temperature Effects for Solids
- 58 Measuring Transmission Efficiencies of Mass Spectrometers
- 59 Automated Heat-Flux-Calibration Facility

Books and Reports

- 60 Accuracy of Hot-Wire Anemometry in Supersonic Turbulence
- 61 Computing Geopotential Perturbations
- Computer Programs
- 70 Designing Corrector Optics

Standard Method for Radiation Tests of Liquids

Three vials are used.

NASA's Jet Propulsion Laboratory, Pasadena, California


A simple procedure provides a standard method for radiation tests of liquids. It assures identical handling and dosage so that data from different test laboratories can be compared reliably. Developed for measuring properties of liquids for use in radiation-resistant liquid-dielectric capacitors, the procedure can be used for any of a variety of liquids proposed for use in the high-radiation environment — in x-ray and particle-accelerating machines and nuclear reactors, for example.

A pair of glass vials, joined by a frangible neck and equipped with valves, is used (see figure). A third vial is also used. It is filled with a control specimen and not irradiated. A technician first opens valve A, valve B, and the vacuum valve to pull contaminants from the vials. The vacuum valve and valve B are then closed and the filling valve opened to transfer the specimen liquid to vial A.

Next, the vacuum and filling valves are closed while valve A is left open and valve B is opened. The technician then irradiates the vials. The gas given off by the liquid in vial A as a result of chemical reactions stimulated by the radiation is collected in vial B. When irradiation is complete, the technician closes valves A and B, then breaks the joint to separate the vials.

The irradiated liquid in vial A is tested for such properties as viscosity, dielectric strength, and dielectric constant. The gas in vial B is analyzed in a mass spectrometer to identify its constituents.

This work was done by Frank L. Bouquet and Robert B. Somoano of Caltech for NASA's Jet Propulsion Laboratory. For



The Twin-Vial Portion of the Testing Apparatus provides for standardized handling and irradiation of the liquid specimen. Vials A and B are readily separated so that each can be subjected to different tests.

for further information, Circle 138 on the TSP Request Card. NPO-16840

Long-Wavelength Infrared Detector

Intersubband absorption in coupled quantum wells would enable detection at wavelengths from 10 to 100 μm .

NASA's Jet Propulsion Laboratory, Pasadena, California

A proposed device would detect infrared photons of 10- to 100- μm wavelength

by intersubband absorption in coupled quantum wells. Such a device would be


made of $\text{Al}_x\text{Ga}_{1-x}\text{As}/\text{GaAs}$ or other semiconductor material, even though the ma-

After centuries of practice, mankind perfects engineering calculations: MathCAD.

Announcing MathCAD 2.5: The Dawn of a New Age.

What the historians will call it, only time will tell.

Perhaps the Century of Speed, or the Era of Ease. But whatever the name, this is the age of MathCAD 2.5, the only math package that looks and works the way you think.



MathCAD 2.5 includes 3-D plotting, HPGL sketch import, and PostScript output.

MathCAD is far and away the best-selling math package in the world. Because it lets you perform engineering and scientific calculations in a way that's faster, more natural and less error-prone than the way you're doing them now—whether you're using a scratchpad, calculator, spreadsheet or program that you wrote yourself.

And now we've made the best even better. MathCAD 2.5 is a dramatically improved version that includes three-dimensional plotting, enhanced numerical analysis, and the ability to import HPGL files from most popular CAD programs, including AutoCAD.* And now you can print on PostScript® compatible printers.

And like before, MathCAD's live document interface™ lets you enter



equations anywhere on the screen, add text to support your work, and graph the results. Then print your analysis in presentation-quality documents.

It has over 120 commonly used functions built right in, for handling equations and formulas, as well as exponentials, differentials, cubic splines, FFTs and matrices.

No matter what kind of math you do, MathCAD 2.5 has a solution for you. In fact, it's used by over 50,000 engineers and scientists, including electrical, industrial, and mechanical engineers, physicists, biologists, and economists.

But don't take our word for it; just ask the experts. PC Magazine recently described MathCAD as "everything you have ever dreamed of in a mathematical toolbox."

And for Macintosh® users, we present MathCAD 2.0, rewritten to take full advantage of the Macintosh interface. Entering operators and Greek letters into equations is pure simplicity!

Look for MathCAD 2.5 at your local software dealer, or give us a call. For more information, a free demo disk, or upgrade information,* dial 1-800-MATHCAD (in MA, 617-577-1017).

**If you purchased MathCAD 2.0 between 5/1/89 and 6/16/89, you can get a FREE upgrade to version 2.5 (otherwise, the upgrade cost is \$99.00 until June 30, 1989; afterwards, the cost will be \$149.00).*



March 14, 1989 issue.
Best of '88
Best of '87

MathCAD®

MathSoft, Inc. One Kendall Square, Cambridge, MA 02139

22

terial may not have any intrinsic absorption in the desired range of wavelengths.

Recently, quantum-well devices made of layers of $\text{Al}_x\text{Ga}_{1-x}\text{As}$ and GaAs have been demonstrated to detect radiation at wavelengths of 8 to 11 μm . The absorption of a photon in such a device corresponds to the transition of an electron between the ground and first excited state of a quantum well formed by the discontinuity in the energy of the conduction band between a GaAs well and an $\text{Al}_x\text{Ga}_{1-x}\text{As}$ barrier. The photoexcited charge carriers then tunnel out of the well and are collected with the aid of an applied electric field.

The proposed device is based on the splitting of the energy level that occurs when two quantum wells are placed so close together that the wave functions of the quantized energy levels overlap. The detector absorbs photons, the energy of

which equals the difference in energy between two levels that result from the split. Because the degree of overlap of the wave functions and, therefore, the magnitude of the split can be varied by varying the width of the barrier between the two coupled wells, such a detector can, in principle, be designed to operate at any desired wavelength.

Operation at wavelengths from 10 to 100 μm requires splits of 12 to 120 meV. A split of 25 meV (corresponding to a wavelength of 50 μm) could be obtained by use of GaAs wells 70 Å thick, with $\text{Al}_{0.06}\text{Ga}_{0.94}\text{As}$ barriers, including a 14-Å-thick barrier between the wells. This approach to design could be used in other combinations of materials that exhibit quantum size effects and is not restricted to the $\text{Al}_x\text{Ga}_{1-x}\text{As}$ system.

The restrictions on the design param-

eters of quantum wells of the proposed device are less severe than those of single-well devices. However, energy levels near the tops of the wells are still necessary so that the photoexcited carriers can tunnel out. Additional flexibility in design can be obtained by use of wells of different widths and asymmetric wells formed by barriers of different heights.

This work was done by Richard P. Vasquez of Caltech for **NASA's Jet Propulsion Laboratory**. For further information, Circle 19 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, NASA's Resident Office-JPL [see page 14]. Refer to NPO-17543

Thermal Analysis of Reluctant Glass Formers

A thermocouple holds a sample and monitors its temperature during cooling.

Marshall Space Flight Center, Alabama

An apparatus for the study of heterogeneous nucleation and crystallization in reluctant glass formers achieves cooling rates from 10 to 2,500 $^{\circ}\text{C/s}$ by providing control of both radiative and conductive cooling. Reluctant glass formers are materials that require cooling rates greater than 10 $^{\circ}\text{C/s}$ to form glasses. Laser spin melting, a prior technique, can be used only at cooling rates greater than about 1,000 $^{\circ}\text{C/s}$ and only for very small samples. The new apparatus can be used to examine the glass-formation ability of a material and the critical cooling rate to form a glass from it.

The apparatus (see Figure 1) includes an ellipsoidal furnace, which focuses radiation from a tungsten/halogen lamp onto a sample. The sample is supported between the two leads of a type S thermocouple that has a junction bead 0.005 in. (0.13 mm) in diameter. Raising the power to the lamp melts the sample, causing it to flow around the thermocouple bead. A specimen in a still atmosphere can be cooled at rates from 10 to 250 $^{\circ}\text{C/s}$ by reducing the lamp power at the appropriate rate with a variable-speed, motor-driven, adjustable transformer. Higher cooling rates are obtained by blowing helium gas onto the sample after turning the lamp off.

The temperature of the sample is derived from the thermocouple signal. During quenching, the temperature of the sample is recorded on a strip chart and/or in a microcomputer data-acquisition system. The recorded quenching curve (see Figure 2) is analyzed to determine the temperature of the sample prior to quenching; the rate of cooling prior to nucleation; the time and temperature of nucleation; the rate, time,




Figure 1. The **Ellipsoidal Furnace** provides controlled cooling rates for studies of the thermal properties of reluctant glass formers. A glass tube (not shown) is inserted into the furnace and used to blow helium on the specimen to cool it rapidly.

and temperature of recalescence; and the rate of cooling after nucleation.

Quenched samples are inspected for

crystallization. If the quenched sample is transparent and the quench curve shows no recalescence peak, it is assumed that

MATH ADVANTAGE[®]

FORTRAN VERSION

TOOLSMITH SERIES[®]



FUEL EFFICIENT.

Get maximum compute-engine performance for every application, with Math Advantage[®] from QTC.

Math Advantage is the de facto standard for math libraries in high-speed computing environments. It's developed and optimized by QTC's team of mathematicians, applications engineers, and supercomputer experts. It features over 260 frequently used but hard-to-program subroutines. And it runs on over 40 systems ranging from Cray X-MP

to IBM PC, Cyber to VAX, Sun to Mac.

Best of all, Math Advantage gives you FORTRAN, C, and Ada versions of algorithms like FFTs, eigensolvers, matrix operations, and BLAS, all completely *ready-to-run*. So it helps you optimize the most valuable resource of all—your time.

Because it's from QTC, the experts in high-performance development

tools, Math Advantage also comes with unmatched documentation, support, and technical excellence.

See for yourself—over 10,000 Math Advantage users already have. Contact QTC at 1-800-234-0168, or


Telex 910 240 2827 for more information.




QTC
Quantitative
Technology
Corporation

DADiSP...

Serious Signal Analysis
The Way You Always
Pictured It!



Make Waves...



make Sense...

the First Spreadsheet
designed exclusively for
Scientists and Engineers.

Over 150 functions for displaying
and analyzing waveforms makes
sophisticated signal processing as
easy as typing a name. Run external
data acquisition software, or
your own analysis programs;
create new functions with DADiSP
Macros; and, talk to your in-
struments with DADiSP-488.

make a Call.

(617) 577-1133

Mention this magazine, receive
evaluation FREE. A \$20 value.
Order our \$20 Interactive Demo Disk.
Ask about DADiSP for IBM-PC/XT/AT,
DEC MicroVAX, HP9000, Masscomp
5000, and Sun Workstations. For further
information write DSP Development
Corporation, One Kendall Square,
Cambridge, MA 02139, (617) 577-1133





Figure 2. A **Cooling Curve** (above) can be analyzed to determine the rate of cooling and such properties of the sample as nucleation and recalescence temperatures at that cooling rate. Continuous-cooling-crystallization boundaries can be determined empirically from plots of nucleation time vs. nucleation temperature from runs at a large number of different rates of cooling.

glass has been formed. Whenever a recalescence peak is observed, the sample is opaque and predominately crystalline due to the rapid rate of crystal growth.

Nucleation times and temperatures for a large number of different quenches can be plotted to produce empirical continuous-cooling-crystallization diagrams. The nucleation of crystallization from each

quench run that did not result in the formation of glass is represented by a datum on the plot.


This work was done by Edwin C. Ethridge and Peter A. Curreri of **Marshall Space Flight Center**. For further information, Circle 50 on the TSP Request Card. MFS-28283

ULTRAPAC

Ultrasonics by Physical Acoustics


FOR ALL YOUR ULTRASONIC INSPECTION NEEDS

Physical Acoustics Corporation is pleased to introduce a truly affordable PC based ultrasonic system. The UltraPAC system has the right price performance for production level C-Scan and Transducer Evaluation as well as the enhanced software options for sophisticated ultrasonics analysis. Users have the opportunity to select from a wide range of TestPRO* software modules to meet their application requirements.




C-Scan

UltraPAC offers the functionality of systems many times its price. The system provides real time color imaging, scan storage and simple menu driven set-up.



Transducer Evaluation

Compute a frequency spectrum or signal features for any transducer. Record the results in a report or store to disk for future evaluations.



Optional Software

The TestPRO* software offers an extensive library of modules for your analysis needs. Choose from Flaw Classification, Plotting, Feature Extraction or Artificial Intelligence enhancements.



UltraPAC is a versatile, multi-functional immersion system comprised of innovative mechanics, electronics and software. This unique system offers more features as standard than any other — all for one low price. Of course, its modular design allows for cost effective expansion.

Whether you are looking to upgrade existing equipment or planning to buy a total ultrasonic system, UltraPAC can be configured to meet your NDT needs.

*TestPRO is the registered trademark of Infometrics, Inc.



HQTS: PO Box 3135, Princeton, NJ 08543 • (609) 896-2255 • Telex 67-17731 • FAX (609) 895-9726;
 Dunegan-PAC Ltd. Norman Way, Over, Cambridge, CB45QE, UK • (44) 954-31612 • Telex (851) 81386 •
 FAX (44) 954-31102; EuroPhysical Acoustics S.A. 74, rue des Grands Champs 75020, Paris, France • (33)
 (14) 356-2210 • Telex (842) 220754; Nippon Physical Acoustics 8F, Okamoto L.K. Bldg. 2-17-10, Higashi,
 Shibuya-Ku, Tokyo 150, Japan • (81) (3) 498-3570 • Telex (781) 33656 • FAX (81) (3) 498-8450

The Integrated NDT People

Circle Reader Action No. 425

Dynamic-Range Compression for Infrared Imagery

Photorefractive crystals covering detectors would prevent saturation.

NASA's Jet Propulsion Laboratory,
Pasadena, California

The results of experiments suggest that photorefractive crystals can be used to reduce the dynamic range of infrared radiation incident upon a photodetector or array of photodetectors. Such predetection range compression can be useful in infrared-imaging systems because typical scenes contain bright spots (e.g., solar radiation reflected from automobiles) on dark backgrounds, and the bright/dark contrast exceeds the dynamic ranges of photodetectors, causing their output signals to saturate. When fully developed, an effective dynamic-range-compressor plate, film, or coating would reduce the apparent contrast of the scene imaged on the detector plane to within the dynamic range of the detectors (see Figure 1); the original image contrast or intensity data could be recovered subsequently in electronic image processing because the range-compression function and its inverse would be known.

The proposed dynamic-range compressor would be made of photorefractive crystals. The two-wave-mixing process that occurs in such crystals attenuates the radiation passing through them. Because the process is nonlinear, the degree of attenuation is greater at higher intensities. Thus, a compressor plate would darken the bright spots more strongly than it would darken the other portions of an image.

One useful range-compression function is

$$I_{out} = A(I_{in})^X$$

where I_{out} and I_{in} are the input and output intensities, respectively, and A is a constant. For compression, X must be less than 1; as X decreases, the degree of compression increases. This function is approximated by the experimental data of Figure 2, in which the input dynamic range of about 365:1 is changed to output dynamic ranges of about 175:1, 160:1, and 90:1.

This work was done by Li-Jen Cheng and Hua-Kuang Liu of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 105 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, NASA Resident Office-JPL Laboratory [see page 14]. Refer to NPO-17140.




Figure 1. The Output of a Typical Photodetector saturates at low and high levels of input intensity. To make full use of the information in an image, it is desirable to compress the dynamic range of the input intensity to within the region of approximately linear response of the detector.




Figure 2. Dynamic-Range Compression is exhibited by measurements of attenuation in photorefractive GaAs.

Making Durable Specimens for Electron Microscopy

Consistent metal-oxide cross sections are prepared quickly.

Lewis Research Center, Cleveland, Ohio

High-quality specimens of metal-oxide cross sections transparent to electrons are necessary to perform some of the more sophisticated studies involving transmission electron microscopy (TEM) and scanning transmission electron microscopy (STEM). A major problem in the preparation of specimens is obtaining durable specimens in a simple and consistent fashion. A new technique can be used to prepare 3-mm-diameter specimens of cross sections of oxides of alloys intended for use at temperatures greater than approximately 600 °C (see figure).

The alloy of interest is cut into bars approximately 1.5 mm by 0.75 mm by 10 mm. Only one of the large faces of each bar need be prepared for oxidation treatments. The bars are oxidized at the appropriate experimental conditions. After the bars are cooled, a thin coat of silver paint is applied to the prepared surface of each bar. The painted surfaces are placed and held together until the paint dries. This provides

enough strength for handling of the specimen-bar sandwich.

The sandwich is then placed in a specially-designed stainless-steel mold and held in place with setscrew pins. The purpose of the mold is to hold the sandwich in place inside a 3-mm-diameter bore, into which a molten alloy is injected. After the sandwich is aligned in the mold, a chunk of Zn(4 atomic percent)/Al(1 atomic percent)/Cu alloy is placed in the riser portion of the mold. This alloy was chosen because of its low melting temperature (415 °C), sufficient strength, and high coefficient of thermal expansion.


The entire mold is heated quickly with an oxyacetylene torch until the alloy is molten. A glass tube connected to a rubber bulb is placed over the riser and in contact with the mold. A blast of air causes the molten alloy to flow around and encapsulate the specimen-bar sandwich. After removal from the mold, the resulting 3-mm specimen bar is sliced into TEM specimens by

use of a slow diamond saw. Finally, the specimens are polished, dimpled, and ion-thinned.

The primary advantage of this technique is that durable specimens can be prepared consistently in a very short time. In addition, epoxy resins are not used, and organic solvents can be used to clean the specimens. Yet another advantage is that two different experimental conditions can be incorporated into one specimen.

One of the disadvantages of this technique is that specimens of materials that would be affected by the high casting temperature are not suitable. Furthermore, during the ion-thinning process, the zinc alloy is often sputter-deposited on the area of interest, requiring subtraction of additional background signals from quantitative-chemical-analysis spectra.

This work was done by Joseph Doychak of Sverdrup Technology Inc. for Lewis Research Center. No further documentation is available. LEW-14755



The **New Process** makes TEM/STEM cross sections of metal/oxide interfaces. After the specimen bars have been oxidized, they are placed in the specially designed mold. Following encapsulation in the zinc alloy, the 3-mm-diameter specimen bar is sliced into disks suitable for further preparation steps.

Isothermal Equation of State for Compressed Solids

The same equation with three adjustable parameters applies to different materials.

Lewis Research Center, Cleveland, Ohio

An improved equation of state describes the pressure on a solid as a function of

relative volume at constant temperature. Even though the types of interatomic inter-

actions differ from one substance to another, the form of the equation is determined primarily by the overlap of electron wave functions during compression. Con-

sequently, the equation is universal in the sense that it applies to a variety of substances, including ionic, metallic, covalent, and rare-gas solids. Only three parameters are needed to describe the equation for a given material.

The equation gives the pressure, P , at a fixed temperature, T , as a function of the relative size, X

$P(X, T) = 3B_T[(1-X)/X^2] \exp[\eta_T(1-X)]$ where B_T = the isothermal bulk modulus at zero pressure, $X = (V/V_0)^{1/3}$, V = the volume at pressure P , and V_0 = the equilibrium volume (the volume at zero pressure). The parameter in the exponential term is given by


$$\eta_T = (3/2)[(\partial B/\partial P)_T - 1]$$

where B = the isothermal bulk modulus and the derivative is evaluated at zero pressure. These equations are valid over the range of pressure and volume that contains no phase changes.

To test the equation of state by comparison with experimental data, it is convenient to define a function H (not to be confused with the enthalpy, which H usually denotes in thermodynamic contexts)

$$H = \ln[PX^2/3(1-X)] \\ = \ln(B_T) + \eta_T(1-X)$$

The pressure equation predicts that plots of experimental isothermal values of H versus $1-X$ will be linear, with intercepts and slopes yielding $\ln(B_T)$ and η_T , respectively. The prediction is confirmed by close agreement with experimental data on a variety of solids at various temperatures (see figure), including hydrogen at 4.2 K, xenon at 150 K, cesium at 295 K, molybdenum at 293 K, sodium chloride at 298 K, and magnesium oxide at 293 K.



Experimental Plots of H Versus $1-X$ all lie on nearly straight lines, even though the data in the plots were taken from measurements of different materials at different temperatures.

This work was done by Pascal Vinet and John Ferrante of **Lewis Research Center**. Further information may be found in NASA TM-87303 [N86-28775/NSP], "Universality in the Compressive Behavior of Solids."

Copies may be purchased [prepayment

required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700. LEW-14615

Equation of State With Temperature Effects for Solids

Behavior at high temperature is predicted from only four parameters.

Lewis Research Center, Cleveland, Ohio

Equations have been derived to express the thermodynamical properties of compressed solids at high temperatures. The new equations are based on fundamental considerations of thermodynamics, the isothermal equation of state discussed in the preceding article, and the assumption that the thermal pressure is independent of volume and varies linearly with temperature near and about the Debye temperature. Using only four parameters (three of which are those of the isothermal equation of state), the new equations describe the thermodynamic behavior of a material over a range of temperatures from approximately its Debye temperature to its melting point.


The four parameters are measured at a reference temperature T_R near the Debye temperature. They are (1) the isothermal bulk modulus B_0 at zero pressure, (2) the

quantity $\eta_0 = (3/2)[(\partial B/\partial P)_{T_R} - 1]$ with the derivative evaluated at zero pressure, (3) the volume V_0 at zero pressure, and (4) the coefficient of thermal expansion α_0 at zero pressure. Then the pressure P , isothermal bulk modulus B , and isothermal derivative of bulk modulus with respect to pressure $\partial B/\partial P$ at relative size X are given by

$$P(T, X) = 3B_0[(1-X)/X^2] \exp[\eta_0(1-X) + \alpha_0 B_0(T - T_R)] \\ B(T, X) = (B_0/X^2)[2 + (\eta_0 - 1)X - \eta_0 X^2] \exp[\eta_0(1-X)], \text{ and}$$

$$\frac{\partial B}{\partial P}(T, X) = [4 + (3\eta_0 - 1)X + \eta_0(\eta_0 - 1)X^2 - \eta_0^2 X^3] / [3(2 + (\eta_0 - 1)X - \eta_0 X^2)]$$


where $X = (V/V_0)^{1/3}$. An equation for the temperature dependence of the coefficient of thermal expansion at zero pres-



The Coefficient of Thermal Expansion of Xenon relative to the size at the reference temperature T_R is closely approximated by values derived from the universal equation of state.



Molecu Wire: Your innovative source for specialty wire and ribbon



WHEN YOUR APPLICATION calls for "impossible" wire or ribbon, turn to Molecu Wire to insure your project's success.

No matter how tough your process or product parameters—and no matter whether your field is aerospace or data processing . . . medical devices or robotics . . . consumer electronics,

telecommunications, appliances or virtually anything else—Molecu's accomplished team of experts can help make your application a reality.

To guarantee the flawless wire or ribbon you need, Molecu's full-service capabilities include metallurgical and application R&D, product engineering, prototyping, complete in-house tool and diemaking, full-scale production with rigorous quality controls including SPC, and some of the most sophisticated testing available anywhere.

Established in 1958, Molecu is a recognized leader in custom precision wire and ribbon design, engineering and manufacturing. We work

with the world's foremost companies—from global giants to small, emerging firms—to pioneer tomorrow's products and technologies . . . today.

To learn more about how you can put Molecu's one-of-a-kind wire and ribbon technology to work for you, call us today at (201) 938-9473. Or write Molecu Wire, P. O. Box 495, Farmingdale, New Jersey 07727. Fax: (201) 938-3189.



sure can also be derived by setting $P(T, X) = 0$ and solving for $X(T)$.

These equations agreed well with experimental data on the pressures, volumes, and bulk moduli of gold, sodium chloride, and xenon at various temperatures. Even the nonlinear variation of the thermal expansion with temperature is well approximated by the values derived from the generalized equation of state (see figure):

previously, the thermal expansion had been difficult to predict over a wide range of temperatures.

This work was done by Pascal Vinet and John Ferrante of **Lewis Research Center**, John R. Smith of General Motors Corp., and James H. Rose of the Ames Laboratory of the United States Department of Energy. Further information may be found in NASA TM-87321 [N86-28776/NSP],

"Temperature Effects on the Universal Equation of State of Solids."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700. LEW-14616

Measuring Transmission Efficiencies of Mass Spectrometers

Coincidence counts would yield absolute efficiencies.


NASA's Jet Propulsion Laboratory, Pasadena, California

A proposed system would measure the mass-dependent transmission efficiencies of mass spectrometers, using coincidence-counting techniques reminiscent of those used for many years in the calibration of detectors for subatomic particles. When fully developed, the system should be compact, portable, and used routinely to calibrate mass spectrometers.

The conceptual system is connected to the inlet and to the output circuit of the mass spectrometer (see figure). A gas (e.g., H_2 , D_2 , He, Ne, N_2 , O_2 , Ar, or CO_2) is passed through an array of capillary tubes, then through a series of apertures to form a well-collimated, well-defined beam of molecules. This beam is crossed by a beam of electrons with kinetic energies greater than the ionization potential of the molecules and with an energy spread less than 300 mV. Some of the collisions between electrons and molecules produce singly ionized molecules that travel toward the entrance aperture of the mass spectrometer, and scattered electrons, the kinetic energies of which are diminished by the amounts lost in production of the ions.

The electrons scattered at some arbitrarily chosen angle θ are analyzed in energy and detected by a multichannel amplifying plate or other suitable charged-particle detector. Each detected electron gives rise to an electrical pulse that is shaped, amplified, and sent to a pulse counter: it is assumed that each pulse at a specified scattered-electron energy corresponds to an ion that has begun to travel toward the entrance of the mass spectrometer. The electron-detector output is also fed through a variable-delay unit to start a time-to-pulse-height converter.

Another charged-particle detector, another pulse shaper, and another amplifier form a pulse for each ion that arrives at the output end of the mass spectrometer. Each ion pulse serves as the stopping pulse for the time-to-pulse-height converter. Between the starting and stopping pulses, there is a time correlation for those detected ions that were produced by detected electrons. For other detected ions



Coincidences Between Detected Ions and the Electrons That Produced Them would be counted during the operation of a mass spectrometer. Under certain assumptions regarding the inelastic scattering of electrons, the electron/ion-coincidence count is a direct measure of the transmission efficiency of the spectrometer.

and electrons, there is no time correlation. Thus, the output of the time-to-pulse-height converter includes uncorrelated pulses spread over a wide range of time intervals, plus correlated pulses spread over a fixed time interval, as shown in the output of a pulse-height analyzer.

The transmission efficiency of the mass spectrometer is taken to be the ratio of the number of time-correlated pulses to the number of electron pulses. The measurement can be repeated for each of the various gases to obtain the transmission efficiency for the molecular mass of each.

This work was done by Santosh K. Srivastava of Caltech for NASA's Jet Pro-

pulsion Laboratory. For further information, Circle 10 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Edward Ansell
Director of Patents and Licensing
Mail Stop 301-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125

Refer to NPO-16989, volume and number of this NASA Tech Briefs issue, and the page number.


Automated Heat-Flux-Calibration Facility

Computer control speeds operation of the equipment and processing of measurements.

Lewis Research Center, Cleveland, Ohio

A new heat-flux-calibration facility has been developed at Lewis Research Center. This facility is used for fast-transient heat-transfer testing, durability testing, and calibration of heat-flux gauges. Calibrations can be performed at constant or transient heat fluxes ranging from 1 to 6 MW/m² and at temperatures ranging from 80 K to the melting temperatures of most materials. The facility was developed because there is a need to build and calibrate very-small heat-flux gauges for the Space Shuttle main engine (SSME). These heat-flux gauges are required for the measurement of the flux of heat to the surfaces of turbines in the turbopumps of the SSME.

The calibration facility includes a lamp head attached to the side of a service module, an argon-gas-recirculation module, a reflector, a heat exchanger, and a high-speed positioning system. The lamp head contains electric-arc-stabilization and de-ionized-water cooling systems. The stability of the arc, necessary for minimal fluctuation of the light (heat) source, is attained by giving the argon gas a high rotational velocity as the gas enters a quartz tube con-



A 100-kW Arc Lamp provides repeatable, controllable directional radiant heating of the surface of a heat-flux gauge.

taining the arc, gas, and water (see figure).


The water is pumped in a spiral fashion along the tube and flows between the plasma arc and the quartz tube. Also, the de-ionized water cools the reflector, removes

electrode debris from the inside surface of the tube, and cools the quartz tube. After the water has passed through the quartz tube, it is filtered within the service module and then cooled within the heat exchanger.

PERFORMANCE...

FAX: (213) 539-8325

REQUEST FOR QUOTE



**PRECISION MOLDING TO:
.0005". ZERO DEFECT**



**COST EFFECTIVE CLASS 'A'
MOLD CONSTRUCTION**

PERFORMANCE	PLASTICORP	Others
Custom Injection Molding	Yes	Yes
In House Class 'A' Mold Construction	Yes	Few
Insert Tooling Program	Yes	-
Mold Engineering Design	Yes	-
2 Color/2 Shot Molding	Yes	No
2 Material 2/Shot Molding	Yes	No
Performance Polymers +600°	Yes	Few
Including: LCP's, Fluorocarbon	Yes	Few
Automation: Insert Loading	Yes	No
Unscrewing	Yes	No
Tolerances exceed published	Yes	No
Shrinkage of polymer suppliers	Yes	No
Quality Control Standard	AQL Milspec	1.0 45208
Mold Life Guarantee	Yes	-
Mold Maintenance	Yes	-
Secondaries: Tampo	Yes	-
Hot Stamp	Yes	-
Ultra Sonic & Spin Welding	Yes	-
Tap, Punch & Drill	Yes	-
Package & Assemblies	Yes	-



PLASTICORP

24105 S. Frampton Ave.
Harbor City, CA 90710
(213) 539-9530 FAX: 213-539-8325

■ VECTRA
■ XYDAR
■ AMODEL

■ PEEK
■ ULTEM
■ NORYL

■ VICTREX
■ VALOX
■ DELRIN


■ NYLON
■ LEXAN
■ CYCOLAC

■ RYNITE
■ RYTON
■ CELANEX

Customized For Cryogenics

DT-470 Series Temperature Sensors (1.4K to 475K)

Lake Shore's DT-470 hermetic package incorporates a sapphire substrate for high electrical isolation and excellent thermal conductivity. Robust Kovar™ leads are thermally anchored to the substrate. This proprietary package minimizes measurement errors commonly encountered at low temperatures. So you get a sensor ideally suited for cryogenics.



Look to
Lake Shore
High
performance
in low
temperature
technology

LakeShore

CRYOTRONICS, INC.

64 East Walnut Street, Westerville, Ohio 43081 USA (614) 891-2243
Telex: 24-5415 Cryotron WTVL Fax: (614) 891-1392
© 1989 Lake Shore Cryotronics, Inc.

Circle Reader Action No. 579

Heathkit®

A leader in quality electronics for the technically sophisticated customer.

When you need kit or assembled electronic products for work, home or hobby, you can be sure Heathkit products are designed to perform reliably and effectively...year after year.

See what we have to offer. To get your **FREE Heathkit Catalog**, fill out and mail the coupon below or call toll-free today!

1-800-44-HEATH
(1-800-444-3284)

YES! Please send me a **FREE** copy of the Heathkit Catalog.

Send To: Heath Company, Dept. 047-784
Benton Harbor, Michigan 49022

Name _____

Address _____ Apt. _____

City _____


State _____ Zip _____

A subsidiary of Zenith Electronics Corporation CL-801




Powerful Kit
Laptop and
Desktop
Computers

Precision
Test
Instruments



Dynamic
Home Entertainment
Products



Skill-Enhancing
Educational
Courses
and Trainers

A positioning arm attached to the high-speed positioning system is used to position carefully the heat-flux gauge in the focus of the reflector; the positioning system also rapidly removes the gauge from the focal position after sufficient heating. Microcomputers built into the arc lamp and positioning system are controlled by a minicomputer stationed in a nearby control room. Before and after heating by the electric arc, the gauge is cooled by programming the minicomputer to position the gauge in a Dewar filled with liquid nitrogen.

Thermocouples attached to the bodies of heat-flux gauges produce voltages that are converted to temperature data and then stored in the minicomputer. The heat flux is calculated with computer codes that use measured gauge-body temperatures as input. This type of automated heat-flux-calibration facility can be installed in industrial plants for onsite calibration of heat-flux gauges that measure fluxes of heat in advanced gas-turbine and rocket engines.

This work was done by Curt H. Liebert and Donald H. Weikle of **Lewis Research Center**. No further documentation is available.

LEW-14724

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Accuracy of Hot-Wire Anemometry In Supersonic Turbulence

The sensitivity of a hot-wire probe is compared to laser-induced-fluorescence measurements.

A report discusses the factors that affect the readings of a hot-wire anemometer in a turbulent supersonic boundary layer. The report presents a theoretical analysis of the responses of a hot-wire probe to changes in the flow; it also compares measurements by a hot-wire probe with measurements of the same flows by laser-induced fluorescence (LIF). Because LIF provides spatially and temporally resolved data on temperature, density, and pressure, it provides independent means to determine the responses of hot-wire anemometers to these quantities.

The usual objective of hot-wire anemometry is to measure the fluctuations in the mass flux, which is a product of flow speed and density. However, a hot wire does not respond to mass flux alone but to a combination of mass flux and total temperature, the total temperature being the

temperature of a stagnation point in the flow. While comparisons of hot-wire anemometry with laser doppler velocimetry can provide partial speed calibrations, they provide no information on responses to fluctuations in density and temperature.

The basic equation of hot-wire anemometry is a linearized expression for the fluctuation in the voltage across a hot wire immersed in a flow:

$$(\Delta E/E) = S_\rho(\Delta \rho/\rho) + S_U(\Delta U/U) + S_T(\Delta T/T)$$

where E = the voltage, ρ = the density, U = the speed, T = the total temperature, S = the sensitivity to the subscripted quantity, and Δ denotes the fluctuation in the associated quantity. For mach numbers above 1.2 and Reynolds numbers above 20 (based on wire diameter)

$$S_\rho \approx S_u = S_m$$

where $m = \rho U$ = mass flux. The theoretical analysis explores the mathematical consequences of these equations under various assumed flow conditions to derive equations for three different calibration methods.

The first two methods are based on the concept of "single high overheat": the wire is operated at such a high temperature that it is sensitive only to mass flux and not to fluctuations of temperature in the flow. In the first method (the centerline method), measurements are made at the center line of a wind tunnel, where the flow is relatively free of disturbances. The stagnation pressure, and consequently the mass flux (but not the mach number), is varied from run to run. The second method (the boundary-layer method), which is less vulnerable to certain calibration errors, involves measurements of the boundary-layer flow with mass flow estimated from pitot-static measurements by the standard equations of compressible flow. The third method is more complicated: through measurements at various wire temperatures (multiple overheats) and statistical analysis, it provides for the determination of both S_m and S_T .

The three methods were applied to a mach 2.1 flow of nitrogen in a blowdown wind tunnel and compared with LIF measurements. As a result, the following conclusions were drawn:

- The boundary-layer and centerline methods give the same measurements of mass flux. The boundary-layer method minimizes errors, but the centerline method may be easier and more reliable for the measurement of some complicated flows.
- A hot wire can be operated at a single high overheat or at multiple overheats to measure fluctuations in the mass flux.
- If a high overheat is used to measure only fluctuations in mass flux, then root-mean-square fluctuations of temperature and density cannot be determined accurately.
- If multiple-overheat measurements are taken of the mass flux, the total tempera-

ture, and the correlation between them, and if there are no unsteady shocks or other sources of pressure fluctuations, then the root-mean-square fluctuations of temperature and density can be determined accurately.

This work was done by Pamela Logan, Robert L. McKenzie, and Daniel Bershader of Ames Research Center. To obtain a copy of the report, "Comparisons of Hot-Wire and Laser-Induced Fluorescence Measurements Obtained in Supersonic Turbulence," Circle 112 on the TSP Request Card.


Inquiries concerning rights for the commercial use of this invention should be ad-

dressed to the Patent Counsel, Ames Research Center [see page 14]. Refer to ARC-11802.

Computing Geopotential Perturbations

An improved formulation reduces error and the number of computational steps.

A report describes a method for calculating the partial derivative of the geopotential perturbation with respect to time. This partial derivative is useful in computations



RADIOGRAPHY

Radiography is just one of the many applications possible with KeveX X-RAY's patented portable X-ray source, the PXS.

The PXS can create new market opportunities for your products. The design eliminates the bulk associated with conventional X-ray systems allowing your products to be portable, lightweight and compact.

Some new products to date include:

- A portable real-time imaging system for detection of tampered products in the field
- A radically different altimeter for the next generation of aircraft
- An on-line thickness gauge used in 100°C environments
- A compact X-ray fluorescence system
- A tabletop double crystal diffractometer
- An airborne meteorological device for measuring particle distribution

All possible because of the self-contained compact X-ray energy source, the PXS.

KeveX X-RAY integrated a miniature X-ray tube and a high voltage power supply into one compact, 5 lb. package. Operational from a 12 volt DC battery, this highly regulated, highly stable source has all the high voltage components molded internally. As a result there are no high voltage cables or connectors to work around.

Designed, manufactured, and sold only by KeveX X-RAY. Call or write KeveX X-RAY today for information on our complete line of portable sources including the 10 micron focal spot PXS.

keveX X-RAY

P.O. Box 66860
Scotts Valley, CA 95066 408-438-5940

◆ A VG Instruments Group Company

of the orbit of a lightweight satellite in which the total orbital energy or a related parameter is one of the dependent variables.

In a total-orbital-energy formulation, the differential equation for the trajectory of the satellite is obtained by taking the total derivative, with respect to time, of the total orbital energy, h :

$$h = \frac{1}{2} \mathbf{r} \cdot \mathbf{P} + \frac{\partial V(\mathbf{r}, t)}{\partial t}$$

where \mathbf{r} is the instantaneous position vector from the center of the Earth to the satellite in an inertial reference frame, $\mathbf{r} = |\mathbf{r}|$, \mathbf{P} represents the perturbation forces derivable from the geopotential, $V(\mathbf{r}, t)$ is the non-spherically-symmetrical perturbation in the geopotential, and t = time. The total derivative of the perturbation with respect to time experienced by the satellite is given by

$$\frac{dV}{dt} = \mathbf{r} \cdot \frac{\partial \mathbf{V}}{\partial \mathbf{r}} + \frac{\partial V}{\partial t}$$

where $\frac{\partial V}{\partial \mathbf{r}}$ represents the gradient operator usually denoted as ∇ .

In a system of coordinates that rotates with the Earth or other geopotential source at a suitable angular velocity ω , the perturbation can be expressed as a function of position \mathbf{r}_G only. With the help of this geocentric coordinate system, and taking $\mathbf{r} = \mathbf{r}_G$ instantaneously, the total derivative with respect to time experienced by the satellite and the partial derivative with respect to time in the inertial coordinate system are given by

$$\frac{dV}{dt} = \frac{\partial V}{\partial \mathbf{r}_G} \cdot (\mathbf{r}_G + \omega \times \mathbf{r}_G) + \frac{\partial V}{\partial t} \text{ and}$$

$$\frac{\partial V}{\partial t} = - \frac{\partial V}{\partial \mathbf{r}_G} \cdot (\omega \times \mathbf{r}_G), \text{ respectively}$$

The perturbation is then decomposed into a zonal component V_Z that depends only on the radius and colatitude in the rotating coordinate system and into a component V_T that includes the sectorial and tesseral terms of the potential (terms that depend on the longitude or on longitude and colatitude in the rotating coordinate system). Because $\frac{\partial V_Z}{\partial \mathbf{r}_G}$ contains only terms perpendicular to $\omega \times \mathbf{r}_G$, it does not contribute to the scalar product, and consequently

$$\frac{\partial V}{\partial t} = - \frac{\partial V_T}{\partial \mathbf{r}_G} \cdot (\omega \times \mathbf{r}_G)$$

Two options are considered within this general formulation. While both are correct, they differ in the speed and accuracy with which the trajectory can be computed. In option A, all of the zonal, sectorial, and tesseral terms are included in the potential and, thereby, in the total energy: this makes $\mathbf{P} = \mathbf{0}$ and results in

$$h_A = \frac{\partial V}{\partial t} = - \frac{\partial V_T}{\partial \mathbf{r}} \cdot (\omega \times \mathbf{r}_G)$$


In option B, only the zonal terms are included in the geopotential and, thereby, in the total energy: this makes $\frac{\partial V}{\partial t} = 0$ and places the sectorial and tesseral terms in \mathbf{P} , resulting in $h_B = \mathbf{r} \cdot \mathbf{P} = - \frac{\partial V_T}{\partial \mathbf{r}} \cdot \mathbf{r}$.

For a satellite orbit near the Earth, the magnitude of the velocity $\omega \times \mathbf{r}_G$ that arises from the rotation of the geocentric coordinate system is much less than the magnitude of the inertial velocity \mathbf{r} . Thus $|\dot{h}_A| < |\dot{h}_B|$, and in practice $\dot{h}_A/\dot{h}_B < 1/16$. Because the total-orbital-energy formulation involves equations of perturbed harmonic oscillators, the frequencies of which depend on the total orbital energy, the smaller perturbation of option A results in oscillator frequencies that are more nearly constant.

Options A and B were compared by using them to propagate a nearly circular orbit for 10 days. Option B required an average of 59.4 variable steps per revolution, with a maximum error of 25 m. Option A required an average of 45.2 variable steps per revolution, with a maximum error of about 8 m. When both were implemented with 30 fixed steps per revolution, option B showed a rapidly growing error that reached 25 m after 4 days, while option A reached a maximum error of about 15 m after 10 days.

This work was done by Victor R. Bond and David D. Mulcihy of McDonnell Douglas Corp. for Johnson Space Center. To obtain a copy of the report, "Computation of the Partial Derivative of a Potential Function With Respect to Time," Circle 73 on the TSP Request Card. MSC-21281

Red hot value



NEW Programmable control now standard

Exceptional performance, Lindberg/Blue M dependability and attractive prices make these 1100°C furnaces the preferred choice of laboratories everywhere.

- Four-segment programmable control
- Precise self-tuning control
- Four chamber sizes available
- Fast heat-up and recovery
- Energy efficient Moldatherm® insulation

For more information, contact your local laboratory distributor or Lindberg/Blue M, 304 Hart Street, Watertown, WI 53094. Phone 414-261-7000 • FAX 414-261-0925

9L33

LINDBERG/BUE M
A UNIT OF GENERAL SIGNAL

"NASA Tech Briefs generates high-caliber ad leads."

"As a manufacturer of automatic test equipment, Artisan has a wide and varied customer base. Limiting our advertising to test and instrumentation magazines proved too narrow an exposure and left a vast group of potential customers untapped. Through NASA Tech Briefs we were able to reach many qualified users of our products who were not available through other publications. We'll continue to use this proven method for creating new sales."



Michael Ryba
President/CEO,
Artisan Development
Corp.

Put The Power Of NASA Tech Briefs To Work For You.

Call (212) 490-3999 today for a complete marketing kit, or clip your business card to this ad and mail to:

NASATechBriefs

41 East 42nd St.,
Suite 921, New York, NY 10017

THE TACONIC

Option: Zero Compromise



Specify Confidence



Get top reliability in microwave-printed circuit boards, take the Taconic option. Our proprietary technology ensures superior electrical and mechanical performance. Plus 30 years' pioneering experience in PTFE/glass technology and development.

Specify Guaranteed Materials



Taconic meets almost any need with a unique range of high-performance microwave printed circuit board materials: From the TLY series of PTFE/woven glass products to pure PTFE products; from our XL series (up to 12 ft. long) to our new ultra-tough, radiation-resistant FEP line.

Specify Custom Service



Name your specs and Taconic has the cost-effective answer. We offer dielectric constants from 2.1 to 2.7, dielectric tolerances as close as ± 0.01 , and dissipation factors as low as .0003 at 10 GHz and above.

Specify Performance


Taconic products stand up to chemicals, vibration, radiation, and extreme heat cycling with no decline in performance and meet MIL P-13949G.

Don't compromise. Specify the Taconic option. Call or write for more information on our outstanding microwave substrates.

In New York: (518) 658-3202 Fax: (518) 658-3204
Export Department, P.O. Box 1896, New Haven, CT 06508
(203) 288-1638 Telex: 179160 Fax: (205) 287-8099

TACONIC MICROWAVE
DIELECTRIC
DIVISION
Taconic Plastics, Ltd., Petersburg, NY 12138
Call (800) 833-1805

Circle Reader Action No. 613



Materials

Hardware Techniques, and Processes

64 Glass Coats for Hot Isostatic Pressing

Books and Reports

66 Resistance to Delamination in Composite Materials

66 Unified System of Data on Materials and Processes

67 Effect of Solidification Speed on Fatigue Properties

Glass Coats for Hot Isostatic Pressing

Surface voids would be sealed from pressurizing gas.

Marshall Space Flight Center, Alabama


A proposed coating technique would enable the healing of surface defects by hot isostatic pressing (HIP). Internal pores are readily closed by HIP, but surface voids like cracks and pores that are in contact with the pressurizing gas are not healed. The proposed coat would be easy to apply, would separate the voids from the surrounding gas, would not react with the metal part under treatment, and would be easy to remove after pressing.

The coat would be applied to a casting or weldment as a thick slurry of two glass powders: one (component A), which melts at a temperature slightly lower than that used for HIP, and another (component B), which melts at a higher temperature. For example, powder A could be a glass of 75 percent SiO_2 and 25 percent Na_2O , while the other powder could be SiO_2 (see figure). The liquid component of the slurry could be a fugitive organic binder; for example, a mixture of cellulose acetate and acetone.

Most casting defects at surfaces occur in "hotspots" — areas where heat is not conducted away fast enough during solidification. Such areas are often inaccessible. The slurry should readily flow to them, however, after being brushed on a casting. The user does not have to worry about applying too much slurry — it should come off easily after HIP.

In the case of the $\text{Na}_2\text{O}/\text{SiO}_2$ material mentioned above, as the temperature is raised to about 825 °C during hot isostatic pressing, the lower-melting glass should first melt; but then the glasses should react, and the melting point should rise so that the glass mixture should harden. With the proper choice of the relative amounts of each glass, the mixture should form a coat stiff enough to protect against the gas pressures of 15,000 lb/in.² (100 MPa) typically used in HIP.

When pressing is complete, the casting would be cooled to room temperature. The glass coat should shrink faster than the casting would. Therefore, the coat should spall from the casting, leaving no detect-



The Phase Diagram of Na_2O and SiO_2 indicates that a glass that has a melting temperature between ~780 and 1,723 °C can be made by mixing various proportions of 75-percent SiO_2 /25-percent Na_2O glass with pure SiO_2 . The numbers on the horizontal axis denote weight percentages of SiO_2 .


able effects on it.

This work was done by Gunes M. Ecer of Rockwell International Corp. for Marshall

Space Flight Center. For further information, Circle 115 on the TSP Request Card. MFS-29501

**ANOTHER ASTRO-MED FIRST
IN 8-CHANNEL RECORDERS**

LASER PRINTER RESOLUTION!



- Laser Quality Writing—300 dpi
- 20 kHz Frequency Response
- Automatic Self-Calibration—Traceable to NBS
- Expandable to 16 Channels
- Data Capture with 200 kHz Sample Rate Per Channel
- Built-In Programmable Signal Conditioners

From its laser-sharp charts to its unparalleled frequency response, this remarkable new 8-channel recorder brings you the technology of the Twenty-First Century today! It outperforms even Astro-Med's MT-9500, which in 1987 was heralded as the first breakthrough in 8-channel recorders in 20 years. It has 50% more reso-

lution, 4 times higher frequency response, and 8 times more memory than the MT-9500. With automatic self-calibration traceable to NBS, expandability to 16 channels, and a host of other important features. We call it the MT-95000, a product so unique that it is protected by U.S. Patent No. 4,739,344.

Phone, Fax or Write for details!



Astro-Med, Inc.

Astro-Med Industrial Park, West Warwick Rhode Island 02893
Telephone (401) 828-4000 • Toll Free 800-343-4039
Telex No. 710-382-6409 • Fax (401) 822-2430

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Resistance to Delamination in Composite Materials

A fracture-mechanics approach is applied to delamination failures.

Delamination is the most-commonly-observed mode of failure in composite-material dynamic components of rotorcraft. Potential delamination sites in composite structures exist at discontinuities in load paths; for example, at straight edges, bonded joints, and bolted joints. These discontinuities give rise to interlaminar stresses even when the remote loading is in the plane of the laminations. Clearly, it would be useful to be able to model delamination mathematically and predict its onset for a given loading condition at a specified discontinuity.

A report presents a fracture-mechanics approach to analyzing, characterizing, and designing against delamination. In the study, examples of delamination problems

are illustrated wherein the strain-energy-release rate associated with the growth of delamination has been found to be a useful generic parameter, independent of thickness, layup, and source of delamination, for the characterization of failure by delamination. Several techniques for the calculation of strain-energy-release rates for delaminations from a variety of sources are outlined. A technique for the quantification of durability due to cyclic loading is presented.

One example of this approach is the analysis of edge delamination. In this case, the strain-energy-release rate is related through an equation to the remotely applied strain, the thickness of the laminate, and the modulus of the laminate with and without the delamination. The strain-energy-release rate is independent of the size of the delamination and the orientation of the layup. A critical strain for delamination is identified, and this is used to calculate a critical strain-energy-release rate, which is then used to calculate the remotely applied strains required to propagate a delamination for a number of different fiber orientations. These predictions, for the case of edge delamination, closely approximate experimentally-determined strain values.

To model delaminations involving mixed-mode fracture, a finite-element approach is used to calculate the three components

of the strain-energy-release rate: G_I (interlaminar tension), G_{II} (interlaminar sliding shear), and G_{III} (interlaminar scissoring shear). The total G is then determined by summing these components. This technique can be applied to different geometries, calculating the strain-energy-release rate components for several different sources of delamination.

This work was done by T. Kevin O'Brien of Langley Research Center. To obtain a copy of the report, "Delamination Durability of Composite Materials for Rotorcraft," Circle 154 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Langley Research Center [see page 14]. Refer to LAR-13753.

Unified System of Data on Materials and Processes

Wide-ranging sets of data for aerospace industry are described.

A document describes the Materials and Processes Technical Information System (MAPTIS), a computerized set of integrated data bases for use by NASA and the



the right environment
for cost-effective composite curing

Blue M's Ultra-Temp® Oven line has a programmable temperature range of +15 C above ambient to +704 C. Work load capacities from 4.1 to 24 cubic feet. Plus the right combination of control capabilities to meet your most demanding composite curing needs. If you're looking for the system that delivers a greater return on investment, check out the Ultra-Temp. You won't find a better buy, anywhere. For more information write, call or FAX: Blue M, A Unit of General Signal, Blue Island, Illinois 60406. Phone 312-385-9000 • FAX 312-331-2515.



689



The Dream Is Alive

Colorful T-Shirt For All Ages

Celebrate America's return to space with this official T-shirt from the movie "The Dream Is Alive™." Gorgeous full-color graphics against a white background. Machine-washable cotton and polyester. Only \$11.50 each! Order yours today using this convenient coupon.

Enclosed is \$_____ (Add \$2.50 for shipping and handling. NY residents add sales tax.)

Rush me _____ T-shirt(s) in the following sizes(s):

Adult: _____ S _____ M _____ L _____ XL

Children: _____ XS _____ S _____ M _____ L

Name _____

Address _____

City _____ State _____ Zip _____

Clip and mail with payment to:
NASA Tech Briefs, Fulfillment Dept.
41 East 42nd Street, New York, NY 10017

aerospace industry. MAPTIS stores information in a standard format for fast retrieval in searches and surveys of data. It helps engineers select materials and verify their properties. It promotes standardized nomenclature as well as standardized tests and presentation of data.

MAPTIS contains the following sets of data, among others:

- Nonmetallic materials — specifications, manufacturers, trade names, flammability, toxicity, and compatibility with hydrazine, hydraulic fluid, oxygen, and hydrogen.
- Metals — alloys, heat treatments, corrosion, stress corrosion cracking; and compatibility with oxygen, nitrogen tetroxide, hydrazine, hydrogen, and hydraulic oil.
- Atomic oxygen — effects on materials, guidelines for selection, and protective techniques.
- Thermal vacuum stability — data on outgassing, gathered from a variety of agencies.
- Verification and control of materials — information on where materials are used, ready reference for foreign alloys, and records of agreements on the uses of materials.
- Properties of materials, including mechanical, electrical, chemical, and thermal properties — particularly those related to processing, safety, and endurance in use.
- Lubricants — lubricity, viscosity, tempera-

ture range, formulation, flashpoint, chemical properties, processing, and thermal properties.

- Specifications and standards.

The format of the document is that of photographic projection slides used in lectures. The document presents examples of reports from the various data bases.

This work was done by Carlo F. Key of EER Systems for Marshall Space Flight Center. To obtain a copy of the report, "Materials and Processes Information System," Circle 88 on the TSP Request Card. MFS-27212

Effect of Solidification Speed on Fatigue Properties

Fast solidification increases fatigue life, but the failure distribution becomes less predictable.

A report describes the effects of the rate of solidification on the nickel-based superalloy MAR-M246(Hf) used in turbine blades. The report is based on experiments in which specimens were directionally solidified at 5 cm/h and 30 cm/h, then tested for high cycle fatigue. The specimens were also inspected by energy-dispersive x-ray (EDX) analysis and optical and electron mi-

croscopy.

The specimens solidified at the higher speed had higher volume fractions of carbide and interdendritic eutectic and lower volume fractions of the γ' phase. Correlated with these characteristics was the fatigue life — twice as high in the rapidly solidified specimens as in those solidified slowly.

However, the rapidly solidified specimens failed more randomly. These specimens exhibited more early failures than did the slowly solidified specimens, which followed a normal wearout pattern. The lesser predictability of failure in the rapidly solidified specimens can be related to the greater carbide and eutectic contents. Although heat treatment can diminish the segregation to some extent, it is still greater than in the specimens solidified more slowly.

This work was done by M. H. McCay, D. D. Schmidt, W. D. Hamilton, W. S. Alter, and R. A. Parr of Marshall Space Flight Center. To obtain a copy of the report, "The Influence of Growth Rate on Fatigue Properties in a Directionally Solidified Superalloy," Circle 26 on the TSP Request Cards.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center [see page 14]. Refer to MFS-27215


EXCELLENCE BY DESIGN WORLD'S SHORTEST LINEAR STAGE

DIMENSIONS

Length 5 1/4"
Width 5 5/8"

When space is at a premium, Anoride™ Model-5 tables with Anoline™ linear dc motor drives provide the most compact table available anywhere. By eliminating the need for a rotary motor extending beyond the table's base, the length of the assembly is dramatically reduced.

The Anoline linear motor drive offers stiffness and responsiveness far in excess of other drives. Anorad's linear, high-reliability, solid state encoder provides resolution from 100 microinches to 1 microinch. To assure the highest accuracy, both the encoder and motor are mounted



in-line with the centerline of travel.

The Model-5 table is available with travels from 1 inch to 5 inches, and can be readily mounted in an XY configuration. When performance counts, the Model-5 provides accuracy, response and compact size with a design suitable for continuous duty in the most demanding applications.

Call or write for a free brochure and pricing, or call our Application Engineers.

ANORAD CORPORATION

110 Oser Avenue

Hauppauge, NY 11788

Tel: 516-231-1995

FAX: 516-435-1612

TWX: 510-227-9894





OUTER SPACE ADVENTURE

Experience the thunderous power of Space Shuttle launches, bouncing moon walks, and weightless space ballet — all in the action-packed VHS videotape **SPACE SCAPES**, featuring rare footage gleaned from NASA's film archives. This visual treat is set to the award-winning music of Jan Hammer. (Color, 30 minutes) Only \$19.95 each plus \$3.00 postage and handling.

Name _____
Address _____
City _____
State _____ Zip _____
Total Enclosed: \$ _____
for _____ (quantity) Space
Scapes videotapes.

Send check or money order to:

NASA Tech Briefs, Dept. F
41 East 42nd St.
New York, NY 10017



Computer Programs

68 Computer-Aided Engineering of Labeling
70 Designing Corrector Optics
70 Data-Dictionary-Editing Program
70 AutoCAD-To-NASTRAN Translator Program

COSMIC: Transferring NASA Software

COSMIC, NASA's Computer Software Management and Information Center, distributes software developed with NASA funding to industry, other government agencies and academia.

COSMIC's inventory is updated regularly; new programs are reported in *Tech Briefs*. For additional information on any of the programs described here, circle the appropriate TSP number.

If you don't find a program in this issue that meets your needs, call COSMIC directly for a free

review of programs in your area of interest. You can also purchase the 1988 *COSMIC Software Catalog*, containing descriptions and ordering information for available software.

COSMIC is part of NASA's Technology Utilization Network.

COSMIC* — John A. Gibson, Director, (404) 542-3265
The University of Georgia, 382 East Broad Street, Athens, Georgia 30602

Computer Programs

These programs may be obtained at a very reasonable cost from COSMIC, a facility sponsored by NASA to make computer programs available to the public. For information on program price, size, and availability, circle the reference number on the TSP and COSMIC Request Card in this issue.



Electronic Components and Circuits

Computer-Aided Engineering of Cabling

This program generates data sheets, drawings, and other information on electrical connections.

DFACS is an interactive multiuser computer-aided-engineering tool for system-level electrical integration and cabling engineering. The purpose of the program is to provide the engineering community with a centralized data base for putting in, and gaining access to, the functional definition of a system as specified in terms of details of the pin connections of the end circuits of subsystems and instruments and data on harnessing. The primary objective is to provide an instantaneous single point of interchange of information, thus avoiding error-prone, time-consuming, and costly shuttling of data along multiple paths.

The DFACS program, which is centered around a single data base, has built-in menus that provide easy input of, and access to, data for all personnel involved in the system, subsystem, and cabling. The DFACS program enables the parallel design of circuit-data sheets and drawings of harnesses. It also recombines raw information to generate automatically various project documents and drawings, including the index of circuit-data sheets, the list of electrical-interface circuits, lists of assemblies and equipment, cabling trees, and drawings of cabling electrical interfaces and harnesses.

Real-time automatic production of harness drawings and circuit-data sheets from the same reservoir of data ensures instant harmony in the engineering design of the system and cabling. DFACS also contains automatic wire-routing procedures and extensive error-checking routines designed to minimize the possibility of engineering error.

The DFACS program was developed in 1987. It is designed to operate on a DEC


ALGOR FEA—Design and Stress Analysis \$889*

For 286 or 386 desktop computers

- **Finite Elements:** truss, beam, 2-D solid, 3-D solid, membrane, plate/shell, pipe, boundary, rigid link, non-linear gap, thin and thick shell/plate composites.
- **Stress Analysis:** point load, pressure, temperature, accelerations, centrifugal loads, deflections.
- **Dynamic Analysis:** mode shapes, frequencies, time stress history, response spectrum, direct integration, random vibration.
- **Heat Transfer Analysis:** 2-D/3-D conduction, convection, radiation, heat source, temperature, steady state and transient.
- **Graphics:** 3-D models; hidden line removal; light source shading animation; stress, displacement, temperature and flux contours w/optional shading; deformations; pan; zoom; node/element numbers; color.
- **Modeling:** 2-D/3-D mesh, cylinders, extrusions profile-path, warped surfaces; boundaries, loads, materials. SUPERDRAW II and parametric model generation.
- ***Full Capability, no size restrictions:** 3-D drawing, Computer Aided Design, solid modeling, design visualization, finite element stress analysis, and graphic post-processing.

GSA Contract #GS00K89AGS6270


Design the future with Algor.



Wire wheel model



Propeller hub/blades



Stress contour on clip



Temperature contour electronic part

Algor has the largest base of installed FEA software in the world!

TEL: (412) 967-2700 FAX: (412) 967-2781

ALGOR Quality Engineering Software Since 1977
ALGOR INTERACTIVE SYSTEMS, INC.
260 Alpha Drive, Pittsburgh, PA 15238

PASTRAN: THE COST EFFECTIVE ADA SOLUTION FOR REUSING YOUR PASCAL CODE

"I tried PasTran on some large public domain Pascal files and it worked great. I had to make a few changes to the Pascal and Ada because the program was in DEC Pascal, but it only took a few hours. Since I didn't know the program, I figured a straight translation would take about a week or two, if I tried it manually. That sold me!"

T. L. (Frank) Pappas, IEEE Computer

PasTran is an innovative tool for converting your existing Pascal code into Ada code. It has been field tested for over two years, with many different Pascal variants, and the response is overwhelmingly positive. PasTran is written and compiled in Janus/Ada, which recently was revalidated under ACVC 1.10, insuring the highest standards available in the Ada industry. PasTran offers the following capabilities:

- PasTran can convert up to 97% of your existing Pascal code into Ada code!
- Customized site licensing is available for PasTran, as well as single user licensing.
- Source code licensing is available for PasTran, allowing your company to customize to its needs.
- Customization of PasTran is available by our staff; contact our sales staff with your specific needs, so we can assist your company in making the most out of your existing Pascal code.
- PasTran increases the reusability of your existing Pascal code, allowing your company to increase its capabilities in Ada at a fraction of the cost.

"... you need a tool that's going to do a pretty good translation. PasTran, from the makers of Janus/Ada, is what you need."

T. L. (Frank) Pappas, IEEE Computer

JANUS/ADA: WHERE OUR CUSTOMERS COME FIRST!!!!



SOFTWARE, INC.

© Copyright 1989 RR Software

specialists in state of the art programming

P.O. Box 1512 Madison, Wisconsin 53701
(608) 244-6436 TELEX 4998168

1-800-PC ADA 4 U !!!!!

VAX minicomputer or microcomputer using INGRES Version 5.0/03 and VAX.VMS/04. INGRES is available through Relational Technology, Inc.

This program was written by Joseph W. Billitti of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 61 on the TSP Request Card. NPO-17391



Physical Sciences

Designing Corrector Optics

Image-spot radii can be reduced by factors ranging from 5 to 25.

Corrector Surface Design Software (CORFIG) calculates the optimum figure of a corrector surface for an optical system based on real ray traces. CORFIG generates the corrector figure in the form of a spline data-point table and/or a list of polynomial coefficients. The number of spline data points as well as the number of coefficients are specified by the user.

First, the parameters of the optical system (thicknesses, radii of curvature, and the like) are entered. CORFIG traces the outermost axial real ray through the uncorrected system to determine approximate radial limits for all rays. Then several real rays are traced backward through the system from the image to the surface that originally followed the object, within these radial limits. At this first surface, the local curvature is adjusted on a small scale to direct the rays toward the object, thus removing any accumulated aberrations.

For each ray traced, this adjustment is different, so that at the end of this process the resultant surface is made up of many local curvatures. The equations that describe these local surfaces, expressed as high-order polynomials, are then solved simultaneously to yield the final surface figure, from which data points are extracted. Finally, a spline table or list of polynomial coefficients is extracted from these data points.

CORFIG is intended to be used in the late stages of optical design. The design of the system must have at least a good paraxial foundation. Preferably, the design should be at a stage at which traditional methods of correction of Seidel aberrations do not bring the size of an image spot within specification.

CORFIG reads the system parameters of such a design and calculates the optimum figure for the first surface such that all of the original parameters remain unchanged. Depending upon the system, CORFIG can reduce the root-mean-square image-spot radius by a factor of 5 to 25.

The original parameters (magnification, back focal length, and the like) are maintained because all rays upon which the corrector figure is based are traced within the bounds of the outermost ray of the original system. For this reason, the original system must have a certain degree of integrity.

CORFIG optimizes the figure of the corrector surface for on-axis images at a single wavelength only. However, it has been demonstrated many times that the method of CORFIG also significantly improves the quality of field images and images formed at wavelengths other than the design wavelength.

CORFIG is written completely in VAX FORTRAN. It has been implemented on a DEC VAX-series computer under VMS with a central-memory requirement of 55K bytes. The program was developed in 1986.

This program was written by A. Dantzler of Goddard Space Flight Center. For further information, Circle 110 on the TSP Request Card. GSC-13120



Mathematics and Information Sciences

Data-Dictionary-Editing Program

Access to data-dictionary relations and attributes is made more convenient.

The Data Dictionary Editor (DDE) computer program was developed to give the developers of data bases more convenient access to the OMNIBASE VAX/IDM data-dictionary relations and attributes. Prior to the development of DDE, access to the descriptions table could be obtained via OMNIBASE IQL software. However, it was necessary to specify relations (tables) and attributes (fields) by numbers associated with their names. The DDE application program provides more convenient read/write access to the data-dictionary table ("descriptions table") via a data screen that uses SMARTQUERY function keys. (SMARTQUERY is an OMNIBASE software product that uses special function keys for the storage and retrieval of data records.)

DDE provides three main advantages: (1) The user works with the table names and field names rather than with table numbers and field numbers, (2) DDE provides online access to definitions of data-dictionary keys, and (3) DDE provides a displayed summary list that shows, for each datum, which data-dictionary entries currently exist for any specific relation or attribute.

The DDE data screen is an OMNIBASE

SMARTDESIGN screen with two windows. The top window retrieves relation (table) descriptions and attribute (field) descriptions. The bottom window retrieves definitions of data-dictionary keys. DDE allows users to switch back and forth between the two windows without interfering with retrievals in progress in either window.

The DDE application program was developed for specific use: that of review and editing of records in the OMNIBASE "descriptions" relation (table). However, the routines that allow more than one retrieval sequence to be in progress at the same time can be adapted for use in other OMNIBASE applications.

DDE was developed on a DEC VAX 750 computer under VMS 3.6. Implementation of DDE requires a Brittain Lee data-base machine with IDM 500 and the OMNIBASE software package. OMNIBASE is available from Signal Technology, Inc. The DDE program was developed in 1987.

This program was written by A. P. Cumming of McDonnell Douglas Corp. for Johnson Space Center. For further information, Circle 135 on the TSP Request Card. MSC-21290

AutoCAD-To-NASTRAN Translator Program

This program facilitates the creation of finite-element mathematical models from geometric entities.

The AutoCAD to NASTRAN translator (ACTON) computer program was developed to facilitate quick generation of small finite-element mathematical models for use with the NASTRAN finite-element modeling program. (NASTRAN is available from COSMIC.) ACTON reads the geometric data of a drawing from the Data Exchange File (DXF) used in AutoCAD and other PC-based drafting programs.

The geometric entities recognized by ACTON include POINT's, LINE's, SOLID's, 3DLIN's, and 3DFACE's. From this information, ACTON creates a NASTRAN bulk data deck, which can be used to create a finite-element model. The NASTRAN elements created include CBAR's, CTRIA's, CQUAD4's, CPENTA's, and CHEXA's. The bulk data deck can be used to create a full NASTRAN deck. It is assumed that the user has at least a working knowledge of AutoCAD and NASTRAN.

ACTON was written in Microsoft Quick-Basic (Version 2.0). The program was developed for the IBM PC and has been implemented on an IBM PC-compatible under DOS 3.21. ACTON was developed in 1988.

This program was written by A. Jones of Goddard Space Flight Center. For further information, Circle 136 on the TSP Request Card. GSC-13217

Pixelink

...Your Total Resource for High-res Monitors

Pixelink.

Filling your needs for color and monochrome monitors.

For AT, Mac II, PS/2, RT and other platforms.

With expert calibration to *any* high-res graphics board or controller.

With electrical and mechanical customization to your specs.

With complete support • sales • repairs • parts.

Pixelink. The North American importer and authorized service center for Philips (FIMI), a NATO manufacturer you can rely on.

Pixelink. Focused exclusively on high, very high, and ultra high-res monitors.

Main Office
8 Kane Industrial Drive
Hudson, MA 01749
508-562-4803 • FAX: 508-568-0514

California
805 University Avenue
Los Gatos, CA 95030
408-354-8471 • FAX: 408-354-8032

Mid-Atlantic & Washington, D.C.
7031 Albert Pick Road, Suite 100
Greensboro, NC 27409
919-665-0848 • FAX: 919-668-3944



Compatibility with AT, PS/2, Mac II and other high-res graphics boards and workstations

UL, CSA, DHHS, VDE B and FCC B approved

CRT with Dynamic Focus in-line gun, 30,000 hours' MTBF

Custom electrical and mechanical modifications to meet your application needs

PCBs housed in rigid steel frame and mounted in guide rails for ease of access and diagnosis

Modular electronics with self-diagnostic indicators


Tempest Approved (some models)

PHILIPS

The Philips name. Over a century of technological excellence


PIXELINK
CORPORATION

Circle Reader Action No. 490



Mechanics

Hardware Techniques, and Processes

- 72 Spring-Blade Impact Tester
- 72 Algorithm for Solution of Navier-Stokes Equations
- 73 Improved Flow-Controlling Vortex Generator

- 74 Cleanly Burning Squib
- 75 Capillary-Condenser-Pumped Heat-Transfer Loops
- 76 Calculating Flows in Turbomachine Channels
- 77 Structurally-Tailorable, Nonlinear, Snap-Through Spring

Books and Reports

- 79 Thermal Stresses in Space-Shuttle Wing
- 79 Reduced-Dynamic Technique for Determination of Orbits
- 81 Quality Evaluation by Acousto-Ultrasonic Testing of Composites

Spring-Blade Impact Tester

A record of energy relationships can be retrieved from a compact, portable tester.


Langley Research Center, Hampton, Virginia

The spring-blade impact tester was developed to support the evaluation of the tolerance to damage of struts under consideration for use in the Space Station. This approach offers the potential for determining damage as a function of the change in the relationship between applied and absorbed energies as the applied energy is successively increased with each impact. The concept also provides the potential for measuring behavior during impact, and the energy relationships are retrievable from oscilloscope traces of the impact.

The tester includes two identical flat spring blades set vertically and parallel to each other (see figure). The blades are clamped at the bottom to a massive plate that acts as a baseplate for the whole unit. At the upper ends, the blades are clamped to a single, rectangular-beam-like mass that spans the horizontal distance between them. When the mass is pulled horizontally in a direction that causes the blades to bend about their weak axis, the beam remains horizontal. Upon release of the pulling force, the mass travels back and forth horizontally with a decaying oscillatory motion.

Strain gauges installed on the blades measure the bending of the blades. A pair of back-to-back strain gauges mounted on each blade at a point other than at mid-height, where strain is always zero, provides a signal proportional to the displacement of the blade at the moment of release.

The maximum kinetic energy of the oscillating mass is proportional to the volume



The **Impactor Strikes the Specimen** at the moment of maximum kinetic energy after the spring blades are released from their cocked position.

of the two blades, the elastic modulus of the blade material, and the square of any measurable static elastic bending strain at the moment of release, if damping is assumed to be zero. Damping is not zero, but its highly repeatable effect can be measured, calibrated, and taken into account so that the maximum kinetic energy can be predictably set by monitoring and adjusting the static bending strain at the instant of release. The specimen is placed so that a special anvil attached to the mass strikes it at midoscillation, the moment of maximum kinetic energy.

Other features include a hydraulic actuator to pull the mass to its release position; a special releasing latch that provides a clean, sharp release actuated by the tap of

an ordinary hammer; and a special latch that allows the mass to pass through the location of maximum kinetic energy only once. This second latch prevents repeated, oscillatory blows to the specimen. Because the energy available is a function of the volume of the spring-blade material, a minimum of space is required for operation and storage. The impact tester is compact and portable and is both easy and safe to use.

This work was done by Alan M. Holmes and James W. Champagne of Lockheed Missiles & Space Co., Inc., for Langley Research Center. For further information, Circle 22 on the TSP Request Card. LAR-13749

Algorithm for Solution of Navier-Stokes Equations

Advantages of two previous algorithms are combined.

Lewis Research Center, Cleveland, Ohio

An algorithm for the solution of the two-dimensional, steady-state Navier-Stokes equations has been developed by combining the efficiency of the LU-SSOR scheme with the accuracy of the flux-limited dissipation scheme.

The algorithm has been used to predict laminar, turbulent, and hypersonic flows.

The development begins with the classical equations for the two-dimensional, vis-

cous flow of a gas in thermodynamic equilibrium. The flow is characterized by Cartesian components of velocity as functions of position and time. The dependent variables include the mass density, total energy per


unit mass, pressure, and temperature. The pressure is obtained from an equation of state, as a function of the ratio of specific heats and the difference between the densities of total and kinetic energy. The Navier-Stokes equations are written in the form of conservation laws for the fluxes of mass, momentum, and energy, with source terms based on scalar coefficients of viscosity and thermal conductivity.

The steady-state Navier-Stokes equations are put in an implicit finite-difference form that can be solved by approximate Newton iteration. Because of the rapid growth in the number of arithmetical operations with the number of cells in the finite-difference mesh, such systems of equations have previously been solved indirectly by relaxation methods.

The LU-SSOR scheme is a new relaxation method that combines the advantages of LU factorization with Gauss-Seidel relaxation. The vectorizable LU-SSOR scheme, which is based on central differences, requires scalar diagonal inversions. The application of the scheme to the approximate Newton iteration of the Navier-Stokes equations yields a set of equations that require no implicit smoothing on the left side. Only adaptive, total-variation-diminishing, flux-limited dissipation terms are added to the right side.

The algorithm was able to simulate a subsonic, viscous, laminar flow past an airfoil (see figure). It also performed well when applied to a subsonic, viscous, turbulent flow past an airfoil and to two hypersonic, inviscid flows past an inlet.

This work was done by Seokkwan Yoon of Sverdrup Technology, Inc., for **Lewis Research Center**. Further information may be found in NASA CR-179608 [N87-



These **Velocity Vectors** mark the viscous flow past a National Advisory Committee for Aeronautics 0012 airfoil at mach 0.5, Reynolds number 5,000, and zero angle of attack.

20243], "A Navier-Stokes Solver Using the LU-SSOR TVD Algorithm."

Copies may be purchased [prepayment required] from the National Technical In-

formation Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700. LEW-14656

Improved Flow-Controlling Vortex Generator

Symmetrical tangential streams control flow of radial primary streams.



NASA's Jet Propulsion Laboratory, Pasadena, California


A vortex generator uses a small secondary stream of fluid to control a normally-larger primary stream. The device is an improved version of the vortex generator described in "Variable Control Port for Fluidic Control Device," (NPO-16603), *NASA Tech Briefs*, Vol. 10, No. 2 (March/April 1986), pp. 114-115. Like a valve, the vortex generator can vary the rate of flow of the primary fluid from its maximum value down to zero. When properly designed, it requires a low pressure differential between the primary and secondary streams and expends a relatively small amount of secondary fluid.

The vortex generator consists of a disk-like short, hollow cylinder in which the primary fluid enters radially at two opposed

points while two secondary streams enter tangentially at points 90° from the primary streams (see figure). An exit port is located at the center of one end of the cylinder.

The primary fluid enters through slots that extend the height of the cylinder. Without any secondary flow, the primary streams flow directly from their entrance ports to the central exit port. When the secondary streams are introduced (at a smaller volume and greater velocity), they set up a circular flow that gradually spirals inward

Secondary, or Control, Flows entering tangentially through diametrically opposite ports set up a swirling motion that restrains the primary flow. The pressure of the secondary fluid in relation to that of the primary fluid is the controlling factor.



to the exit port.

The rotating fluid exerts pressure against the periphery of the cylinder in proportion to the square of the circumferential velocity of the fluid and inversely proportional to the radius of the cylinder. This centrifugal pressure acts against the primary-fluid inlet ports as well as against the wall. Thus, the greater the speed of the secondary fluid, the smaller the flow from the primary inlet ports. When the centrifugal pressure equals the primary inlet pressure, the primary flow stops. At that point, the only fluid leaving the exit port is the secondary fluid.

In an experimental version of the valve

with air as the fluid, a secondary pressure of only 100 psi (0.69 MPa) created enough circumferential flow to cut off the primary flow at a supply pressure of 80 psi (0.55 MPa). The secondary flow aids in removing particles previously entrained in the primary flow that have been dropped in the vortex generator. In tests with combinations of air and sand; water and sand; air, water, and sand; and diesel fuel, n-pentane gas, and pulverized coal; the secondary gas (air) swept up the particles and carried them to the exit port.

This work was done by Earl R. Collins, Jr., Wilbur J. Marner, and Naresh K. Rohatgi of Caltech for NASA's Jet Propul-

sion Laboratory. For further information, Circle 151 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Edward Ansell
Director of Patents and Licensing
Mail Stop 301-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125

Refer to NPO-17277, volume and number of this NASA Tech Briefs issue, and the page number.

Cleanly Burning Squib

The ignition wire would be repositioned to suppress unburned particles.

NASA's Jet Propulsion Laboratory, Pasadena, California

A proposed pyrotechnic squib would burn more thoroughly and cleanly than its predecessors. It would therefore rupture its diaphragm and release its hot gases at a pressure that is more nearly constant and predictable from unit to unit.


In the present version, the ignition wire that ignites the charge is located at the bottom of the combustion chamber (see figure). The charge thus burns upward and can expel unburned particles of the charge, creating localized and unpredictable variations in pressure that affect adversely the operation of the squib-actuated mechanism.

In the proposed new configuration, also shown in the figure, the ignition coil would be located near the top of the combustion chamber. As the charge burns, the unburned portion would be held at the bottom of the chamber. Little or no unburned charge would be ejected. A more nearly uniform pressure would be generated, and only gases would be ejected from the combustion chamber.


This work was done by Donald B. Bickler of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 90 on the TSP Request Card. NPO-17112

Is your subscription about to expire?

Check the expire date. If it is less than 6 months now is the time to fill out a new qualification form before your subscription expires.



PRESENT CONFIGURATION



PROPOSED CONFIGURATION

The Ignition Coil Would Be Moved Upward from its present position at the base of the combustion chamber. This arrangement would help to contain solid particles of the explosive charge until they are gasified by combustion. In the present configuration, particles can escape before they burn.

Capillary-Condenser-Pumped Heat-Transfer Loop

The heat being transferred supplies the operating power.

Marshall Space Flight Center, Alabama

The capillary-condenser-pumped loop is a closed-circuit, two-phase-fluid system for the transfer of heat through relatively long pipes. Like a heat pipe, this system requires no pump or externally supplied power to circulate the heat-transfer fluid, relying instead on the flow of heat in its evaporator and condenser sections to do the pumping. Unlike in a heat pipe, in which the liquid and vapor flow in opposite directions, the liquid and vapor in the capillary-condenser-pumped loop flow in the same direction.


In some respects, the capillary-condenser-pumped loop is essentially a capillary-evaporator-pumped loop operating in reverse. The loop (see figure) is filled with the fluid in both liquid and vapor phases. Heat is added to the liquid phase along the evaporator section (an ordinary pipe with no wick structure), causing the liquid to vaporize. Heat is removed in the relatively short condenser section, causing the vapor to condense.

The condenser section contains a non-wettable, porous wick structure in thermal contact with an external heat sink. (The corresponding section of a capillary evaporator pump would contain a porous, wettable wick.) The pressure is at a minimum in the vapor condensing in the wick and at a maximum in the liquid that has just condensed. The capillary pressure due to the surface tension of the liquid in the wick is the source of this difference in pressure and balances the pressure lost in pumping the fluid around the loop. The pressure in the condensed liquid pushes this liquid out of the condenser, causing the fluid to flow once again around the loop.

Whereas a capillary evaporator pump must be placed at a heat source, the capillary condenser pump can be placed at a heat sink. Thus, a capillary-condenser-pump heat-transfer loop is preferable where the heat-input (evaporator) length is greater than the available heat-rejection (condenser) length. This situation exists, for example, where the surface of a hypersonic airplane has to be cooled by transporting the aerodynamically generated heat to a central hydrogen-fuel heat sink.

The capillary-condenser-pumped loop offers the following additional advantages:

- Because only a small fraction of the loop is filled with liquid, the weight is lower than that of a forced-convection loop, which must be filled completely.
- The internal pressure is limited to the saturation pressure of the heat-transfer fluid, whereas in an all-liquid forced-



The **Capillary-Condenser-Pumped Heat-Transfer Loop** is similar to a heat pipe and to a capillary-evaporator-pumped heat-transfer loop in that the heat-transfer fluid is pumped by the evaporation and condensation of the fluid at the heat source and sink, respectively. A capillary condenser pump can be combined with a capillary evaporator pump (below) to form a heat exchanger that circulates the heat-transfer fluids in both loops.

convection system, the internal pressure may be several times as high. The lower internal pressure may permit the use of thinner tubing, thus reducing weight even further.

- The transport of heat is more nearly isothermal than in older heat-transport systems of similar capacity. Thus, thermal stress in the loop is reduced, and less external surface area is needed in the condenser section for the rejection of heat to

the heat sink.

This work was done by Calvin C. Silverstein of CCS Associates for **Marshall Space Flight Center**. For further information, Circle 69 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center [see page 14]. Refer to MFS-26046.

Calculating Flows in Turbomachine Channels


A noniterative integral-entrainment method yields good approximations.

*Lewis Research Center,
Cleveland, Ohio*

A method of approximate calculation of flow in a channel of a turbomachine is based on the interaction of viscous flow in the boundary layers with inviscid flow in the core layer. The method is both faster and more robust than other approximate methods of the same type. The method is suitable for use in preliminary calculations for design and for off-design operation of turbomachinery.

The method involves the following assumptions:

1. The flow is turbulent everywhere but in other respects can be treated as though it were steady everywhere.
2. The fluid is a perfect gas.
3. The flow in the boundary layers is two-dimensional, without a crossflow component.
4. The flow surfaces are adiabatic.
5. Density varies along the streamlines but not along lines perpendicular to the boundaries.
6. The streamline velocity in the boundary layer is describable by a simple power-law equation in the distance from the wall, the thickness of the layer, and the velocity



The **Flows in Conical Diffuser Channels** are represented by two-dimensional boundary-layer and one-dimensional core flows described by the equations of the new method.

Now you can transform your ideas... into a 3-dimensional prototype...



at the edge of the boundary layer, which is taken to be the free-stream velocity.

7. The flow in the core can be treated as though it were one-dimensional, in the sense that the two-dimensional equations of the conservation of momentum and mass can be reduced to one-dimensional equations in the coordinate along a streamline.

The equations of conservation of momentum and mass are integrated through the boundary layers, and some additional assumptions regarding the geometrical properties of the streamlines are invoked. Head's entrainment relation is introduced to find the perpendicular component of velocity at the edge of the boundary layer. The skin-friction coefficient is obtained from the Ludwig-Tillman relation. The variation of free-stream velocity is determined via the simple one-dimensional equation of

continuity for the flow in the core. The set of equations is completed with the energy equation and the equation of state of the flow in the core, which are used to relate the static temperature, pressure, and density to the other quantities.

The foregoing constitute a set of simultaneous one-dimensional differential equations that are solved together to find the flow field. Because no iteration is involved, the solution is found rapidly — that is, the integration is performed in one pass along the channel. With some modifications and additional assumptions, the equations can also be solved for flow with merged boundary layers and no isentropic core ("fully developed" flow) and for separated flow.

The method has been applied to round and rectangular conical diffuser channels (see figure). The calculated pressure coefficients and other quantities of interest

were in good agreement with experimental values in cases in which the analysis indicated no separation of flow. The pressure coefficients showed fair agreement in the separated regions.

This work was done by Lawrence F. Schumann of the U.S. Army Aviation Research and Technology Activity for Lewis Research Center. Further information may be found in NASA TM-88928 [N87-15944], "A Method for Calculating Turbulent Boundary Layers and Losses in the Flow Channels of Turbomachines."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700. LEW-14705

Structurally-Tailorable, Nonlinear, Snap-Through Spring

An abrupt change in load/deflection response is controllable and predictable.

Langley Research Center, Hampton, Virginia

A structurally-tailorable, nonlinear, snap-through spring (STNSTS) exhibits a controllable and predictable abrupt change in load/deflection response and is based upon a known phenomenon of snap-through struc-

tural response. The STNSTS is composed of a pin-connected two-bar linkage as shown in Figure 1, which depicts combined tension/compression springs. As load is applied to the STNSTS, the stiffness is a

function of the internal spring and the bending stiffness of the pin-connected bars. As the load increases, the bars deform laterally until they collapse and snap through (Figure 2).

...just as fast as you can get your hands on this Roland CAMM-3 Modeling Machine!

The Roland CAMM-3 Computer Aided Modeling Machine lets the designer take his ideas to an exact 3-D model . . . fast!

Designed like a 3-D plotter, the CAMM-3 is an innovative new computer peripheral. With the CAMM-3 and its MicroModeler software, an engineer can translate his designs from any CAD system into a functional model without any of the delays and costs normally associated with prototype development. No longer do designers need to produce shop drawings nor wait the days, weeks, and sometimes months it takes before the model returns. And, should there be a design flaw in the first model, the process continues for every design change.

The CAMM-3 can machine a wide variety of materials including wax, wood, plastic, and non-



ferrous metals like aluminum and brass. By maintaining a positioning accuracy of 0.0004" across its 7" x 6" x 6" travel, the CAMM-3 is perfect for applications like PC board drilling, EDM electrode machining, light production, and CAD/CAM training.

Roland's CAMM-3 Modeling Machine.
Helping you design the future.


THE CAMM-3 FROM

Roland
DIGITAL GROUP
WE DESIGN THE FUTURE

Roland Digital Group/Division of Roland Corp. US/7200 Dominion Circle/Los Angeles, CA 90040-3647/Call (213) 685-5141/FAX (213) 722-0911/Telex 67-4489 RCUS LS.

12.5 MFLOPS

32-bit Floating Point Array Processor for PC, XT, AT, & Compatibles



- 473 functions callable from C, FORTRAN, or Turbo Pascal
- Software designed for up to 8 PL1250s, running in parallel

1K Complex Floating Point FFT 8.35ms

Complete with Software—\$2695

For more information & benchmarks, contact:

Eighteen Eight Laboratories

771 Gage Drive, San Diego, CA 92106
(619) 224-2158 • FAX (619) 224-3958

In Australia: Comp. Trans. Sys.
(03) 51 7789

In Japan: Kyokuto Boeki Kaisha (KBK)
(03) 244-3790 • FAX (03) 246-1846

In Europe: Assentoft Electronics
(06) 16 29 26

Circle Reader Action No. 675



Show Your Pride

This quality poplin cap features a striking red and blue embroidered logo against a white background. Leather adjustment strap and cord give added pizzazz. One size fits all. Only \$11.95 each. The perfect gift!

Rush me _____ cap(s). Enclosed is \$ _____ plus \$3.00 postage and handling. (NY residents add sales tax.)
Total enclosed: \$ _____

Name _____

Address _____

City _____

State _____ Zip _____

Mail with payment to:

NASA Tech Briefs, Dept. F
41 East 42nd Street
New York, NY 10017




Figure 1. The STNSTS Can Be Structurally Tailored in both tension and compression configurations.

When the snap through occurs, a large deformation occurs as a result of a small increment of the applied load. After the snap through, the load/deflection response becomes a function of stiffness of the internal spring and the membrane stiffness of the bars. Additional stiffness can be provided by restraints in contact with the spring case. The restraints limit the deflection of the internal spring/two-bar linkage. Once the restraints make contact with the spring case, the load/deflection response of the STNSTS is a function of the stiffness of the internal spring, the membrane stiffness of the bars, and the stiffness of the spring case.

The load/deflection response of the STNSTS is tailorable by changing the size, stiffness, and orientation of its components. Multiple devices can be placed in parallel or series to produce an infinite number of different load/deflection responses. The STNSTS has potential application in passively-tailored rotor-blade flap, pitch, and lag response, to improve the aerodynamic performance and stability characteristics of rotors; in aerodynamically- and aeroelastically-tailored wing spars and ribs, to produce a tailored deformation state for improved effectiveness in maneuvering, aerodynamic performance, and stability characteristics; and in energy absorbers for automobile bumpers and aircraft landing gear.

This work was done by James H. Starnes, Jr., of Langley Research Center

and Gary L. Farley and Wayne R. Mantay of the U.S. Army Aerostructures Directorate. No further documentation is available.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Langley Research Center [see page 14]. Refer to LAR-13729.




Figure 2. Bars Deform and Collapse to produce snap-through spring response.

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Thermal Stresses in Space-Shuttle Wing

Combined thermal deformations of wing-skin panel and the TPS would not tear the SIP layer.

A report presents an analysis of thermal stresses induced in the skin panel, the thermal-protection system (TPS), and the strain-isolation pad (SIP) of the Space Shuttle orbiter. The purpose of the analysis was to determine whether any part of the above-mentioned structures would be overstressed and overdeformed under the reentry heating, assuming one TPS tile had been lost at the end of the reentry heating.

The wing-skin panel, which is reinforced by spanwise stringers of hat-shaped cross section, was represented with an equivalent plate of uniform effective thickness. The temperature distribution in the wing-skin panel was chosen to represent the likely cooling effect of the loss of one tile at the center of the panel at the end of the reentry heating. The temperature of the central square-shaped region of the panel was assumed to be 180 ° (82 °C), while the rest of the panel was assumed to be at 320 °F (160 °C).

The first problem was to determine whether the compressive stresses induced in the panel immediately outside the cooled region would be sufficient to cause skin buckling. The stresses in the panel were calculated by use of the NASA structural analysis (NASTRAN) computer program. The peak chordwise compressive stresses predicted by NASTRAN were 4960 lb/in.² (34.2 MPa) and 2650 lb/in.² (18.3 MPa), respectively, under free-edge and fixed-edge conditions. The critical buckling stress in the chordwise direction calculated from the classical buckling theory was 3612 lb/in.² (24.9 MPa). Thus, if the actual edge condition is close to the free-edge condition, then the skin panel immediately outside the cool region may reach the elastic instability in the chordwise direction.

The next problem was to determine whether the thermal deflection of the skin panel could tear the SIP. The maximum chordwise compressive stress in the skin panel calculated by NASTRAN could produce a maximum deflection of 0.0246 in. (0.63 mm), which could induce peak tensile stress of 18.14 lb/in.² (125 kPa) in the SIP. This stress level is considerably less than

the tensile strength [40 lb/in.² (276 kPa)] of the SIP. Thus, the SIP is unlikely to be torn.

Finally, thermal-stress analysis was performed on the TPS tile that was subject to the most severe temperature gradient during the reentry heating. The tensile stress induced in the TPS was found to be much less than the tensile strength of the TPS tile. For the worst case, that in which the skin-panel and the TPS tile deform in opposite directions, the combined deflections of the skin panel and the TPS tile could induce 33.72 lb/in.² (232.5 kPa) tensile stress in the SIP. This is about 84 percent of the tensile strength of the SIP. Thus, the combined deformations of the TPS tile and the skin panel are unlikely to tear the SIP.

This work was done by William L. Ko and Gerald M. Jenkins of Ames Research Center. Further information may be found in NASA TM-88276 [N87-23994], "Thermal Stress Analysis of Space Shuttle Orbiter Wing Skin Panel and Thermal Protection System."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700.

Inquiries concerning rights for the commercial use of this invention should

be addressed to the Patent Counsel, Ames Research Center [see page 14]. Refer to ARC-12139.

Reduced-Dynamic Technique for Determination of Orbits

Orbits are determined more accurately than in the dynamic or geometric method.

A report discusses the reduced-dynamic technique for the use of signals from satellites in the Global Positioning System (GPS) to determine the orbit of a satellite in a low orbit around the Earth. The reduced-dynamic technique is formed from a combination of the dynamic and geometric (nondynamic) tracking techniques, and it combines the advantages of both to increase the accuracy of the estimated orbit under conditions in which neither is clearly superior.

The simplest technique is geometric tracking by use of instantaneous measurements to four or more GPS satellites. This technique is completely free of errors in the assumed dynamics but is vulnerable to measurement noise, ephemeris error, and a factor called position dilution of precision,

The Position Transducer with Good Connections

Model LW & LWB

Model LWH

Novotechnik's LWH series of conductive-plastic position transducers comes with whichever connector you need: DIN 43 650 (models LWH & LWG), Binder (LWB & LW), or Amphenol (LWC). The LWH series also gives you high resolution (.01mm) and a range of stroke lengths from 150 to 1200mm. The transducers may be built directly into your mechanical system, without need of motion conversion or linkage mechanisms.

Improved design of the LWH transducer eliminates offset errors and ensures reliable contact of the elastomeric-damped wiper. Outstanding linearities of up to $\pm .05\%$ are available (up to $\pm .01\%$ on special order), as well as life expectancies of up to 100×10^6 operations. Robust construction ensures consistent reliability, in temperatures from -40 to $+100^\circ\text{C}$, 5 to 2000Hz vibration.

For Novotechnik's full line catalog of transducers, potentiometers and sensors, call or write:

novotechnik
Siedle Group

novotechnik u.s., inc.
237 Cedar Hill Street
Marlborough, MA 01752
Tel: 508-485-2244
FAX: 508-485-2430

which magnifies the error where the observing geometry is poor. At best, the tracking accuracy approaches a few meters.

In dynamic tracking, the dynamics of the satellite are constrained, and noisy instantaneous measurements of the state (position or velocity or both) of the satellite taken during an interval of time are combined to reduce the measurement noise and to yield greater information concerning the state at a single instant of time. At the same time, the estimates of the orbits of the GPS satellites are also improved to reduce their contributions to the error of the estimated state of the satellite in question. The transition from the states of the satellites at the times of the measurements to the states at the time of interest is furnished by integration of the equations of motion, which are governed by the forces (dynamics) acting upon the satellites during the interval. Any mismodeling of these dynamics results in systematic errors in the state. These errors tend to grow as the data arc length increases.

In nondynamic tracking, the instantaneous user satellite positions are still determined by differential GPS pseudorange measurements; however, the transition between positions at different times is furnished by the satellite positional change inferred from continuous differential GPS carrier phase measurements. Because

carrier phase can be tracked with extremely high accuracy, very accurate state transition can be inferred from carrier phase. This approach is completely free from satellite dynamic errors. In exchange, however, it is highly sensitive to weak observing geometry.


Nondynamic tracking discards orbit dynamic models and the associated information entirely. This is one of the principal attractions of the nondynamic technique. Not only is sensitivity to model errors eliminated, but the complexity of the solution process is greatly reduced. Nevertheless, it is reasonable that if dynamic and nondynamic tracking are good separately, then an optimal combination of the two should be even better. In situations in which the geometry is good and the dynamics are poorly known, the small additional improvement to be expected by adding in dynamics might not justify the greatly increased complexity. However, where the geometry is poor and the dynamic models are reasonably good, the added dynamic information could lead to a substantial improvement. In the new technique, both dynamic and geometric information is used to propagate the state, with appropriate weight given to each method.

The reduced-dynamic technique can be described mathematically in terms of a Kalman sequential-filter formulation. This

involves two steps: a time update, which makes use of a state-transition model to propagate the estimate of the state and the covariance of the state of the satellite from one batch of data to the next, and a measurement update, which incorporates a new batch of measurements. These two steps alternate until all batches of data are incorporated.

The weight on the dynamic information is controlled by adjusting a set of three process-noise parameters that represent a fictitious three-dimensional force on the satellite in question. The relative weight of the dynamics is varied by selecting different values for the a priori uncertainty σ_0 , the steady-state uncertainty σ , and the correlation time τ for these process-noise parameters. An increase in τ and a decrease in σ_0 and σ increases the weight on the dynamic information. When $\tau \rightarrow \infty$, $\sigma \rightarrow 0$, and $\sigma_0 \rightarrow 0$, the technique reduces to conventional dynamic tracking; when $\tau \rightarrow 0$, $\sigma \rightarrow \infty$, and $\sigma_0 \rightarrow \infty$, it becomes nondynamic tracking. It follows that an optimally-tuned reduced-dynamic solution must always be as good as or better than both the purely dynamic and the purely nondynamic solutions.

To derive the full benefit of the reduced-dynamic technique, it is necessary to give the optimum weight to the dynamic model. The weight can be predetermined through



If you can see the flaws,

Now there's a way to turn visual inspection into problem prevention. Instead of just scrapping bad product, you can locate problem processes and fix them.

The new DataMyte® 769 system automates inspection reporting. But more than that, it's a problem solving tool that will pay for itself in less than six months.



The system is rugged, compact, and easy to use. It gobbles up data with quick keypad or bar code entry. It gives you back information in its most usable form—charts on a video display terminal and repair tickets off a printer.

You get instant lot control and traceability, so that you can pinpoint concerns and tie

a covariance analysis that uses a realistic model of the dynamic error. However, the performance appears to be insensitive to the relative weighting between the two types of information as long as it is not far from optimum. When the actual level of dynamic-model error is uncertain, an additional deweighting of the dynamic model is recommended. Such biased weighting would prevent an inordinately large error from arising due to misjudgment of the error in the dynamic model.

This work was done by Sien-Chong Wu, Thomas P. Yunck, and Catherine L. Thornton of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Reduced-Dynamic Technique for Precise Orbit Determination of Low Earth Satellites," Circle 126 on the TSP Request Card.
NPO-17386

Quality Evaluation by Acousto-Ultrasonic Testing of Composites

This promising nondestructive-testing method is based on ultrasonic simulation of stress waves.

A report reviews acousto-ultrasonic technology for nondestructive testing. The report

discusses principles, suggests advanced signal-analysis schemes for development, and presents potential applications.

Acousto-ultrasonics has been applied principally to assess defects in laminated and filament-wound fiber-reinforced composite materials. The technique can be used to determine variations in such properties as tensile, shear, and flexural strengths and reductions in strength and toughness caused by defects. It can be used to evaluate states of cure, porosities, orientation of fibers, volume fractions of fibers, bonding between fibers and matrices, and qualities of interlaminar bonds.

The term "acousto-ultrasonics" is a contraction for "acoustic-emission simulation with ultrasonic sources." Conventional acoustic-emission testing depends on loading a part to excite spontaneous stress waves like those that accompany plastic deformations and the growth of cracks. Acousto-ultrasonics differs mainly in that the ultrasonic waves are benign and are generated externally by pulsed sources (usually piezotransducers).

In a typical apparatus, a transmitting probe and a receiving probe are placed a specified distance apart on the same side of the part under test. The sending-and-receiving pair can be moved about as a unit to scan the part. Signal-processing instrumentation analyzes the received sound to


generate a map of variations in the properties of the material.

The sensitivity of acousto-ultrasonics has already been demonstrated experimentally. The technology has been used to detect and quantify subtle but significant variations in strength and resistance to fracture of fiber-reinforced composites. This achievement is remarkable because it was accomplished with relatively-unso-phisticated signal-processing and signal-analysis procedures.

Although acousto-ultrasonic technology has been used on polymer-matrix composites, it is applicable to such other composite materials as metals reinforced by fibers and ceramic-matrix composites. The use of acousto-ultrasonics should be considered whenever it is necessary to quantify damage or degradation of properties after composites have been exposed to hostile environments.

This work was done by Alex Vary of Lewis Research Center. Further information may be found in NASA TM-89843 [N87-20562], "The Acousto-Ultrasonic Approach."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700. LEW-14709



you can fix the cause.

what happened with who, when, where and why.

We'll show you how to get started.


Fax us one of your inspection sheets. We'll make a bar coded version of it, and show you how to stream-line data collection and analysis. Our fax number is 612-935-0018.

Or call us at 612-935-7704, and we'll arrange

a demonstration. With over 20,000 proven DataMyte installations, and over twenty years in the business, we can help you see your way to better quality.

DataMyte

An Allen-Bradley Company



Machinery

Hardware Techniques, and Processes

82 Robot Hand Grips Cylinders Securely
83 Energy-Efficient, Continuous-Flow Ash Lockhopper

84 Thermal Brushes for Memory-Metal Actuators

Books and Reports
85 Ceramic Bearing for Gas-Turbine Engines

Robot Hand Grips Cylinders Securely

Jaws and linkage accommodate various sizes.

Lyndon B. Johnson Space Center, Houston, Texas

A robot hand includes two pairs of parallel jaws that can grasp rods, pipes, tubes, struts, and other long, heavy cylindrical objects. The hand features a compact rotary drive and a butterfly configuration that simplify the approach and gripping maneuvers of the robot.

Parallelogram linkages maintain the alignment of each jaw with the other jaws. One bar of each linkage is connected to one of two concentric, counterrotating shafts; the rotation of these shafts moves the jaws in each pair toward or away from each other to grasp or release the workpiece (see Figure 1).

Each jaw includes a rigid gripping pad lined with rubber to give it a firm grip and to prevent damage to the workpiece. The inner cylindrical surface (corner) of each jaw tapers off to flat sides. This enables the jaw to grasp workpieces with diameters larger than or equal to twice the corner radius. The range of graspable diameters could be increased by making the corner radius very small and the flat sides as fingers that mesh together when the jaws approach each other.

The counterrotating shafts are driven by two pancake-type harmonic speed reducers in series, actuated by the same motor (see Figure 2). The output of one harmonic speed reducer drives the inner shaft, while that of the other harmonic speed reducer drives the outer shaft. Slots are cut in the outer shaft so that the stationary portions of the harmonic speed reducers can be fixed to the housing. It is possible to do this because the outer shaft does not have to rotate more than 50°.

This work was done by George F. Parma of Johnson Space Center. For further information, Circle 82 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Johnson Space Center [see page 14]. Refer to MSC-21365.




Figure 1. Pairs of Jaws on Parallelogram Linkages are actuated by counterrotating shafts. Part of the outer shaft is cut away to allow movement of the arms of the linkage connected to the inner shaft.




Figure 2. The Compact Rotary Drive contains two collinear harmonic speed reducers driven by the same motor.

Energy-Efficient, Continuous-Flow Ash Lockhopper

Pressure balance in the control gas prevents the loss of reactor gas.

NASA's Jet Propulsion Laboratory, Pasadena, California


The energy efficiency of a continuous-flow ash lockhopper (see figure) has been increased by preventing hot gases from flowing out of a reactor vessel through the ash-hopper outlet and carrying away heat energy. Stopping the loss of reactor gases can also be important for reasons other than energy efficiency: the desired reaction product may be a gas, or the gases produced may be toxic or may need to be contained to prevent pollution. The improved lockhopper should also enable the reactor to attain the highest possible product yield with continuous processing while permitting a controllable, continuous flow of ash.

The principal components of the lockhopper have been discussed in the following NASA Tech Briefs: "Pressure-Letdown Plates for Coal Gasifiers" (NPO-15965), page 355, Vol. 8, No. 3 and "Variable Control Part for Fluidic Control Device" (NPO-16603), page 114, Vol. 10, No. 2. The lockhopper was designed to convert reactor solids removal from batch to continuous flow; it should also be applicable in fluidized-bed reactor systems and in the separation of dust or other solids from gases.

In the improved lockhopper, the loss of the reactor gas is prevented by equalization of the pressure of the control gas injected into the fluidic flow-control device with the pressure in the reactor vessel. This eliminates the pressure gradient at the ash outlet of the reactor. However, the flow of ash continues because of gravity. In scale-model tests that used sand to simulate ash, the continuous flow of the sand was obtained without loss of reactor pressure.

In the original lockhopper, a quasi-porous-plug pressure-letdown device greatly reduced, but did not eliminate, the loss of gas and the concomitant loss of heat from the reactor vessel. In the improved lockhopper, the pressure-letdown device serves to reduce the flow of control gas required to achieve the equalization of pressures.

The original lockhopper used steam as the control gas, but in some processes the introduction of steam into the reactor vessel is not permissible or not desirable. The steam was generated by injecting water into the ash-hopper outlet of the reactor. This quench water also caused large cinders to disintegrate into fine ash that could pass through the fluidic control and pressure-letdown devices. With the improved lockhopper, moving grates or other conventional mechanical methods would be used to break up cinders when necessary.



In the **Improved Continuous-Flow Ash Lockhopper**, the pressure-driven loss of hot gas from the reactor vessel through the ash-hopper outlet is prevented by using the control gas in the fluidic flow-control device to equalize the pressure in the reactor vessel.

In many applications the control gas may be compressed air; in others, inert gases or other specific gases may be re-

quired. The control gas eventually leaves the system along with the ash, but a collecting chamber with scavenging compressor

pumps can be used to recover it for recirculation.

This work was done by Earl R. Collins, Jr. and Jerry W. Suito of Caltech **NASA's Jet Propulsion Laboratory** and David Dubis of the Morgantown Energy Technology

Center of the Department of Energy. For further information, Circle 92 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive

license for its commercial development should be addressed to the Patent Counsel, NASA's Resident Office-JPL [see page 14]. Refer to NPO-16985.

Thermal Brushes for Memory-Metal Actuators

Thermal brushes would remove or add heat for rapid actuation.

*NASA's Jet Propulsion Laboratory,
Pasadena, California*

Proposed thermoelectric elements with wire-brush contacts would remove heat from or add heat to memory-metal actuators and thereby enable them to respond faster than previously possible. A memory-metal actuator is formed to a shape while hot, then to another shape while cold. When a cold actuator is heated so that its temperature rises above a critical point, it snaps from its cold shape to its hot shape. Upon cooling, the actuator returns to its cold shape, ready for another cycle. Clearly, the faster the actuator can be heated and cooled, the faster it can operate.

In an early version of a memory-metal actuator, actuation time was kept short by keeping the actuator just below its critical temperature and passing an electrical current through it for direct resistance heating. Later versions used thermoelectric cooling. Peltier junctions consisting of metal wires were placed on the actuators or on their mounting plates. However, metal thermocouples are highly inefficient and would accomplish little more than transmit heat by conduction. Semiconducting Peltier junctions are orders of magnitude more efficient, but unlike metal wires, they are inflexible. To allow for this inflexibility, a brush contact is employed.

In the proposed configuration, the actuator could still be heated by passing a current through an electrical resistance. However, it could also be both cooled and heated thermoelectrically via a brush mounted on an external thermoelectric heating or cooling plate (Figure 1). The flexible bristles of the brush would press against or could be permanently attached to the actuator, ensuring good thermal contact. Heat would flow rapidly to or from the actuator metal, through the bristles and heating/cooling plate, from or to a heat sink.

Depending on the heating and cooling needs of the device, additional brushes and cooling elements could be placed along the circumference of the actuator.




Figure 1. **Mounted in the Plane** of actuator motion, bristles of a metal brush press lightly but firmly against the actuator in its closed (hot) position. When the actuator expands to its cold position, the brushes are compressed further.




Figure 2. **Mounted Perpendicularly to the Plane** of motion, bristles rub against the sides of the actuator. They maintain thermal contact in both hot and cold states.

The bristles should bend slightly when they are in contact with the contracted (hot) actuator; they can then easily bend further when the actuator expands. The elements should not be placed near the moving end of the actuator, where they would interfere with the displacement.

The bristles must not be too long or else their thermal resistance will be excessive. Therefore, if they must accommodate a

large swing of the actuator, another brush orientation should be considered. The brushes can be mounted perpendicularly to the plane of motion so that they wipe the sides of the actuators as they expand and contract (see Figure 2). In this position, the brushes add frictional resistance to the motion of the actuator; whereas in the in-plane position, they add bending resistance. In either case, the resistance is small

compared with the density of the force generated by the memory metal — about 6×10^4 psi (400 MPa) for Nitinol (or equivalent) alloy.

This work was done by Charles Wood of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 102 on the TSP Request Card.
NPO-17068

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Ceramic Bearings for Gas-Turbine Engines

Materials and methods of design have improved over the years.

A report reviews data from three decades of research on bearings that contain rolling elements and possibly other components made of ceramics. Ceramic bearings are attractive for use in gas-turbine engines because ceramics generally retain their strengths and resistances to corrosion over a range of temperatures much greater than that of typical steels used in rolling-element bearings. Furthermore, because ceramics have mass densities lower than those of steels, they might be used to reduce centrifugally induced stresses in the outer races of high-speed bearings.

The text begins with a brief description of historical developments in the field. This is followed by a discussion of the effect of contact stress on the fatigue life of a rolling element. The discussion is supplemented by figures and a table that give data on the fatigue lives of rolling elements made of various materials.

The next topic is the effect of elastic and thermal properties. Equations for stresses, contact radii, and fatigue lives are presented. A table gives typical physical properties of ceramic and steel bearing materials. Another table gives the lives and dynamic-load capacities, relative to those of all-steel bearings, of bearings made with steel races and rolling elements of crystallized-glass ceramic, alumina, silicon carbide, titanium carbide bonded with nickel, silicon nitride, or steel.

The report then analyzes data on the effects of temperature and speed on fatigue lives for several materials and operating conditions. This is followed by a discussion of the related topic of the generation of heat in bearings, with consideration of the effects of bearing materials, lubrication,

speeds, and loads.

Preliminary research on unlubricated bearings and bearings lubricated by solid films is reported. There is a brief description of the advantages and disadvantages of several schemes for mounting ceramic-rolling-element bearings. Recent developments in the manufacture of silicon nitride rolling elements are recounted.

The report presents several conclusions, including the following:

- Of the ceramic materials studied, silicon nitride yields the rolling elements with the longest fatigue lives. However, the dynamic-load capacity of an all-silicon nitride bearing is only 5 to 12 percent that of an all-steel bearing of the same size and shape.
- A bearing made of ceramic rolling elements and a steel race cannot be expected to last as long as does an all-steel bearing if the modulus of elasticity of the

ceramic exceeds that of the steel (as it usually does).

- Lubrication of ceramic rolling elements appears to be necessary to prevent failure at high temperatures.
- The contemplated use of all-ceramic bearings in turbomachinery will impose special requirements on design and mounting. Optimum designs have yet to be developed.

This work was done by Erwin V. Zaretsky of Lewis Research Center. Further information may be found in NASA TM-100288 [N88-18007], "Ceramic Bearings for Use in Gas Turbine Engines."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700.
LEW-14832

ITI REMOTE VIEWING SYSTEMS

If you have to visually:

- ☆ Observe
- ☆ Inspect
- ☆ Measure
- ☆ Record (Photo or Video)

in areas that are *inaccessible* or *hostile*, call on the professionals—*Instrument Technology, Inc.*, "The Leader in Remote Viewing."

STANDARD PRODUCTS—Over 1,000 standard products to help solve your problems.

CUSTOM—Since we recognize that most industrial problems are unique, ITI specializes in customizing any product to fit the application.

SYSTEMS—ITI offers total system capability with options for automatic or semi-automatic positioning controls, image analysis and documentation.


All instruments made and serviced in the U.S.A.

P.O. Box 381, Westfield, MA 01086
(413) 562-3606 Telex 955329, Attn: ITI

ITI | INSTRUMENT TECHNOLOGY, INC.

The Leader in Remote Viewing





Fabrication Technology

Hardware Techniques, and Processes

- 86 Strong, Low-Resistance Bonds for AMTEC Electrodes
- 86 Improved Vacuum-Tight Connector
- 88 Electrostatic Spraying With Conductive Liquids

- 89 Differential Curing in Fiber/Resin Laminates
- 90 Attaching Precise Mirrors to Lightweight Supports
- 90 Making a Superconductive Thin Film
- 93 Advanced Engraving of Angle-Encoder Disks

- 94 Process for Patterning Dispenser-Cathode Surfaces
- 95 Deposition of Pinhole-Free CoSi_2 Film
- 96 Fluidized-Bed Reactor With Zone Heating
- 97 Molecular-Beam Epitaxy of CrSi_2 on $\text{Si}(111)$

Strong, Low-Resistance Bonds for AMTEC Electrodes

The heat of an operating cell helps form the contacts.

NASA's Jet Propulsion Laboratory, Pasadena, California

Strong, low-electrical-resistance contacts between the elements of a current-collection grid in an alkali-metal thermoelectric converter (AMTEC) cell are obtained by simple in-place thermocompression bonding. The bonds are formed between the porous electrode of molybdenum film, the nickel or cobalt strips that overlie the film, and the molybdenum tie wires that run at right angles to the strips.

The elements are assembled on a sodium β " alumina ceramic substrate. When the assembly is exposed to the temperature of an operating AMTEC cell, typically in excess of 1,000 K, the elements diffuse and bond together at their junctions under the combination of heat and pressure creat-

ed by the differing coefficients of thermal expansions of the materials. The contact between the nickel grid and the molybdenum current lead is strong but contributes resistance of less than 10 milliohms for a 1-cm² electrode. The contact between the nickel grid and the porous electrode is also quite strong but contributes a higher resistance, approximately 100 milliohms for a 1-cm² electrode, depending on the composition and morphology of the electrode. The bonding method also works on films of tungsten or tungsten/platinum.

This work was done by Roger M. Williams, Bob L. Wheeler, Barbara Jeffries-Nakamura, C. Perry Bankston, Terry Cole, and Maria Loveland of Caltech for NASA's

Jet Propulsion Laboratory. For further information, Circle 5 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Edward Ansell
Director of Patents and Licensing
Mail Stop 301-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125

Refer to NPO-17161, volume and number of this NASA Tech Briefs issue, and the page number.


Improved Vacuum-Tight Connector

A simple reinforcing tube increases service life and improves the seal.


Lewis Research Center, Cleveland, Ohio

Copper cooling lines used in a vacuum must be connected with fittings that not only are easily installed or replaced but also remain vacuum tight at pressures in the range of 1×10^{-9} torr (about 10^{-7} Pa) and temperatures in excess of 250 °C. Standard stainless-steel Swagelok (or equivalent) fittings have been used to make these connections, but the high temperatures to which they were subjected invariably caused leaks, which necessitated the shutdown of the system for maintenance. The repair of a fitting involved the replacement and installation of a new sealing ferrule along with a corresponding shortening of the copper line. Several such repairs would eventually make it necessary to replace a line with a new one of sufficient length.

One method to eliminate this problem, as shown in the figure, is to place a special stainless-steel tube insert within the copper line where the fitting is attached. This insert provides a nondeformable backup wall that supports the copper material



The **Short Stainless-Steel Tube** is inserted in the copper tube to reinforce it against compression, thereby preventing leaks due to thermal distortion or to collapse under the squeeze of the ferrule in the compression fitting.



Take a job that's nothing but problems.

1. How do you design an engine that increases aircraft performance while improving fuel consumption?
2. Create an engine that boosts thrust by 12,000 pounds with just a software change.
3. Design the optimum engine for Advanced Short Takeoff or VTOL aircraft.
4. Can turbine blades be manufactured as single crystals?

If you love solving problems like these, we need you. We'll put you side by side with engineers who are making aviation history. Working on programs like the National Aero-Space Plane. The Advanced Tactical Fighter. Or the engines on the new super-twin jetliners that are transforming commercial aviation.

Your biggest problem could be choosing between Pratt & Whitney's Florida or Connecticut locations. We offer the diversity you'd expect from United Technologies, the world's seventh-largest manufacturing company. Naturally, you'll get good pay and solid benefits. But you'll get something more: a chance to put your energy into things that matter.

Send your resume to Pratt & Whitney, Professional Recruitment, P.O. Box 109600, Mail Stop NBP 710-18, West Palm Beach, FL 33410-9600.

You want more challenge and recognition. **We read you loud and clear.**



An equal opportunity employer.

against the ferrule. This insert not only prevents the copper from moving inward under the squeeze of the ferrule but also prevents thermal distortion of the copper from opening a leak. The insert enables the sealing ferrule to bite more deeply into the copper and thereby produces a vacuum

seal similar in principle to the commonly-used Conflat (or equivalent) flange seal.

Several test specimens of this improved connector have been constructed, tested, and evaluated. The fittings have not only operated successfully at the required operating conditions of vacuum and temper-

ature but have also consistently demonstrated high reliability after having been loosened and tightened many times.

This work was done by Frank Rudin of Lewis Research Center. No further documentation is available.
LEW-14720

Electrostatic Spraying With Conductive Liquids

Thin, uniform polymer coatings can be applied in a water base normally impossible to charge.

Lyndon B. Johnson Space Center, Houston, Texas

An electrostatic sprayer has been modified so that it can apply coatings suspended or dissolved in electrically conductive liquids. The sprayer was developed to apply a water-base polyurethane coating to a woven, shaped polyester fabric. The coating provides a pressure seal for the fabric, which is part of a spacesuit. The sprayer may also be useful for applying waterproof, decorative, or protective coatings to fabrics for use on Earth.

Ordinarily, such a sprayer cannot handle water or other conductive liquids because the tip of the nozzle electrode tends to short-circuit; it cannot then impart a charge to the particles in the atomized liquid. In the modified sprayer, the nozzle and gun are constructed of nonconductive molded plastic. The liquid passageway is made long enough that electrical leakage through it is low. The coaxial hose for the liquid is built of a polytetrafluoroethylene tube, an insulating sleeve, and a polyurethane jacket.

In addition, the sprayer is provided with an insulated seal at the gun-to-hose connection, a nonconductive air hose, a pressure tank electrically isolated from ground, and a special nozzle electrode. The supply of atomizing air is reduced so that particle momentum will be controlled by the electrostatic field more effectively.

A high-voltage cable is connected to the nozzle electrode in the spray head. The polyurethane/water mixture passes from a pressurized pot through the coaxial hose to the nozzle. There it is atomized by the air supply and charged by the negative nozzle electrode so that it emerges from the gun as a spray of uniformly dispersed negative particles. A nozzle voltage of more than 30 kV is needed.

The fabric is not conductive enough to act as a positive electrode. It is therefore placed on a metal plate shaped to conform with the fabric. The electrostatic field passes directly through the thin fabric, setting up a force field perpendicular to the surface of the grounded plate. The fabric interstices thus become thoroughly filled, since the charged particles try to penetrate the fabric. Even irregularly shaped surfaces become smoothly and uniformly coated.

The CPI fitting is one o



**Simple design,
high quality...
The "One and
Only" Parker
single ferrule
fitting for
process con-
trol, power,
instrumentation
and analytical
systems.**

The simplicity of Parker's single ferrule design, only two metal-to-metal seal points, makes the CPI fitting one of the most effective leak tight fittings available.

Available in a wide range of configurations, materials and sizes. No matter what the application, there is an engineered CPI fitting or valve to meet your most demanding requirements.

As a precaution, the fabric surface should be made thoroughly clean, as should the atmosphere in which the spraying process is carried out. Otherwise, dirt particles on the fabric will align with the force field and stand upright, creating a flocked surface.

This work was done by Joseph J. Kosmo and Frederic S. Dawn of **Johnson Space**

Center and Robert E. Erlandson and Loren E. Atkins of **Albany International Research Co.** For further information, Circle 85 on the TSP Request Card.

Title to this invention has been waived under the provisions of the National Aeronautics and Space Act [42 U.S.C. 2457(f)], to the Albany International Research Co. Inquiries concerning licenses for its com-

mercial development should be addressed to

Albany International Research Co.
1000 Providence Highway
Dedham MA 02026

Refer to MSC-21067, volume and number of this NASA Tech Briefs issue, and the page number.

Differential Curing in Fiber/Resin Laminates

A modified layup schedule should counteract the tendency toward delamination.

Lyndon B. Johnson Space Center, Houston, Texas

over 10,000 products made as standard by the instrumentation divisions of Parker.

Our Total Quality Assurance
and S.P.C. Programs assure the
integrity of your systems.

For full information contact:

Parker Hannifin Corporation
Instrumentation Connectors
Division
P.O. Box 400004-1504
Montgomery, AL 35815-1504
(205) 881-2040

Canada call:
Parker Hannifin, Inc., Grimsby, Ontario, 416/945-2274

Parker Hannifin Corporation
Instrumentation Valve Division
P.O. Box 69
Jacksonville, Alabama 36265
205 / 435-2130

Parker
FluidConnectors

A proposed differential-curing technique should help to prevent the entrapment of volatile materials during the manufacturing of fiber/resin laminates. The volatiles are released during the cure of the resin. It is necessary to remove them because they give rise to voids and delaminations.

In the conventional (non-differential-curing) manufacturing process, layers of woven fibers, all impregnated by the same thermosetting resin (prepregs), are stacked on a mold, then covered with a release material and a bleeder cloth. The entire layup is then enclosed in a vacuum bag and heated in an oven or autoclave to cure the resin. The vacuum removes the volatiles that diffuse out to the surface of the laminate.

The rate of curing of the resin increases with the temperature. Because the heat of the oven or autoclave is conducted into the curing laminate through the bag and the mold, the outer plies of the laminate are initially hotter, and therefore, can cure before the middle plies do. If the outer plies on the bag side cure first, they can trap the volatiles inside.

The improved manufacturing process would resemble the conventional process, except that prepregs that have been partially cured would be laid on the mold in a sequence in which the degree of partial cure decreases from the mold side to the bag side. The degree of partial cure of each layer at the time of layup can be selected by controlling the storage and partial-curing temperatures of the prepreg according to an Arrhenius equation for the rate of gel of the resin as a function of temperature and time from the moment of mixing. The differential advancement of the cure in the layers would be made large enough to offset the effect of advance bag-side heating in the oven or autoclave. Thus, the inner layers would cure before the outer layers, allowing the volatiles to escape.

In an alternative version of the process, the prepregs would be uncured or partially cured to the same degree and kept in cold storage. One prepreg would be taken from storage, placed on the mold, and heated to a moderate temperature for a short time to obtain a partial cure. Another prepreg

would then be taken from storage, placed on the first prepreg, and the resulting layup heated again to cure the first layer further and begin the cure of the second layer. This process would be repeated until all the layers are in place. The laminate would

then be vacuum-bagged and autoclaved to complete the cure.

This work was done by Charles N. Webster of LTV Missiles and Electronics Group for **Johnson Space Center**. For further information, Circle 109 on the TSP

Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Johnson Space Center [see page 14]. Refer to MSC-21376.

Attaching Precise Mirrors to Lightweight Supports

Mirrors would be formed on optical masters and glued in place.

NASA's Jet Propulsion Laboratory, Pasadena, California


A technique has been proposed to form precise mirror surfaces on lightweight, rigid, imprecise graphite-composite substrates. The technique should enable the fabrication of lightweight mirrors of high surface finish suitable for use at short wavelengths: Heretofore, the irreducible small-scale roughness of the surfaces due to the structures of composite materials inhibited the use of composite mirrors at short wavelengths.

The technique (see figure) resembles that used to make lightweight replica mirrors and gratings. A layer of parting material is deposited on a master optical surface of the precise desired shape. This parting layer must be very thin to minimize degradation of the replica.

By ion-assisted evaporation or another established method, a shell of mirror or mirror-supporting material is deposited on the parting layer. The shell could be made of SiO_2 , SiN , HfN , or other hard material. The thickness of the shell is made large enough — typically between a few microns and 1 mm — to give the shell significant rigidity of its own and to withstand handling and abrasion.

Next, a layer of adhesive much thinner than the shell is used to attach the mirror shell to a graphite-composite substrate, the surface of which approximates the desired mirror surface. When the adhesive has cured, the substrate and shell are separated from the master at the parting layer. The resulting mirror has nearly the high optical quality of the master.

This work was done by Aden B. Meinel and Marjorie P. Meinel of Caltech for **NASA's Jet Propulsion Laboratory**. For further information, Circle 142 on the TSP Request Card. NPO-17164



A Mirror Would Be Attached to an imprecise substrate in a procedure similar to that used to make replica mirrors and gratings.

Making a Superconductive Thin Film

A sharp transition is obtained at 93 K.

Marshall Space Flight Center, Alabama

An experimental fabrication process results in a superconductive thin film of $\text{YBa}_2\text{Cu}_3\text{O}_7$ (the "123" phase of Y/Ba/Cu/O) on a substrate of green semiconducting Y_2BaCuO_5 (the "211" phase). The film be-

comes superconductive below a transition temperature (T_c) of 93 K.


Previous experiments had shown that after specimens of Y/Ba/Cu/O were reacted at temperatures greater than 950 °C

but for relatively short times, they had sharper T_c transitions. This observation gave rise to the hypothesis that an extremely careful heat treatment is necessary because the formation of the semiconducting "211" phase is thermodynamically favored over the formation of the superconducting "123" phase. The new fabrication process takes account of this hypothesis by incorporating suitable heat treatments.

In the experiment, preparation of the semiconducting substrate material was begun by grinding appropriate amounts of metal oxides, pressing them into pellets, then heating them to 950 °C for 12 h to form the "211" phase. To assure complete reaction, the pellets were reground, pressed into pellets again, and reheated.

The superconducting material to be deposited on the substrate was prepared by mixing the appropriate amounts of metal oxides to form $\text{YBa}_2\text{Cu}_3\text{O}_7$, pressing them into pellets, heating at 950 °C for 12 h, then quenching to room temperature. The material was then annealed in oxygen at 950 °C for 6 h, followed by slow cooling in the furnace. At this point, the material had a T_c of 96 K.

The superconducting material was deposited on the substrate by radio-frequency sputtering at room temperature. Initially, the deposited film was 1 mm thick and was insulating. After it was annealed in oxygen at 900 °C for 30 min, then cooled in the furnace, it had become superconducting. As shown in the figure, the transition to superconductivity at 93 K is very sharp. The estimated critical current density is 350 A/cm².



The Resistance of the Film deposited by the experimental fabrication process decreases with decreasing temperature down to 93 K, where it exhibits a sharp transition to zero.

This work was done by Maw-kuen Wu of the University of Alabama for Marshall Space Flight Center. For further informa-

tion, Circle 29 on the TSP Request Card. MFS-26093

Advanced Engraving of Angle-Encoder Disks


Precision would be increased over that of mechanical engravers.

Marshall Space Flight Center, Alabama

A proposed optical/mechanical/electronic system would engrave the angular-interval marks on angle-encoder disks. The system was conceived to meet the need for increased precision of angular measurements in advanced scientific instruments.

At present, the most-precise angular-encoder disks are made on mechanical angle-dividing machines. Small increases in the precision of such machines are expensive and consume much time. The proposed system would abandon the traditional mechanical-precision approach, relying instead on a combination of the high precision of electronic time division and digital synthesis of frequency with the almost-friction-free motion of a rotor suspended in a high vacuum by electrostatic forces.

As shown schematically in the figure, the disk to be engraved would be mounted on the lower end of a short cylindrical rotor suspended electrostatically and would serve as the lower-end rotor electrode. Voltages applied to all the electrodes of the electrostatic suspension system would be determined by a feedback control subsystem that would sense the various capacitances between the end and side rotor and stator electrodes. Because these capacitances depend on the position and orienta-



Laser Pulses Timed According to the Rotational Speed of a rotor electrostatically suspended in a vacuum would mark an angular-encoder disk mounted on the lower end of the rotor. The precision of the timing circuitry and the low rotational damping (damping time about 700 years in a high vacuum) would result in highly-precise angular intervals.

tion of the rotor relative to the stator, the subsystem could process the capacitance signals to compensate for asymmetry in the rotor, seismicity, and other perturbations in such a way as to keep the axis of the rotor vertical and at the desired position.

The surface of the disk to be engraved would be coated with a noble metal. Focused laser beams would mark this surface by evaporating the metal at the designated spots. There would be two pairs of laser beams, arranged orthogonally to enable cancellation of the effects of devia-

tions of the lateral position of the rotor. For equal angular increments, the lasers would be pulsed periodically, at intervals of the fraction of the period of rotation corresponding to the desired increment of angle.

A corotating (but normally mechanically-separate) transparent disk below the disk to be engraved would collect the evaporated metal so that it does not accumulate on the laser-beam windows, where it would otherwise subsequently attenuate the laser beams. To bring the rotor up to the desired rate of rotation, the corotating

disk would initially be connected to the rotor via a piezoelectric or electromagnetic clutch, which would disengage when the rotor attains the desired speed.

The pressure of the metal vapor and the electric field in the interelectrode gaps must be kept below the levels that would trigger electrical arcs. Preferably, the voltages applied to the top and side electrodes would be balanced in such a way that the electric field at the bottom disk could be zero. Alternatively, the suspension voltages could be interrupted in synchronism with the laser pulses to prevent

arcing, but this would necessitate the careful avoidance of harmonics to prevent excessive vibrations.

This work was done by Walter K. Polstorff of Marshall Space Flight Center. For further information, Circle 119 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center [see page 14]. Refer to MFS-28294

Process for Patterning Dispenser-Cathode Surfaces

Microfabrication techniques increase uniformity.

NASA's Jet Propulsion Laboratory, Pasadena, California

Several microfabrication techniques have been combined into a process that cuts slots 100 μm long and 1 to 5 μm wide into tungsten dispenser cathodes for traveling-wave tubes. The slots enable a more-uniform low-work function coating to be dispensed to the electron-emitting surface. The emission of electrons therefore becomes more uniform over the cathode surface.

A molybdenum mandrel is coated by chemical-vapor deposition with a layer of tungsten 25 μm thick, followed by a layer of aluminum 5 μm thick. A layer of photoresist 1 μm thick is applied over the aluminum. Slots are cut in the photoresist by writing with a laser beam, electron beam, or ion beam, exposing parts of the underlying aluminum film (see Figure 1). The aluminum under the slots is etched away by chemically-assisted ion-beam etching, a process in which chlorine gas and a beam of xenon ions are directed into the slots in the photoresist (see Figure 2). The beam of ions enhances the chemical reactivity of the aluminum with the chlorine, forming a volatile product that is pumped away. The resulting pattern of slots in the aluminum, which is identical to the pattern in the photoresist, exposes the underlying tungsten.

Another chemically-assisted ion-beam etching step follows. Fluorine or chlorine trifluoride gas and a beam of xenon ions are directed at the exposed tungsten, etching slots into it. The aluminum acts as a mask because it reacts only slightly with either gas. If slots narrower than 1 μm are needed, the patterned cathode can be coated with more tungsten by chemical-vapor deposition to close partially the gaps between the walls of the slots.

This work was done by Charles E. Garner and William D. Deininger of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 137 on the TSP Request Card.
NPO-17183




Figure 1. The **Patterned Photoresist** serves as a mask for etching the underlying aluminum.




Figure 2. **Chemically-Assisted Ion-Beam Etching** with chlorine removes exposed parts of the aluminum layer (left). Chemically-assisted ion-beam etching with fluorine or chlorine trifluoride removes the tungsten not masked by the aluminum layer (right).

Deposition of Pinhole-Free CoSi₂ Film

A stoichiometric combination of cobalt and silicon is overlaid with silicon.

NASA's Jet Propulsion Laboratory, Pasadena, California

A new fabrication method produces a pinhole-free film of cobalt silicide on a silicon substrate. Earlier methods resulted in as many as 10^7 pinholes per square centimeter. The absence of pinholes is critical to the operation of multilayer devices employing CoSi₂ layers, such as the metal base transistor.

In the new method, cobalt and silicon are evaporated from electron-beam sources onto a substrate of silicon having a <111> crystal orientation. The materials are deposited in the stoichiometric ratio of two silicon atoms to one of cobalt, yielding a single-crystal CoSi₂ film 5 to 10 nm thick. A layer of amorphous silicon 1 to 2 nm thick is deposited on the CoSi₂. The specimen is then annealed at 550 °C for 10 min.

The amorphous-silicon cap prevents pinholes from forming during annealing. In the absence of this cap, apparently the high surface energy of CoSi₂ relative to Si causes the formation of pinholes, which expose the underlying Si surface and thereby reduce the total energy of the epitaxial system at temperatures above 500 °C. The silicon cap appears to reduce the total surface energy without the formation of pinholes. In fact, the temperature can be raised as high as 600 °C with the cap.

Because the CoSi₂ layer is stoichiometric, it does not consume the cap during annealing. Thus, the cap remains during the entire annealing process and is available to

serve as a template for further deposits of silicon during later processing.


Scanning electron microscopy and other techniques were used to evaluate the quality of the CoSi₂ films on both silicon-capped and uncapped substrates. The films were etched with carbon tetrafluoride plasma to enlarge pinholes for greater visibility; where a silicon cap layer covered a pinhole, it, too, was removed by the plasma. This procedure improved the detection resolution to 1,000 pinholes per square centimeter. No pinholes could be found on the capped film, whereas the uncapped film was riddled with pinholes (see figure).

This work was done by True-Lon Lin, Robert N. Fathauer, and Paula J. Grunthaler of Caltech for NASA's Jet Propulsion Laboratory. For further information, Circle 42 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

*Edward Ansell
Director of Patents and Licensing
Mail Stop 305-6
California Institute of Technology
1201 East California Boulevard
Pasadena, CA 91125*


Refer to NPO-17447, volume and number of this NASA Tech Briefs issue, and the page number.



The **Scanning Electron Micrograph** of a silicon-capped CoSi₂ film shows no pinholes, whereas that of an uncapped film shows many. The density of pinholes in the micrograph of the uncapped specimen is 2×10^7 cm⁻². Both the capped and uncapped specimens have been etched by CF₄ plasma to enhance the visibility of the pinholes.

NASA Tech Briefs, June 1989

Three Things You Shouldn't Have To Share At The Office



In the workplace you would never think of sharing your mug or chair. So why are you running down the hall to find out if there is a terminal available for your mainframe graphics applications? With TGRAF software and your desktop computer there's no reason to ever share a terminal; you can now have a powerful graphics terminal on your desk, inexpensively.

TGRAF accurately duplicates a Tektronix graphics terminal without sacrificing terminal functionality. Now mainframe graphics power is available for your PC, PS/2, Macintosh II, or workstation in RS-232 or networked computer environments, for only a fraction of what a terminal would cost.

TGRAF's comprehensive Tektronix terminal emulation and Grafpoint's superior customer support, puts the terminal sharing blues behind you forever. Call Grafpoint for the name of your local distributor and order a no-risk 30-day evaluation copy.

Current TGRAF users call us for information on how to upgrade to our latest product - TGRAF-4200



GRAFPOINT

1485 Saratoga Avenue
San Jose, CA 95129

1-800-426-2230

In California 408-446-1919

Grafpoint and TGRAF are trademarks of Grafpoint. PC and PS/2 are trademarks of International Business Machines Corporation. Tektronix is a trademark of Tektronix, Inc. Macintosh is a trademark of Apple Computer, Inc.

Fluidized-Bed Reactor With Zone Heating

Deposition of silicon on the wall is suppressed.

NASA's Jet Propulsion Laboratory, Pasadena, California

The design of a fluidized bed for production of silicon greatly reduces the tendency of silicon to deposit on the wall of the reaction vessel. In the new fluidized bed, the silicon seed particles are heated in the uppermost zone of the reactor. The hot particles gradually mix with the lower particles and descend through the fluidized bed. The lower wall of the vessel is kept relatively cool. Because silane that enters at the bottom and circulates through the reactor is pyrolyzed to silicon at high temperatures, silicon is therefore deposited on the particles in preference to the wall.


A typical previous fluidized bed, in contrast, was heated through the wall. Therefore, the wall was hotter than the reaction zone, and silicon was deposited on the wall as well as on the bed particles, reducing the net yield of silicon and creating a clean-up problem. Moreover, the high temperature in the lower layers of the bed favored the formation of fine silicon dust that had to be separated from the product particles and recovered.

In the new process, silicon seed particles are introduced into the base of the reactor vessel (see figure), where a stream of inert gas creates a fluidized bed of the particles extending almost to the top of the vessel. At the top of the bed, immersion heaters encased in quartz and wall heaters maintain a temperature of 650 to 800 °C. The turbulence of the bed mixes hot seed particles from the heating zone with particles in lower layers, the net result being a vertical gradient of temperature ranging down to 450 to 650 °C at the bottom of the bed. Wall heaters add only enough heat to make up for losses.

Silane flowing up from the base of the vessel decomposes in the reaction zone just below the heating zone, depositing silicon on the silicon seed particles but not on the wall. Essentially all the silane reacts in the reaction zone; it does not flow into the heating zone. Once a particle has grown to a size of 400 to 1,500 μm , the particle descends from the reaction zone through a separator to a collector.

Silane enters the vessel through a perforated distributor cone at the bottom. Water circulating in a coil around the distributor cone keeps it at a temperature of about 300 °C — low enough to suppress the deposition of silicon dust even though the silane is highly concentrated at this point in the reactor.

In a demonstration of the process, about 8 kW of power were supplied to the top 15 in. (38 cm), and 2 kW were supplied



The **Upper Heating Zone** furnishes about 80 percent of the heat for the pyrolysis of silane. The temperature in the reactor ranges from about 700 °C at its top to about 300 °C at the silane-gas distributor at its bottom. Polycrystalline silicon particles fall through the fluidized bed and are collected at the bottom.

to the remainder of a reactor 72 in. (183 cm) high and 6 in. (15.2 cm) in diameter. The reactor yielded 1 kg of silicon per hour. The ratio of this rate of yield to input power (0.1 g/Wh) is about 30 times that of a commonly-used batch process and may be higher than that of other fluidized-bed processes as well.

This work was done by Sridhar K. Iya of Union Carbide Corp. for NASA's Jet Pro-

pulsion Laboratory. For further information, Circle 107 on the TSP Request Card. NPO-17470

Is your subscription about to expire?

Check the expire date. If it is less than 6 months now is the time to fill out a new qualification form before your subscription expires.

Molecular-Beam Epitaxy of CrSi_2 on Si(111)

Crystalline layers have been grown in a commercial apparatus.

NASA's Jet Propulsion Laboratory, Pasadena, California

Experiments have shown that CrSi_2 can be grown on the (111) face of a single-crystal Si substrate by molecular-beam epitaxy. The epitaxial CrSi_2 produced thus far is not in the desired single-crystal form. However, because CrSi_2 is a semiconductor with a band gap of 0.3 eV, the experimental process has potential for the monolithic integration of microelectronic devices based on CrSi_2 (e.g., infrared detectors) with signal-processing circuitry based on Si.

In the experiments, Si(111) wafers were first cleaned chemically by a process that leaves a protective oxide on the surface. The wafers were then placed in a commercial molecular-beam epitaxy (MBE) apparatus, where the oxide was removed by a beam of Si in some cases or by thermal desorption in other cases.


The apparatus was equipped with separate electron-beam evaporators, one for Si and one for Cr. Each CrSi_2 specimen was grown by one of four techniques, each of which is a special case of generic MBE. In the first technique, called "solid-phase

reactive epitaxy" (SRE), Cr was deposited on a substrate of Si held at room temperature; the substrate and deposit were then annealed at a temperature of 580, 650, or 720 °C. In the second technique, called "reactive-deposition epitaxy" (RDE), Cr was deposited on a hot Si substrate. The third technique, called "solid-phase epitaxy" (SPE), involved the stoichiometric deposition of Cr and Si at room temperature, followed by annealing at higher temperature. In the fourth technique, denoted by the generic term "MBE," Cr and Si were codeposited stoichiometrically on a hot Si substrate.


CrSi_2 layers were grown to thicknesses of 10 and 210 nm (see figures). The specimens were monitored during growth by reflection high-energy electron diffraction (RHEED). After removal from the MBE apparatus, the specimens were analyzed by scanning electron microscopy (SEM), transmission electron microscopy (TEM), and Rutherford backscattering spectroscopy (RBS).

The analyses showed that the CrSi_2 layers tended to form islands, within each of which one of several crystalline orientations prevailed. The two most common orientations observed were $\text{CrSi}_2(0001)/\text{Si}(111)$ with $\text{CrSi}_2[10\bar{1}0]/\text{Si}[10\bar{1}]$ and $\text{CrSi}_2(0001)/\text{Si}(111)$ with $\text{CrSi}_2[11\bar{2}0]/\text{Si}[10\bar{1}]$. The two orientations differ in that the CrSi_2 layers are rotated about 30° with respect to each other about the perpendicular to the surface. For the thick layers, the MBE technique yielded the largest grains and best RHEED pattern. The sizes of the grains were found to increase with temperature: grains 1 to 2 μm across were observed in a layer deposited at 825 °C.

This work was done by Robert W. Fathauer, Paula J. Grunthaner, True-Lon Lin, and David N. Jamieson of Caltech and Jurek H. Mazur of USC for NASA's Jet Propulsion Laboratory. For further information, Circle 37 on the TSP Request Card. NPO-17438



(a)



(b)

Micrographs of CrSi_2 Layers show (a) cross-sectional TEM image of an island of CrSi_2 for a 10-nm layer grown by SRE. The insert shows the lattice image of a portion of the CrSi_2/Si interface. Part (b) is a planar TEM image of a 210-nm layer grown by MBE.

Waveform Processing For People Who Demand More

- ... More Dynamic Range,
- ... More Channels,
- ... Longer Record Lengths,
- ... No Programming,
- ... All for under \$4000!

Since 1982, ACROSYSTEMS' engineers have been solving the important issues involved in measuring physical parameters. We know, for instance, that struggling to find transients buried in noise demands a high resolution A/D converter.

That's why we developed the 14-bit, 1 MHz, AT-6400 Waveform Digitizer. Compatible with the IBM AT, PS/2 or compatibles, the AT-6400 delivers high performance and versatility, without the burden of a high price tag. Starting under \$4000, the AT-6400 provides:

- 14-bit resolution,
- 1 MHz digitizing rate,
- 8 million point waveform capture,
- Up to 8 input channels,
- Comprehensive triggering, and
- Ready to run applications software including SnapShot, Hypersignal, DADiSP, and more.

For more information, call our team of knowledgeable applications engineers at (508) 927-8880.


ACROSYSTEMS


Precision Measurement & Control Solutions

From DC to 1 MHz

ACROSYSTEMS, 66 Cherry Hill Drive

Beverly, MA 01915 (508) 927-8880





Mathematics and Information Sciences

Hardware Techniques, and Processes

98 Continuously-Variable Vernier Scale

98 Some Protocols for Optical-Fiber Digital Communications

99 Algorithm for Optimal Control of Large Structures

100 Ideal Resampling of Discrete Sequences

103 Design of Combined Stochastic Feedforward/Feedback Control

Books and Reports

103 Commercial Expert-System-Building Software Tools

103 Application of Artificial Intelligence to Wind Tunnels

Computer Programs

70 Data-Dictionary-Editing Program

70 AutoCAD-To-NASTRAN Translator Program

Continuously-Variable Vernier Scale

An easily fabricated device increases precision in reading graphical data.


Langley Research Center, Hampton, Virginia

The continuously-variable vernier scale (CVVS) is designed to provide greater accuracy to scientists and technologists in reading numerical values from graphical data. It is placed on the graph and used to interpolate the coordinate value of a point on a curve or a plotted point on a figure within a division on each coordinate axis.

A typical construction and use of the CVVS are shown in the figure. A baseline PQ is constructed of arbitrary length, but it should be about 10 times the distance to be interpolated. Next, the scale line QR is constructed perpendicular to PQ. For convenience, QR may be equal in length to PQ. Then, 10 equally spaced divisions are marked off on the scale line QR, and straight lines are drawn from P.

The CVVS is overlaid on a plotted curve as shown so that the two legs of the triangle, PQ and PR, span the division on the x axis that includes the projected intercept $x(a)$ of point (a). Note that this intercept falls between lines 4 and 5 of the geometric overlay. Therefore, $x(a)$ can be more closely estimated as 2.49 instead of 2.5. If the scale is then rotated by 90° and the above procedure is repeated for the appropriate division on the y axis, the y coordinate, $y(a)$, is more closely estimated as 2.76 instead of 2.8. To make it easier to line up the baseline with a coordinate axis and with the line that projects the point to one of the axes, faint lines can be drawn parallel to both axes.

The CVVS can also be used to interpolate a logarithmic scale if a logarithmic scale is constructed on the scale line. It can also be used to change the scale of a figure by changing the scale of the coordinate axes on that figure.



The CVVS in This Case is used to read the x and y coordinates of point (a) more precisely as 2.49 and 2.76, respectively.

For durability and clarity, the CVVS can be constructed on thin, clear, plastic material. It is a simple, inexpensive device that can readily meet the needs of scientists and technologists in making better estimates of points on plotted figures that are published in the literature. The CVVS requires neither the measurement of line segments where the projection of the point intersects a division nor a calculation to quantify the projected value. It is a very flexible device that can be constructed with any kind of scale. It is very easy to use, requiring no special equipment of any kind,

and can save a considerable amount of time if numerous points are to be evaluated.

This work was done by Irvin M. Miller of Langley Research Center. No further documentation is available.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Langley Research Center [see page 14]. Refer to LAR-13721.

Some Protocols for Optical-Fiber Digital Communications

One works best in heavy traffic; another, in light traffic.

NASA's Jet Propulsion Laboratory, Pasadena, California

Three protocols have been proposed for digital communications among stations


connected by passive taps to a pair of unidirectional optical-fiber buses. The proto-

cols mediate round-robin, bounded-delay access to the buses by all stations and are

particularly suited to fast transmission. Partly because the transmission medium is passive (there are no relay stations) and partly because the protocols distribute the control of the network among all stations with provision for the addition and deletion of stations (there are no control stations), the communication network should be able to resist and recover from failures.

The signals on the two buses travel in opposite directions. Each station includes a transmitter and receiver connected to both buses (see figure). When the receiver detects a carrier signal, it attempts to synchronize itself to the bits in the preamble of the incoming signal and to copy the signal into the memory of the station. Provided that the receiver detects no signal coming from upstream and/or has been granted access by the protocol, the transmitter sends a preamble followed by a packet of data. There is a delay between the time a station senses the end of a carrier on a bus and the time when it can start transmitting on the same bus. There is an equal delay between the sensing of a carrier coming from upstream and the interruption of a transmission. These functions are common to all unidirectional-bus systems but are managed in different ways by different protocols.

The first of these three protocols, called "U-Net," defines a procedure to determine which two stations are at the right and left ends of the bus and which should transmit a special sequence of bits called the "token." The network then operates in cycles that are initiated when the left-end or right-end station transmits the token. Each station downstream from the initiating end station waits for the token and any appended packets of data to pass by,



Traffic on the Twin Unidirectional Buses is managed by any of three protocols described in the text. Each has advantages and disadvantages, depending on the level of traffic and the number of stations attempting to transmit.

then transmits its own packet (if any). Thus, each station has an opportunity to add a packet of data to a train of packets headed by the token.

When traffic is light or only one station has data to send, the U-Net protocol wastes time by forcing the transmitting station to wait for the token and then to transmit only one packet at each pass. This disadvantage is overcome by a hybrid protocol that enforces a random-access mode when traffic is light or a single station is transmitting and reverts to an implicit-token mode when multiple-source traffic builds up. This protocol is called "Buzz-Net" because of a buzzing signal that any station transmits to synchronize the network and drive it to the token mode under certain conditions of increasing traffic.

While the Buzz-Net protocol is efficient at low traffic, it is less efficient than the U-Net protocol is at high traffic, where it

wastes time by repeatedly switching between the two modes. The "Token-less" protocol was introduced to obtain efficiency at high traffic, to reduce waiting at low traffic, and to eliminate special token-initialization procedures. As the name implies, this protocol does not involve an explicit token. Instead, it supports a round-robin access mode like that of U-Net, and the synchronizing event (implicit token) is the cessation of activity on one of the buses. The implicit token propagates in one direction on one bus and in the opposite direction on the other bus, thus minimizing the interval of silence between the end of one round and the beginning of the next.

This work was done by Cavour Yeh and Mario Gerla of the University of California for NASA's Jet Propulsion Laboratory. For further information, Circle 133 on the TSP Request Card. NPO-17333

Algorithm for Optimal Control of Large Structures

The cost of computation appears competitive with that of other methods.

NASA's Jet Propulsion Laboratory, Pasadena, California

An iterative algorithm has been derived for the numerical computation of optimal control of a linear system (e.g., a large, vibrating structure) of many degrees of freedom. The cost of the algorithm, as measured in terms of the number of computations required, is of the order of, or less than, the cost of prior algorithms applied to similar problems.

The problem is to compute the optimal control of forced response of a structure with n degrees of freedom that is identified in terms of a smaller number, r , of vibrational modes. The article begins with the Hamilton-Jacobi formulation of mechanics and the use of a quadratic cost functional. While the Hamilton-Jacobi approach has previously resulted in computational complexity that increased almost exponentially with n , the complexity can be reduced by

an alternative approach in which the quadratic cost functional is expressed in terms of the control variables only. This leads to the iterative solution of a second-order time-integral matrix Volterra equation of the second kind that contains the optimal control vector.

At each iteration, the matrix Volterra equation is integrated numerically by use of a trapezoidal integration scheme in which the control interval is discretized into s equally spaced intervals of time. The particular structure of the matrices can be exploited to reduce the number of computations and to enable the use of a Jacobi-type iterative solution. Some steps are common to all iterations and thus need to be executed only once.

Overall, the total number of computations required is of the order of

$$[4r(q_{\max} + r)ms + n^2]$$

where m is the number of control variables and q_{\max} is the number of iterations required for convergence. Although q_{\max} is not known a priori, the dominance of diagonal terms in one of the matrices at an intermediate step of the derivation suggests that q_{\max} should be of the order of 10. As a result, the algorithm appears to be competitive with other methods based on solutions to matrix Riccati equations, especially at large n .

This work was done by Moktar A. Salama and John A. Garba of Caltech and Senol Utku of Duke University for NASA's Jet Propulsion Laboratory. For further information, Circle 28 on the TSP Request Card. NPO-16983

Ideal Resampling of Discrete Sequences

Spectral information is preserved to the extent possible.

Ames Research Center, Moffett Field, California


A technique has been developed to shrink or expand a discrete input sequence of numbers into an output sequence in a manner that preserves the input spectrum up to the Nyquist limit of the smaller of the two sequences. In the case of expansion, the technique also prevents the introduction of spurious frequencies not present in the input. While the technique is applicable to many kinds of data sampled at regular intervals, it is particularly useful in the processing and enhancement of images, where the discrete sequences are spatially ordered sets of picture-element brightness values.

The problem is to change the input sequence of N numbers to an output sequence of M numbers. The first step of the solution is to take the discrete Fourier transform (DFT) of the input. The DFT is used to reconstruct a continuous, band-limited function containing the same spectrum as that of the input sequence. This is the function that one would observe upon low-pass filtering an input signal below the Nyquist frequency of the sequence (and taking half the amplitude at the Nyquist frequency) and is the function that yields the input sequence when sampled at the input times or positions.

The continuous function is low-pass filtered to eliminate frequencies (if any) above the Nyquist rate of an M -sample sequence. This can be done in the frequency domain by taking the product of the DFT and the filter frequency dependence, or in the time or space domain by convolution with a sinc function of frequency M . In the time or space domain, the filtered signal can be converted to the output sequence by sampling it at intervals of $1/M$. Alternatively, the filtered DFT can be convolved with a pulse-train DFT, then inverted to the time or space domain to yield the output sequence.

A two-dimensional array of numbers (e.g., image data) is treated by applying the technique to the two-dimensional DFT's of the rows and columns of picture elements. Similarly, third-order and higher-order arrays are treated via the applicable multidimensional DFT's. The technique might be used, for example, to expand an image array, increasing the number of picture elements to smooth out the grainy appearance of a few large picture elements. Alternatively, it might be used to decrease the number of picture elements (see figure).

If the third dimension of a three-dimensional array is time, the technique could be applied to create a slow-motion image sequence without the difficulty of recording



An Image Is Coarsened by resampling to reduce the number of picture elements while preserving as much as possible of the original image information.

rapidly, then playing back at low speed. The image would be recorded at the normal frame rate and played back at the lower frame rate. The technique would be used to generate intermediate images at small intervals between frames, thereby suppressing the appearance of jerky motion caused by the sudden jumps between frames at the low frame rate.

This work was done by Andrew B. Watson of **Ames Research Center**. Further information may be found in NASA TM-88202 [N88-19100], "Ideal Shrinking

and Expansion of Discrete Sequences."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Ames Research Center [see page 14]. Refer to ARC-11719.

Design of Combined Stochastic Feedforward/Feedback Control

Methodology accommodates a variety of control structures and design techniques.

Langley Research Center, Hampton, Virginia

A methodology for the design of combined stochastic feedforward/feedback control has been developed, and a digital automatic landing system has been designed by use of this approach. The main objective of a control law is to enable a plant to track a desired or commanded trajectory selected from a given class of trajectories as closely as possible in the presence of random and deterministic disturbances and despite uncertainties about the plant. The feedforward controller tries to track the desired or commanded trajectory, whereas the feedback controller tries to maintain the state of the plant near the desired trajectory. Modern control theory has concentrated more attention on the important feedback control problem, while the feedforward control problem has received less attention.

In the methodology for combined stochastic feedforward/feedback control, the main objectives of the feedforward and feedback control laws are seen clearly. The inclusion of error-integral feedback, dynamic compensation, rate-command control structure, and the like is an integral element of the methodology. Another advantage

of the methodology is the flexibility to develop a variety of techniques for the design of feedback control with arbitrary structures to obtain the feedback controller: These include stochastic output feedback, multiconfiguration control, decentralized control, or frequency and classical control methods.

A specific incremental implementation is recommended for the combined feedforward/feedback controller. Some advantages of this digital implementation are simplicity, elimination of the need for trim values, and avoidance of such problems as integrator windup. The closed-loop eigenvalues obtained in this implementation contain the designed closed-loop eigenvalues that would result if an incremental implementation were not used. It has been shown that when using an incremental implementation, it is advantageous to design the controller with as many integrators as the number of controls. The use of fewer integrators results in marginally stable eigenvalues of unity, while the use of more integrators constrains the placement of eigenvalues.

A digital automatic landing system for

the Advanced Transportation Operating System (ATOPS) research vehicle, a Boeing 737-100, has been designed by use of the stochastic-feedforward-controller and stochastic-output-feedback methodology. The control modes of the system include the capture and tracking of the localizer and glideslope, crab, decrab, and flare. By use of the recommended incremental implementation, the control laws have been simulated on a digital computer and connected with a nonlinear digital simulation of the aircraft and its systems.

This work was done by Nesim Halyo of Information and Control Systems, Inc., for Langley Research Center. Further information may be found in NASA CR-4078 [N87-25806], "A Combined Stochastic Feedforward and Feedback Control Design Methodology with Application to Autoland Design."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700.

LAR-13795

Books and Reports

These reports, studies, handbooks are available from NASA as Technical Support Packages (TSP's) when a Request Card number is cited; otherwise they are available from the National Technical Information Service.

Commercial Expert-System-Building Software Tools

Computer programming tools are described and compared according to their knowledge-representation approach, inference methods, user interfaces, functional applicability, and other criteria.

A report evaluates commercially-available expert-system-building tools in terms of their structures, representations of knowledge, inference mechanisms, interfaces with developers and end users, and capabilities of performing such functions as diagnosis and design. These software tools are the commercialized derivatives of artificial-intelligence systems developed by researchers at universities and research organizations. Reportedly, they reduce the time to develop an expert system by an

order of magnitude compared to that required with such traditional artificial development languages as LISP.

The core of an expert system consists of a knowledge base and an inference engine that operates on the knowledge base to develop a solution or response. In addition, the system needs an interface to the end user or to an array of sensors and effectors to communicate with the outside world. A tool to develop an expert system must also include a developer interface so that the requisite knowledge base can be developed, the end-user interface can be built, and special instructions can be given to the inference engine. Other important tool attributes include the computers on which they will run and their interfaces with other software and data bases.

A table lists 20 such tools, rating their attributes as strong, fair, programmable by the user, or having no capability in the various criteria. The following tools are rated: ART, KEE, Knowledge Craft, S.1, PICON, ENVISAGE, ES ENVIRONMENT/VM, PERSONAL CONSULTANT+, KES, NEXPERT, EXSYS 3.0, INSIGHT 2+, M.1, RULEMASTER 3.0, KDS, TIMM, ES/P, EXPERT EDGE, 1st Class, and OPS5. The report also briefly describes each of the tools, pointing out their distinctive features.

This work was done by William B. Gevarter of Ames Research Center. Fur-

ther information may be found in NASA TM-88331 [N87-28281/NSP], "The Nature and Evaluation of Commercial Expert System Building Tools: Revision 1."

Copies may be purchased [prepayment required] from the National Technical Information Service, Springfield, Virginia 22161, Telephone No. (703) 487-4650. Rush orders may be placed for an extra fee by calling (800) 336-4700.




Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Ames Research Center [see page 14]. Refer to ARC-11757.

Application of Artificial Intelligence to Wind Tunnels

Goals include data of better quality, increased productivity, and retention of expertise.

A report discusses the potential use of artificial-intelligence systems to manage the wind-tunnel test facilities at Ames Research Center. One of the goals of this program is to obtain experimental data of better quality and otherwise generally increase the productivity of the facilities. Another goal is to increase the efficiency

Look what they've done with our composite braiders.



Braiding. As an industrial process, it's as old as the hills. At the same time, when it comes to the fabrication of complex parts, braiding forms the basis of one of the most cost-efficient composite technologies available. As the single domestic supplier of composite braiders, Wardwell has both the experience and the knowledge base to employ composite braiding to your greatest advantage. You owe it to yourself to find out more. As you can see, you won't be the first.


Call
(401) 724-8800 for more
information, or write for
our current brochure.



Wardwell Braiding Machine Co., 1211 High Street, Central Falls, RI 02863

Circle Reader Action No. 396

SONEX. Your edge on excess noise.



The fact is, nothing kills noise better than SONEX. Its patented wedge helps absorb noise **four times better** than conventional materials. Perfect for any application. Call or write for a free brochure: 3800 Washington Ave. N., Minneapolis, MN 55412. (612) 521-3555

Call toll-free: 1-800-662-0032

illbruck

Circle Reader Action No. 466

and expertise of current personnel and to retain the expertise of former personnel. The third goal is to increase the effectiveness of management through the more efficient use of accumulated data.

The authors recommend the development of three major artificial-intelligence systems to achieve these goals. One would include expert subsystems that could be used in planning and conducting wind-tunnel tests; for advice and training in the understanding of the characteristics of wind tunnels, measuring instruments, and ancillary equipment; and to assist in setting up tests to meet various objectives and requirements.

This system would include what amounts to an interactive electronic instruction manual similar to some textual-information systems that are already commercially available. A pretest-intelligent-assistant subsystem would help engineers in the design of models and selection of instrumentation. A prototype subsystem to aid in the selection of strain-gauge balances to be inserted in models is described in an appendix. One subsystem would incorporate computational fluid dynamics to help in planning tests. Other subsystems include one to assess the quality of data during and after tests, one to correct for the effects of the walls of wind tunnels on experimental data, and one for training.


The second major artificial-intelligence system would guide the diagnosis, monitoring, and repair of equipment. By duplicating established techniques used by experienced technicians, one subsystem could spot emerging trouble early, thereby increasing productivity by preventing unnecessary damage and unnecessary repetition of tests. One subsystem would monitor sensors during tests for signs of malfunctions. Another subsystem would monitor wind-tunnel machinery.

The third major artificial-intelligence system would be an interactive system for the management of the data base of multi-year test statistics. This system would be used to improve schedules of operation and maintenance of tunnels and other equipment, the assignment of personnel, the distribution of electrical power, and the analysis of costs and productivity. Several commercial artificial-intelligence computer programs are discussed as possible candidates for this use.

This work was done by Ching F. Lo and Frank W. Steinle, Jr., of Ames Research Center. Further information may be found in AIAA paper 88-22141, "Application of Intelligence Systems to Wind Tunnel Test Facilities."

Copies may be purchased [prepayment required] from AIAA Technical Information Services, Library, 555 West 57th Street, New York, New York 10019, Telephone No. (212) 247-6500. ARC-12229

$y \sim \frac{36}{3} \frac{1}{3} \delta \cos(t) + \frac{\epsilon}{72} (-\cos(t) + 3 \cos(3t)) + \dots$
 $\text{control pitch thru } \vec{u}: \vec{y}' = A\vec{y} + B\vec{u}$
 $\text{TFM}_{1,1} = \frac{\alpha}{s^3 - 2s^2 + s - 2\alpha}$
 $\text{Matrix} \cdot t \Big|_{1,2} = \frac{6e^{5/2t}}{\sqrt{33}} \sinh\left(\frac{\sqrt{33}}{2}t\right) \text{ from Macsyma}$
 $-\pi' \left(\frac{v'}{r} + \sin(\Theta) \right) + \frac{1}{\partial r}$
 $+ PV' \left(\frac{2v'}{r} + v^2 \cot(\Theta) \right)$
 $+ V' \left(v' \frac{\partial p}{\partial r} + v^2 \frac{\partial p}{\partial \theta} + v^3 \frac{\partial p}{\partial \varphi} \right) + \text{VISCOUS TERM}$
 $|TFM_{ij}|$
 $\text{Fourier}|\sin(t)| \rightarrow \frac{2}{\pi} \left(1 - \sum_{n=1}^{\infty} \frac{(1+(-1)^n) \cos(nt)}{n^2-1} \right)$



Macsyma[®] the most powerful math software in the world of mainframes, *now on* *PC's.*



Circle Reader Action No. 524

Until now, if you wanted to combine symbolic and numerical analyses into a powerful approach to mathematical modeling, there was only one way to do it — MACSYMA and a big computer.

Now we've taken all the power, performance and productivity of MACSYMA and created a PC version, one that runs on any 386/DOS-based PC*.

So now you can perform complex symbolic, numerical, and graphical calculations automatically — in applications ranging from plasma physics to aeronautics, from economics to fluid mechanics and more — right at your desk. Such as differential and integral equations, Laplace and Fourier transforms, vector and tensor calculus. The same calculations that used to require mainframe performance.

There's one thing about MACSYMA that isn't complex — using it. In fact, using MACSYMA is so easy, you can get right to work using our On-line Help and Quick Reference Card — without even opening a book.

MACSYMA on a PC. As easy as π .
Call 1-800-MACSYMA (in
Massachusetts, 617-221-1250).

symbolics, Inc.
Computer Aided Mathematics Group
8 New England Executive Park East
Burlington, MA 01803 U.S.A.

MACSYMA is a registered trademark of Symbolics, Inc.
* 100% IBM compatibles.



Life Sciences

Hardware Techniques, and Processes
106 Automatic Sprout Grower

Automatic Sprout Grower

A compact unit nurtures growing seeds.

Lyndon B. Johnson Space Center, Houston, Texas

A self-contained seed-sprouting system provides an environment for sprouting seeds quickly and easily. Developed as a source of fresh vegetable material on short Space Shuttle flights, the kit offers advantages to home gardeners too. Apartment dwellers could use it for steady production of homegrown sprouts even though they have no garden space.

The system gives seeds all they need to sprout: water, good drainage, and plenty of air. Light, soil, and the containers for cultivating whole plants are unnecessary.

Seeds of various vegetables and field crops can be stored dry indefinitely, then placed in the system when needed. The seeds quickly grow five to seven times in weight and turn into what are essentially green vegetables. The vitamin contents increase dramatically, as do fiber contents. Fat and carbohydrate contents drop, while little protein is lost. Many of the inhibitors and toxicants of raw seeds are eliminated or reduced significantly.


The sprouting container is the standard 6-oz (0.18-L) package for dehydrated food and drink mixes in the Space Shuttle. About 4 g of dry alfalfa or radish seeds are vacuum-sealed in each cup, like freeze-dried foods. Sixteen cups are suspended in a tray (see figure). An air-and-water inlet tube links each cup to a system of tubes and solenoid valves that alternately furnish air and water and remove stale air. A peristaltic pump supplies water from a vinyl medical-fluid bag. A small diaphragm pump supplies and exhausts air. A small circuit board times the movements of the air and water.

The proper growth of sprouts, both on Earth and in the microgravity of outer space, depends on adequate aeration and just the right amount of water. In microgravity, the effect of excess water is magnified in that water clings to the germinating seeds through surface tension, impeding movement of oxygen to the seeds. To prevent the sprouts from drowning in this way, the system adds water at frequent intervals, providing only the moisture needed for immediate uptake and for the expansion of the sprouts during each interval. The kit also periodically deflates and rein-

flates the sealed cups to remove gaseous metabolic products and to supply fresh oxygen.

This work was done by Richard L. Sauer of Johnson Space Center and H. W.

Scheld and J. W. Magnuson of PhytoResource Research, Inc. For further information, Circle 108 on the TSP Request Card. MSC-21266



Sprouts Grow In Cups in a tray. Growth proceeds at room temperature with ordinary room air. The photograph shows details of the growth cup and newly sprouted seeds.

New Literature



Five LCR meters, three precision analyzers, and a 1 MHz part tester are spotlighted in a new **instrument catalog** from Wayne Kerr Inc., Woburn, MA. The free catalog features product specifications, a selection guide, and a "Terms and Techniques" section that illustrates methods used to test capacitors, resistors, and inductors.

Circle Reader Action Number 724.

The Inventor's Notebook offers an organized way to document an inventor's progress from first glimmer to the marketplace. Published by Nolo Press, Berkeley, CA, the soft-cover book features an extensive work diary and covers legal, financial, and marketing issues. Each chapter contains pages for record keeping, explanations of business concepts, and a bibliography of pertinent books.

Circle Reader Action Number 706.




Newport Electronics Inc., Santa Ana, CA, has produced a 12-page brochure highlighting the new 500 Series of **isolated, two-wire 4-20 mA transmitters**. The publication presents 12 transmitter models for RTD, thermocouple, millivolt, milliamp, and volts input. Included are specifications, ordering information, and applications data — which covers the fundamentals of two-wire 4-20 mA transmitters and the combination of a transmitter with digital panel meters in the same loop. The brochure also describes 13 complementary digital process meters.

Circle Reader Action Number 726.

DAIR Computer Systems, Palo Alto, CA, is offering a free **artificial intelligence software and services catalog**. Product highlights include: Chaos Manner, the first chaos exploration program for personal computers; Netwurkz, a neural network tutorial that illustrates an associative memory's operation; PL/D, a system language that combines the speed and control of assembly language with the ease of expression of a compiler; and Neurotape, a 16-hour video course in neural net methodology.

Circle Reader Action Number 722.




RF/IF/Microwave signal processing components from DC to 6 GHz are featured in a new 132-page handbook from Mini-Circuits, Brooklyn, NY. The handbook includes specifications and performance curves for power splitter/combiners, and also describes wideband products such as amplifiers, frequency mixers, high- and low-pass filters, frequency doublers, phase detectors, GaAs switches and drivers, RF transformers, and directional couplers.

Circle Reader Action Number 730.



"The Strategic Difference in Advanced Electronics," a new brochure from the General Electric Company's Silicone Products Division, Waterford, NY, illustrates the application of **silicone technology** to integrated circuits and power electronics. Featured products include silicone junction coatings, die coatings, and molding compounds for electronic packaging systems; and conformal coatings, solventless coatings, gels, encapsulants, and high-temperature adhesives for macroelectronic protection systems.

Circle Reader Action Number 716.



Optical power meters, attenuators, laser and LED sources, and T1 BER analyzers are featured in Intelco Corporation's 1989 catalog, as well as application articles describing bit error rate analysis, fiber optic attenuation, and optical margin measurement. Moreover, the 66-page handbook contains a glossary of fiber optic testing terminology.

Circle Reader Action Number 704.



A free **glossary of microcomputer data acquisition terms** is offered by the MetraByte Corporation, Taunton, MA. The publication includes nearly 300 definitions — from "absolute accuracy" to "zero power resistance" — encompassing data conversion, signal conditioning, and microcomputer systems and software.

Circle Reader Action Number 712.



The new **Connector Design Guide** from Brush Wellman's Alloy Division, Cleveland, OH, assesses the critical design factors and material properties that dictate contact performance, such as spring force, permanent set resistance, temperature rise, stress relaxation resistance, and fatigue. Design criteria are supported with material properties and performance data for common copper-based alloys. The guide includes sample applications to help the engineer apply material specifications to contact designs.

Circle Reader Action Number 710.

"Technology Management," a guide to the development, production, and marketing of new technology, is now available from the Clark Boardman Company, New York City. The 500-page reference book offers pointers on licensing strategies and management; explains antitrust laws and export control regulations; identifies government and university technology sources; and describes how to implement technology transfers. Included are case studies in licensing transactions and examples of licensing forms.

Circle Reader Action Number 720.



To help laboratory personnel choose the right equipment for their water purification needs, Labconco Corp., Kansas City, MO, has published a 12-page **guide that evaluates the effectiveness of various purification methods**. The free booklet also discusses water quality standards and contaminant testing, and includes a glossary and bibliography.

Circle Reader Action Number 714.



More than 150 separate **power supplies, programmable AC power sources, hi-pot testers, and electronic loads** are featured in a full-color brochure from Kikusui International Corp., Torrance, CA. A comparison chart details the operating characteristics of the various supply types, which include bench, dual-tracking, high-current, bi-polar, and burn-in switchers. The free brochure also covers systems applications, programming options, and burn-in testing.

Circle Reader Action Number 718.

A full-color brochure describes the **thermal spray coating services** offered by Sermatech International Inc., Limerick, PA. Sermatech's arsenal of coating technologies includes GATOR-GARD® high-energy plasma spray, conventional plasma spray, and flame-spray coating processes. The free brochure highlights applications to diesel engines, helicopters, missiles, oil field equipment, and computer manufacturing components.

Circle Reader Action Number 702.

There Are No Limits to Growth

when you read **21st CENTURY**
SCIENCE & TECHNOLOGY

Subscribe
now and
read about

■ Scientific optimism instead of hoaxes

The great diet-heart
scam
The Greenhouse
Effect is a hoax
The Big Bang is bunk
The world needs more
people

■ Cities on the Moon and Mars


Space-farming on the
Moon
To Mars in 2 days

■ Unlimited energy from fusion


The fusion-fission hybrid to
burn nuclear waste
Room-temperature fusion

■ Optical biophysics to extend life

Treating the AIDS virus as
an antenna
Was AIDS deliberately
created?
The tuning of living
processes



The magazine
that brings you
tomorrow's
technologies
today



Enclosed is:

- ☐ \$20 for 1 year
(6 issues)
U.S./Canada
☐ \$40 for 1 year
(foreign airmail)

Name _____

Address _____

City _____

State _____ Zip _____


Send check or money order
(U.S. currency only) to

21st Century,
Dept. T, P.O. Box 65473,
Washington, D.C. 20035

Gift cards available

Circle Reader Action No. 651

Check our price breaks . . . before your budget breaks



Competitive, Production-Quantity Prices for the Inorganic Chemical of Your Choice

CERAC's high purity, advanced inorganic chemicals come with very attractive price breaks for production-quantity lots. And you still get the same fast delivery and consistently high purity that you get with our small-quantity, R&D lots. We also give production-quantity discounts on sputtering targets and evaporation materials.

Contact CERAC for a free quote on your next inorganic materials order.

CERAC incorporated

P.O. Box 1178 • Milwaukee, WI 53201

Phone: 414-289-9800 • Fax: 414-289-9805 • Telex: RCA 286122

Circle Reader Action No. 416

New on the Market




PC MACSYMA™, a computer-aided mathematics software application package from Symbolics Inc., Burlington, MA, combines symbolic, numerical, and graphical methods for an automated approach to mathematical modeling. In addition to automating basic operations in algebra and calculus, the PC program performs advanced symbolic computations, such as solving differential and integral equations, computing Laplace and Fourier transforms, automating vector and tensor calculus, and generating finite difference equations. It also features powerful programming tools, including a debugger, compiler, and code generators for C, Fortran, and TeX.

Circle Reader Action Number 768.

Percept™, a CAD tool that identifies material incompatibilities and recommends design solutions, is available from Sendrian Resources, Newbury Park, CA. The software can also estimate polymeric material longevity as a function of service temperature. Program interface is provided by an interpreter "shell" that translates trade names to the nomenclature used by the data libraries — which encompass metals, plastics, elastomers, composites, ceramics, solvents, lubricants, process fluids, and fuels. Percept operates under DESQview presentation manager and runs on IBM PC/XT/AT and compatible computers.

Circle Reader Action Number 774.



The Stripall® thermal wire stripper from the HUB Material Company, Canton, MA, applies heat to remove insulation without nicking or deforming the conductor. Designed for electronic assembly to aerospace and Mil-Spec standards, the hand-held tool uses no external transformers or power supplies; its solid-state temperature control unit plugs directly into a receptacle. Stripall's alloy blades heat to 927 degrees Celsius in less than four seconds, and also cool instantly, eliminating the need for special racks or holding clips.

Circle Reader Action Number 770.



Spectra Diode Labs, San Jose, CA, has developed a 100 mW cw, diffraction-limited, single-mode laser diode suited for high-speed writing in laser printers or optical data storage systems. The GaAlAs device operates in the 820 to 860 nm range, with a spectral width of less than 10 MHz. Threshold current is 35 mA and operating current for 100 mW output is 170 mA. A modulation bandwidth of more than 2 GHz enables high data rates or multi-channel video signal transmission.

Circle Reader Action Number 776.

Scientific Concepts Inc., Marietta, GA, has created Microplots, a collection of sophisticated plotting routines for IBM PCs and compatibles. Starting with up to eight different plot modes, Microplots adds flexible scaling, annotation, color control, and more. The routines can manipulate ASCII data files for two- or three-dimensional displays. This file handling function allows sharing of data between the PC and mainframes, which paves the way for fast, low-cost image networking. Priced at \$149, Microplots can be controlled by a menu system, user programs, or batch files.

Circle Reader Action Number 772.




A new family of portable disk drives called Traveldisks has been introduced by Tradewinds Peripherals Inc., Pacoima, CA. Packaged in self-contained subsystems, the hard disk drives are small and rugged enough to carry in a briefcase. They connect via cable to laptop, Macintosh, and IBM PC/XT/AT computers, and can serve as primary, secondary, or high-speed backup devices. Up to four times faster than traditional backups, Traveldisks are available in capacities from 10 to 200 megabytes.

Circle Reader Action Number 766.

New on the Market

A family of **chip sets** that lowers the cost of fiber optic technology, making it economical for applications such as local area networking, military systems, and corporate data communications, has been introduced by the Signetics Company, Sunnyvale, CA. Priced at approximately 20 dollars per 1000, the HiFI (High-Performance Fiber Interface) chip sets use dense bipolar process techniques to achieve up to 100 megabits per second performance. They support LEDs of any wavelength and multi-mode optical fiber cable of any size. In addition, the receiver components can handle single-mode optical fiber.

Circle Reader Action Number 790.



A new **data acquisition system for Macintosh computers** called MacLab™ measures captured data, produces hard copies of oscilloscope tracings, compares waveforms, and stores data for later analysis. Manufactured by World Precision Instruments Inc., New Haven, CT, MacLab includes two applications: "Scope," emulating a single-channel storage oscilloscope, and "Chart," emulating a four-channel pen recorder. Both are compatible with other Macintosh software, allowing data to be transferred via the clipboard to graphics or spreadsheet programs. The hardware unit can be plugged into the modem port of any Macintosh with at least 512K RAM and two disk drives.

Circle Reader Action Number 792.

The MAX-FAX 9624, a **plug-in half card with both fax and modem capabilities**, is now available from Macronix Inc., San Jose, CA. Designed for IBM PC/XT/AT and compatible computers, the half card automatically distinguishes between incoming fax and data calls without interruption, captures text and graphics printer output from an application and sends it as a fax, and converts PC Paintbrush files to a fax-compatible format. MAX-FAX is supported by a menu-driven software package with such options as auto dial and answer, broadcast, message display and printing, and bulletin board capabilities.

Circle Reader Action Number 798.


The RGB/View™ display controller from RGB Technology, Berkeley, CA, allows text, data, and graphics to be integrated with real-time video on any high-resolution workstation display. The video appears as a window on the computer screen, and can be squeezed or expanded from 1/16 to full screen size. Windowing functions are controlled by front panel switches or via an RS-232 port. The controller supports workstations from Sun, Apollo, Silicon Graphics, IBM, DEC, Hewlett-Packard, Tektronix, and others.

Circle Reader Action Number 794.



Exrust, a concentrated chemical **rust remover** from Kano Laboratories Inc., Nashville, TN, quickly dissolves rust by neutralizing ferrous oxide. The product is offered in a variety of sizes, from a pint-size sample selling for \$4.50 up to a 55-gallon industrial container.


Circle Reader Action Number 800.




ALF Products Inc., Wheat Ridge, CO, has introduced the Quick Copy family of **portable disk duplicators**. The self-contained units can automatically copy an unlimited number of 5 1/4" and 3 1/2" disks, and can also be used to format blank disks. Quick Copy models handle IBM PC, Apple II, Macintosh 800K, Commodore, TRS-80, DEC Rainbow/RX-50, Atari, and Amiga disks.

Circle Reader Action Number 796.

NEW FREE 304 PAGE DATA ACQUISITION & CONTROL HANDBOOK FOR IBM PC/XT/AT, PS/2 AND COMPATIBLE COMPUTERS




- A/D BOARDS
- SIGNAL CONDITIONING
- COMMUNICATION
- INDUSTRIAL CONTROL
- PC INSTRUMENTS
- IMAGE ACQUISITION



***SEND TODAY FOR YOUR
FREE 304 PAGE METRABYTE**

DATA ACQUISITION & CONTROL HANDBOOK



440 Myles Standish Blvd., Taunton, MA 02780
(508) 880-3000 TLX: 503989 FAX: (508) 880-0179

Circle Reader Action No. 606

WE'VE PERFECTED A FEW NEW MOTORS-

STEPPER-SERVO TYPE

- Stainless steel construction or aluminum housing through bore techniques allow for perfect rotor alignment.
- ABEC 3 to ABEC 7 stainless steel bearings for Long Life
- Rugged gearheads with ratio ranges of 10:1 to 17,000:1
- Servo voltages from 5-220 VAC
- Class "H" temperature range to 220°C for wire and insulation
- Stepper voltage 28 VDC
- Precision AC • DC
- Inertially Damped Servo
- Computing Tachometers • Generators



HYSTERESIS SYNCHRONOUS

- Laser scanning and optical
- Speed stability makes A.C. Motors perfect for laser scanners and bar code readers
- Large flanges can be built for unique mounting requirements
- Shaft straightness .0001" TIR and perpendicularity to hub of .0001" TIR
- Speeds to 75,000 RPM
- Frequency ranges from 2.5 HZ to 1,600 HZ
- Dynamic balance of rotor is less than .0001" Oz./inch
- Long life applications from sizes 1" to 4" Diam.

TO YOUR SPEC.

We've built a reputation for fabricating custom components to the most demanding specs. Our Engineering Dept. offers over 1500 standard models intelligently designed for sophisticated motion control technology - whether in quality Long-Life Assemblies or ruggedly independent. There's no charge - just a call, a speedy quote, and a delivery date you'll be happy with.

FREE FULL LINE PRODUCTS CATALOG

Just call or write —

VERNITECH

Division of VERNITRON CORPORATION

300 MARCUS BLVD. • DEER PARK • NEW YORK 11729

516-586-5100

TWX 510-227-6079 • FAX 516-242-7940


Circle Reader Action No. 339

Optimize Filter Response to Fit Your Design Target!

COMTRAN® - Now on a PC*

- Designs filters with custom-shaped responses
- Magnitude, Phase, Zin, Zout, or combination
- Fits any precision response using available capacitor values (by recalculating resistors)
- Derives equivalent circuit from measured data
- Cuts opamp count in half (4 poles per opamp)
- Tolerance, Time Domain, Waveform Digitizing
- **FAST** — Less than 1 second per point typical

*Requires AT compatible w/ HP 82300B BASIC Language Processor card w/1 MB RAM, & HP 9122 floppy drive. This card adds HP Rocky Mountain BASIC, w/ HP-IB interface, to your PC. Lets your PC run HP 200/300 BASIC software. COMTRAN previously ran only on HP computers.



COMTRAN® Integrated Software

A Division of Jensen Transformers, Inc.

10735 BURBANK BOULEVARD, NORTH HOLLYWOOD, CA 91601
FAX (818) 763-4574 • PHONE (213) 876-0059

Circle Reader Action No. 480

MICROWATT COMPUTERS

Board-Level Microcomputers for Remote and Harsh Environments


- Ultralow power consumption.
- -40° to 85°C operating temperature range.
- Unregulated 8 to 18 VDC supply voltage.
- Compact size.
- Boards available include: CPU, analog I/O, digital I/O, communications and more.
- C-44 board-level systems provide tremendous system hardware and software flexibility.

QSI
CORPORATION

QSI Corporation
1740 Research Park Way
Logan, UT 84321
(801) 753-3657


Circle Reader Action No. 545

New on the Market



A precision spray system from Tridak, Brookfield, CT, handles small-volume jobs — from nanoliters to several milliliters. Fluids ranging in viscosity from solvents to heavy oils and paint are atomized pneumatically and propelled to substrates a maximum of 8 inches from the nozzle. Adaptable to many automatic syringe dispensers, the miniature spray system consists of the nozzle with a regulator and a dispensing unit.

Circle Reader Action Number 780.



IBIS Systems Inc., Westlake Village, CA, has introduced the TRIAD, a parallel-transfer disk storage subsystem for VME-based workstations and high-performance computer systems. TRIAD consists of a high-speed, 32-bit VMEbus controller that resides in the host; a 12-megabyte/second, 1-gigabyte capacity disk drive; and a software device driver for UNIX and other VMEbus environments. Applications include data storage for supercomputers and VME-based workstations, high-speed array and real-time image processing, graphics imaging for animation and training simulation, and other specialized industrial and military applications where high-speed I/O capabilities are needed.


Circle Reader Action Number 788.

DuraTool 250, the first in a family of prepreg composite tooling materials for high-temperature applications, is now available from Narmco Materials, a business unit of BASF Structural Materials Inc., Charlotte, NC. An epoxy, "B" staged resin system impregnated into carbon and glass fiber fabrics, DuraTool 250 cures at 93°C in five hours with final postcure at 190°C. Tool service performance is excellent up to 204°C, according to the manufacturer.

Circle Reader Action Number 786.

A free demonstration disk from Applied Computer Solutions Inc., St. Clair Shores, MI, provides an overview of the company's new VSA™ tolerance analysis program. The software tool is applied early in the design process to predict the amount of variation that will occur in an assembly due to fabrication methods and sequence, as well as to non-uniformity of parts. Model creation and analysis can be performed graphically using a mouse and pop-up menus. The demo disk runs on IBM PC-AT, PS/2, and compatible computers.

Circle Reader Action Number 782.



Engineers now can interface thousands of instruments to their Sun desktop workstations with the SCSi488/S, a new IEEE 488 interface package from IOTech Inc., Cleveland, OH. The product uses the SCSI port available on all Sun models, even those without slots or disk drives, to link engineers with instruments and laboratory peripherals compatible with the IEEE 488 bus. The SCSi488/S comes with a UNIX device driver that supports true multitasking. Programs can be written in any high-level language (such as C) that controls UNIX system services. IOTech is also offering a companion software package for waveform analysis and graphics on the Sun, DADISP, that permits users to bring data from IEEE instruments directly into windows for on-screen representation as waveforms.

Circle Reader Action Number 778.

A computer-automated fax delivery system that works with the PostScript DTP language has been introduced by Biscom Inc., North Billerica, MA. Designed to operate with a variety of minicomputer systems, the FAXCOM/Publisher generates and stores graphic fax images, acts as a PostScript controller for local printers, and supports multiple printer types and fonts. Interfaced to the host CPU via an RS-232C port, it can transmit PostScript files directly from any terminal to any Group III fax machine worldwide. The usual process of feeding hard copy into a fax machine is eliminated, as is the image degradation caused by the fax machine's optical scanning process.

Circle Reader Action Number 784.



Subject Index

A

ACCELEROMETERS

Airplane-acceleration display for low-gravity research page 38 LEW-14650

ACTUATORS

Thermal brushes for memory-metal actuators page 84 NPO-17068

ALFALFA

Automatic sprout grower page 106 MSC-21266

ALGORITHMS

Algorithm for optimal control of large structures page 99 NPO-16983

ALUMINUM GALLIUM ARSENIDES

Long-wavelength infrared detector page 48 NPO-17543

ANGLES (GEOMETRY)

Advanced engraving of angle-encoder disks page 93 MFS-28294

ARTIFICIAL INTELLIGENCE

Application of artificial intelligence to wind tunnels page 103 ARC-12229
Commercial expert-system-building software tools page 103 ARC-11757

ASHES

Energy-efficient, continuous-flow ash lockhopper page 83 NPO-16985

AUTOMATIC CONTROL

Passivity in analysis of robustness of a control system page 44 NPO-17589

B

BEARINGS

Ceramic bearings for gas-turbine engines page 85 LEW-14832

BRUSHES (ELECTRICAL CONTACTS)

Thermal brushes for memory-metal actuators page 84 NPO-17068

C

CALIBRATING

Automated heat-flux-calibration facility page 59 LEW-14724

CATHODES

Process for patterning dispenser-cathode surfaces page 94 NPO-17183

CERAMICS

Ceramic bearings for gas-turbine engines page 85 LEW-14832

CHIPS (MEMORY DEVICES)

Chip advancer for GPS receiver page 40 NPO-16996

CIRCUITS

Computer-aided engineering of cabling page 68 NPO-17391

CIRCULAR PLATES

Advanced engraving of angle-encoder disks page 93 MFS-28294

COAL UTILIZATION

Energy-efficient, continuous-flow ash lockhopper page 83 NPO-16985

COATINGS

Electrostatic spraying with conductive liquids page 88 MSC-21067

COBALT COMPOUNDS

Deposition of pinhole-free CoSi_2 film page 95 NPO-17447

COCKPITS

Pilot delays for three cockpit controllers page 47 ARC-11797

COMPOSITE MATERIALS

Attaching precise mirrors to lightweight supports page 90 NPO-17164

Quality evaluation by acousto-ultrasonic testing of composites page 81 LEW-14709

Resistance to delamination in composite materials page 66 LAR-13753

COMPRESSING

Dynamic-range compression for infrared imagery page 54 NPO-17140

COMPUTER AIDED DESIGN

Computer-aided engineering of cabling page 68 NPO-17391

COMPUTER SYSTEMS SIMULATION

Experimenting with multiprocessor simulator concepts page 44 LEW-14617

CONNECTORS

Improved vacuum-tight connector page 86 LEW-14720

CONTACT RESISTANCE

Strong, low-resistance bonds for AMTEC electrodes page 86 NPO-17161

CONTROL

Passivity in analysis of robustness of a control system page 44 NPO-17589

CONTROLLERS

Pilot delays for three cockpit controllers page 47 ARC-11797

COOLING SYSTEMS

Capillary-condenser-pumped heat-transfer loop page 75 MFS-26046

CORRECTION

Designing corrector optics page 70 GSC-13120

CORRELATORS

Counterrotator and correlator for GPS receivers page 34 NPO-16998

CRYSTAL GROWTH

Molecular-beam epitaxy of CrSi_2 on $\text{Si}(111)$ page 97 NPO-17438

CRYSTALLIZATION

Thermal analysis of reluctant glass formers page 50 MFS-28283

CURING

Differential curing in fiber/resin laminates page 89 MSC-21376

D

DATA BASE MANAGEMENT SYSTEMS

Data-dictionary-editing program page 70 MSC-21290

DATA PROCESSING

Ideal resampling of discrete sequences page 100 ARC-11719

DELAMINATING

Resistance to delamination in composite materials page 66 LAR-13753

DIRECT POWER GENERATORS

Advanced fuel-cell modules page 28 MSC-21338

DISPLAY DEVICES

Airplane-acceleration display for low-gravity research page 38 LEW-14650

DOWN-CONVERTERS

Counterrotator and correlator for GPS receivers page 34 NPO-16998

E

ELECTRIC BATTERIES

Advanced small rechargeable batteries page 32 NPO-17396

ELECTRIC IGNITION

Cleanly burning squib page 74 NPO-17112

ELECTRIC POWER SUPPLIES

High-performance power-semiconductor packages page 24 LEW-14618

ELECTRICAL ENGINEERING

Computer-aided engineering of cabling page 68 NPO-17391

ELECTRODES

Strong, low-resistance bonds for AMTEC electrodes page 86 NPO-17161

ELECTRON MICROSCOPY

Making durable specimens for electron microscope page 55 LEW-14755

ENGRAVING

Advanced engraving of angle-encoder disks page 93 MFS-28294

EQUATIONS OF STATE

Equation of state with temperature effects for compressed so page 56 LEW-14616

Isothermal equation of state for compressed solids page 55 LEW-14615

ETCHING

Process for patterning dispenser-cathode surfaces page 94 NPO-17183

EXPERT SYSTEMS

Application of artificial intelligence to wind tunnels page 103 ARC-12229

Commercial expert-system-building software tools page 103 ARC-11757

EYE DISEASES

Image-enhancement aid for the partially sighted page 36 NPO-17307

F

FABRICS

Electrostatic spraying with conductive liquids page 88 MSC-21067

FATIGUE LIFE

Effect of solidification speed on fatigue properties page 67 MFS-27215

FEEDBACK CONTROL

Absolute stability and hyperstability in Hilbert space page 45 NPO-17590

Design of combined stochastic feed-forward/feedback control page 103 LAR-13795

FEEDFORWARD CONTROL

Design of combined stochastic feed-forward/feedback control page 103 LAR-13795

FIBER COMPOSITES


Differential curing in fiber/resin laminates page 89 MSC-21376

WANT TO MEASURE MICRO-OHMS, MILLI-OHMS, OR EVEN NANO-OHMS?

We have high-performance, low-cost solutions for any low-resistance measurement problem.

- The rugged, easy-to-use, Model 510A Digital Micro-ohmmeter provides honest 1 micro-ohm resolution, 4½ digits, and a basic accuracy of 0.02%.
- Three measurement modes: SWITCHED DC cancels thermal errors. CONSTANT DC for inductive components. PULSED MODE for thermally sensitive devices.
- Dry-Circuit test mode, rugged 4-terminal Kelvin clips, and BCD outputs included.
- Accessories for every application including battery-pack, limits-comparator, computer interface, and resolution to 10 nano-ohms.

Money-back Guarantee: Try the 510A free for 30 days.



Cambridge Technology, Inc.


23 ELM STREET, WATERTOWN, MA 02172 U.S.A. (617) 923-1181

Circle Reader Action No. 411

AG Motorized Positioning Stages

AG's Hi-Precision X-Y Positioning Stages are available in 2", 4" and 6" standard travel models. They consist of two identical, specially designed AG Ball Slide assemblies mounted in tandem, driven by precision centrally located lead screws actuated by stepping motors. AG's exclusive tapered wedge pre-load adjusting feature completely eliminates backlash and play.

The X-Y or single axis stages are compact in design and may be mounted in any position. Custom applications are available to your specifications. Call or write for more information.



Smooth, accurate linear motion for instrumentation, product design, machine design and gaging devices.

All standard AG Hi-Precision Slides are available with either ball or crossed roller bearing ways in eight cross-sectional sizes and a travel range from ½ to 15 inches for a total of 62 models from stock.



AUTOMATION GAGES, INC.

850 Hudson Ave., Rochester, NY 14621 Dept. 245
PHONE 716-544-0400 • 800-922-0329

Circle Reader Action No. 433

Space-Age Vision Aids

(Continued from page 20)

chine vision systems.


"The technology we're working towards is so radically different than what's out there now," Rickman said, "that it's difficult to perceive what the long-term benefits will be or where the technology will stop. There's been speculation that this device could be an intermediate step towards performing implants in humans to replace damaged retinas, but there's no way to know yet. Right now, the possibilities are endless." □

Approximately 2.5 million Americans, many older than 65, suffer from low vision. Birth defects, injuries, and aging can cause low vision, but most cases are due to eye conditions that affect the retina, including:

Macular Degeneration. Deterioration of the macula, the center of the retina used for sharp focus, causes central vision loss and makes reading difficult. This disability affects 20 percent of those over 75.

Diabetic Retinopathy. Swelling and leakage of fluid in the center of

Where Vision Problems Strike



the retina brought on by diabetes can cause scar tissue to form, leading to loss of sight.

Macular Degeneration. Deterioration of the macula, the center of the retina used for sharp focus, causes central vision loss and makes reading difficult. This disability affects 20 percent of those over 75.

Diabetic Retinopathy. Swelling and leakage of fluid in the center of the retina brought on by diabetes can cause scar tissue to form, leading to loss of sight.


Glaucoma. Increased fluid pressure inside the eye damages the optic nerve, resulting in vision loss. Because peripheral or side vision usually is affected first, this disease sometimes is called "tunnel vision."

Retinitis Pigmentosa. In this hereditary condition, the retina progressively deteriorates, causing loss of peripheral vision.

Cataracts (the clouding of the lens), cornea infections, and detachment of the retina also can cause low vision. In addition to loss of central or side vision, low vision patients may lose their color eyesight, have difficulty adapting to bright and dim light, and suffer diminished focusing power.

Source: Johns Hopkins Wilmer Eye Institute

New! Collector's Edition Poster



Actual
Size:
42"
wide by
30"
high—
in full
color!

Only
\$8.95

Both artistic and educational, this beautifully illustrated full-color poster presents a cutaway view of the Space Shuttle that reveals its inner workings. Provides size, wingspan, weight, and thrust data. 42 by 30 inches. Folded.

Special introductory price only \$8.95 each!

BONUS: Order now and receive three prints for only \$23.95.

Please rush me _____ Space Shuttle posters.

I have enclosed \$ _____ plus \$2.50 for postage and handling.

Total enclosed: \$ _____ (New York residents add sales tax)

Name _____

Address _____

City _____ State _____ Zip _____

Send payment to: NASA Tech Briefs, Shuttle Poster Offer
41 East 42nd St., New York, NY 10017-5391

FIBER OPTICS
Some protocols for optical-fiber digital communications
page 98 NPO-17333

FINITE ELEMENT METHOD
AutoCAD-to-NASTRAN translator program
page 70 GSC-13217

FLOW EQUATIONS
Algorithm for solution of Navier-Stokes equations
page 72 LEW-14656

Calculating flows in turbomachine channels
page 76 LEW-14705

FLUID FLOW
Calculating flows in turbomachine channels
page 76 LEW-14705

Improved flow-controlling vortex generator
page 73 NPO-17277

FLUIDIZED BED PROCESSORS
Fluidized-bed reactor with zone heating
page 96 NPO-17470

FOAMS
Pourable foam insulation
page 66 MFS-27217

FOOD PRODUCTION (IN SPACE)
Automatic sprout grower
page 106 MSC-21266

FRACTURE MECHANICS
Resistance to delamination in composite materials
page 66 LAR-13753

FUEL CELLS
Advanced fuel-cell modules
page 28 MSC-21338

G
GALLIUM ARSENIDES
Monolithic III-V/silicon spatial light modulator
page 28 NPO-16919

GAS FLOW
Improved flow-controlling vortex generator
page 73 NPO-17277

GAS TURBINE ENGINES
Ceramic bearings for gas-turbine engines
page 85 LEW-14832

GEOPOTENTIAL
Computing geopotential perturbations
page 61 MSC-21281

GLASS
Thermal analysis of reluctant glass formers
page 50 MFS-28283

GLASS COATINGS
Glass coats for hot isostatic pressing
page 64 MFS-29501

GLOBAL POSITIONING SYSTEM
Chip advancer for GPS receiver
page 40 NPO-16996

Counterrotator and correlator for GPS receivers
page 34 NPO-16998

Reduced-dynamic technique for determination of orbits
page 79 NPO-17386

GRAPHS (CHARTS)
Continuously-variable vernier scale
page 98 LAR-13721

H
HEAT FLUX
Automated heat-flux-calibration facility
page 59 LEW-14724

HEAT TRANSFER
Capillary-condenser-pumped heat-transfer loop
page 75 MFS-26046

HIGH TEMPERATURE SUPERCONDUCTORS
Making a superconductive thin film
page 90 MFS-26093

HILBERT SPACE
Absolute stability and hyperstability in Hilbert space
page 45 NPO-17590

HOPPERS
Energy-efficient, continuous-flow ash lockhopper
page 83 NPO-16985

HOT PRESSING
Glass coats for hot isostatic pressing
page 64 MFS-29501

HOT-WIRE ANEMOMETERS
Accuracy of hot-wire anemometry in supersonic turbulence
page 80 ARC-11802

HYDROGEN OXYGEN FUEL CELLS
Advanced fuel-cell modules
page 28 MSC-21338

I
IMAGE ANALYSIS
Designing corrector optics
page 70 GSC-13120

IMAGE ENHANCEMENT
Image-enhancement aid for the partially sighted
page 36 NPO-17307

IMAGE PROCESSING
Ideal resampling of discrete sequences
page 100 ARC-11719

Three-dimensional robotic vision system
page 43 MFS-27191

IMPACT TESTS
Spring-blade impact tester
page 72 LAR-13749

INFORMATION MANAGEMENT
Data-dictionary-editing program
page 70 MSC-21290

INFRARED DETECTORS
Long-wavelength infrared detector
page 48 NPO-17543

INFRARED IMAGERY
Dynamic-range compression for infrared imagery
page 54 NPO-17140

INSULATION
Pourable foam insulation
page 66 MFS-27217

INTERPOLATION
Continuously-variable vernier scale
page 98 LAR-13721

ION BEAMS
Process for patterning dispenser-cathode surfaces
page 94 NPO-17183

ISOTHERMAL PROCESSES
Isothermal equation of state for compressed solids
page 55 LEW-14615

J
JOINTS (JUNCTIONS)
Improved vacuum-tight connector
page 86 LEW-14720

L
LAMINATES
Differential curing in fiber/resin laminates
page 89 MSC-21376

LIGHT MODULATION
Monolithic III-V/silicon spatial light modulator
page 28 NPO-16919

LINEAR SYSTEMS
Algorithm for optimal control of large structures
page 99 NPO-16983

LINKAGES
Structurally-tailorable, nonlinear, snap-through spring
page 77 LAR-13729

LIQUIDS
Standard method for radiation tests of liquids
page 48 NPO-16840

LITHIUM SULFUR BATTERIES
Advanced small rechargeable batteries
page 32 NPO-17396

LOADS (FORCES)
Structurally-tailorable, nonlinear, snap-through spring
page 77 LAR-13729

M
MANAGEMENT INFORMATION SYSTEMS
Data-dictionary-editing program
page 70 MSC-21290

MASERS
Ultra-stable superconducting-maser oscillator
page 22 NPO-17090

MASS SPECTROMETERS
Measuring transmission efficiencies of mass spectrometers
page 58 NPO-16989

METAL OXIDE SEMICONDUCTORS
Making durable specimens for electron microscope
page 55 LEW-14755

MIRRORS
Attaching precise mirrors to lightweight supports
page 90 NPO-17164

MOLECULAR BEAM EPITAXY
Molecular-beam epitaxy of CrSi₂ on Si(111)
page 97 NPO-17438

MULTIPROCESSING (COMPUTERS)
Experimenting with multiprocessor simulator concepts
page 44 LEW-14617

N
NASTRAN
AutoCAD-to-NASTRAN translator program
page 70 GSC-13217

NAVIER-STOKES EQUATION
Algorithm for solution of Navier-Stokes equations
page 72 LEW-14656

NICKEL ALLOYS
Effect of solidification speed on fatigue properties
page 67 MFS-27215

NONDESTRUCTIVE TESTS
Quality evaluation by acousto-ultrasonic testing of composites
page 81 LEW-14709

NUMERICAL ANALYSIS
Continuously-variable vernier scale
page 98 LAR-13721

NYQUIST FREQUENCIES
Ideal resampling of discrete sequences
page 100 ARC-11719

O
OPTICAL CORRECTION PROCEDURE
Designing corrector optics
page 70 GSC-13120

NAG

Numerical Algorithms Group


NAG Fortran Library products enable you to spend your time and talents on genuine problem solving, not software development. 200 experts, recognized worldwide as the leaders in their fields, create the solutions in the NAG Library. The accuracy, performance, and total capabilities of NAG software are unmatched in the industry. Take advantage of NAG's expertise in any of these fine products:

NAG FORTRAN LIBRARY

More than 700 user-level routines covering the principal areas of mathematics and statistics. Available on over 90 different computers from PC's to supercomputers.

NAG GRAPHICAL SUPPLEMENT

A convenient and versatile means for displaying numerical results generated by the Library. A facility not available with other libraries.



NAG ONLINE SUPPLEMENT

An interactive query system enabling the user to make maximum use of the NAG Library. The Online system provides hints on choice of routines, syntax assistance, and other forms of help.

NAG VECPAR 77

An interactive CASE tool for vectorizing and parallelizing Fortran programs. Attain performance improvements beyond what optimizing compilers may provide. Ideal for "rejuvenating" older applications.

NAG Ada Library

The first commercially available math library designed and written completely in Ada. Shortens the development cycle for embedded math operations in Ada programs.

GENSTAT and GLIM

Interactive statistical analysis systems used for data exploration, linear modelling, time series analysis...useful applications in statistical quality control and product survival analysis.

THE NAG PRODUCT LINE OFFERS
NUMERICAL AND GRAPHICAL ALGORITHMS
FOR MANY SCIENTIFIC AND ENGINEERING
APPLICATIONS INCLUDING:

- SIGNAL PROCESSING
- OPERATIONS RESEARCH
- APPLICATIONS DEVELOPMENT
- COMPUTATIONAL CHEMISTRY
- ECONOMETRIC MODELS
- STATISTICAL ANALYSIS

OPTICAL EQUIPMENT

Attaching precise mirrors to lightweight supports
page 90 NPO-17164

OPTIMAL CONTROL

Algorithm for optimal control of large structures
page 99 NPO-16983

ORBIT PERTURBATION

Computing geopotential perturbations
page 61 MSC-21281

ORBITAL POSITION ESTIMATION

Reduced-dynamic technique for determination of orbits
page 79 NPO-17386

OSCILLATORS

Ultra-stable superconducting-maser oscillator
page 22 NPO-17090

P

PARALLEL PROCESSING (COMPUTERS)

Experimenting with multiprocessor simulator concepts
page 44 LEW-14617

PHOTODIODES

Monolithic III-V/silicon spatial light modulator
page 28 NPO-16919

PILOT PERFORMANCE

Pilot delays for three cockpit controllers
page 47 ARC-11797

PIPES (TUBES)

Robot hand grips cylinders securely
page 82 MSC-21365

POLYURETHANE FOAM

Pourable foam insulation
page 66 MFS-27247

PROTECTIVE COATINGS

Glass coats for hot isostatic pressing
page 64 MFS-29501

PROTOCOL (COMPUTERS)

Some protocols for optical-fiber digital communications
page 98 NPO-17333

PULSE

Communication Some protocols for optical-fiber digital communications
page 98 NPO-17333

PYROLYSIS

Fluidized-bed reactor with zone heating
page 96 NPO-17470

PYROTECHNICS

Cleanly burning squib
page 74 NPO-17112

Q

QUANTUM WELLS

Long-wavelength infrared detector
page 48 NPO-17543

R

RADIATION COUNTERS

Measuring transmission efficiencies of mass spectrometers
page 58 NPO-16989

RADIATION DAMAGE

Stabilizing semiconductor devices with hydrogen
page 30 NPO-17187

RADIATION EFFECTS

Asymmetrical SRAM cells for radiation tests
page 26 NPO-16890

Standard method for radiation tests of liquids
page 48 NPO-16840

RANDOM ACCESS

MEMORY

Asymmetrical SRAM cells for radiation tests
page 26 NPO-16890

RECEIVERS

Chip advancer for GPS receiver
page 40 NPO-16996

REDUCED GRAVITY

Airplane-acceleration display for low-gravity research
page 38 LEW-14650

REFRACTIVITY

Dynamic-range compression for infrared imagery
page 54 NPO-17140

REMOTE MANIPULATOR SYSTEM

Robot hand grips cylinders securely
page 82 MSC-21365

ROBOTICS

Robot hand grips cylinders securely
page 82 MSC-21365

Three-dimensional robotic vision system
page 43 MFS-27191

ROBUSTNESS (MATHEMATICS)

Passivity in analysis of robustness of a control system
page 44 NPO-17589

S

SATELLITE ORBITS

Reduced-dynamic technique for determination of orbits
page 79 NPO-17386

SATELLITE PERTURBATION

Computing geopotential perturbations
page 61 MSC-21281

SEEDS

Automatic sprout grower
page 106 MSC-21266

SEMICONDUCTOR DEVICES

High-performance power-semiconductor packages
page 24 LEW-14818

Stabilizing semiconductor devices with hydrogen
page 30 NPO-17187

SILICIDES

Deposition of pinhole-free CoSi_2 film
page 95 NPO-17447

Molecular-beam epitaxy of CrSi_2 on $\text{Si}(111)$
page 97 NPO-17438

SILICON

Fluidized-bed reactor with zone heating
page 96 NPO-17470

SINGLE EVENT UPSETS

Asymmetrical SRAM cells for radiation tests
page 26 NPO-16890

SOFTWARE TOOLS

Commercial expert-system-building software tools
page 103 ARC-11757

SOLID STATE DEVICES

Stabilizing semiconductor devices with hydrogen
page 30 NPO-17187

SOLIDIFICATION

Effect of solidification speed on fatigue properties
page 67 MFS-27215

SOLIDS

Equation of state with temperature effects for compressed solids
page 56 LEW-14616

Isothermal equation of state for compressed solids
page 55 LEW-14615

SPACE SHUTTLES

Thermal stresses in Space-Shuttle wing
page 79 ARC-12139

SPECIMENS

Making durable specimens for electron microscope
page 55 LEW-14755

SPRAYING

Electrostatic spraying with conductive liquids
page 88 MSC-21067

SPRINGS (ELASTIC)

Spring-blade impact tester
page 72 LAR-13749

Structurally-tailorable, nonlinear, snap-through spring
page 77 LAR-13729

SQUIBS

Cleanly burning squib
page 74 NPO-17112

SQUID (DETECTORS)

Ultra-stable superconducting-maser oscillator
page 22 NPO-17090

STABILITY

Absolute stability and hyperstability in Hilbert space
page 45 NPO-17590

STOCHASTIC PROCESSES

Design of combined stochastic feed-forward/feedback control
page 103 LAR-13795

STORAGE BATTERIES

Advanced small rechargeable batteries
page 32 NPO-17396

STRUTS

Spring-blade impact tester
page 72 LAR-13749

SUPERCONDUCTORS

Making a superconductor thin film
page 90 MFS-26093

SUPERSONIC BOUNDARY LAYER

Accuracy of hot-wire anemometry in supersonic turbulence
page 60 ARC-11802

T

TEMPERATURE CONTROL

Capillary-condenser-pumped heat-transfer loop
page 75 MFS-28046

TEMPERATURE EFFECTS

Thermal stresses in Space-Shuttle wing
page 79 ARC-12139

TEST EQUIPMENT

Standard method for radiation tests of liquids
page 48 NPO-16840

TEST FACILITIES

Automated heat-flux-calibration facility
page 59 LEW-14724

THERMAL STRESSES

Thermal stresses in Space-Shuttle wing
page 79 ARC-12139

THERMODYNAMIC PROPERTIES

Equation of state with temperature effects for compressed solids
page 56 LEW-14616


THERMOELECTRIC GENERATORS

Thermal brushes for memory-metal actuators
page 84 NPO-17068

THERMOELECTRIC POWER GENERATION

Strong, low-resistance bonds for AMTEC electrodes
page 86 NPO-17161

Vacuum Pump Vibration Isolator



NEC

Vibration

Isolators effectively remove turbo-molecular and cryo pump vibrations.

Available in elastomer and air-isolated versions, they are UHV compatible, have short insertion

lengths and high conductance. A wide variety of flanges are available.



National Electrostatics Corporation

Graber Road, Box 310

Middleton, WI 53562

Tel. 608/831-7600 • Telex 26-5430

Fax 608/256-4103

Circle Reader Action No. 591

ORDER THE TOP SPACE VIDEO NOW!



Aviation Week Video's SPACE SHUTTLE—THE RECOVERY has been chosen by the National Space Club for its prestigious *National Press Award* for 1989! This brilliant video gives you the inside story on America's triumphant return to space. Spectacular live action footage. Special computer animation. Interviews with designers and astronauts. The gripping story of the Challenger disaster. And a marvelous pictorial record of Discovery's historical flight. Only \$49.95—plus \$3.50 postage and handling. Please add applicable sales tax. Don't miss it!

Name _____


Address _____

Format: ☐ VHS ☐ Beta City _____ State _____ Zip _____

Total enclosed \$ _____. Please send me _____ copies of "Space Shuttle—The Recovery."

Send a check or money order to: Aviation Week Video, McGraw-Hill Aerospace and Defense Group, P.O. Box 308, Mt. Olive, New Jersey 07828 OR CALL 1-800-433-0880 to charge your Visa, Diner's Club, American Express, or MasterCard. B080

Circle Reader Action No. 310



Reliable, Affordable
CAD Peripherals
from Houston Instrument

Now you can buy full-size drafting plotters from an industry leader at prices as low as \$3,295.

Call for our complete guide to plotters, scanners, and graphics digitizers.

1-800-444-3425

512-835-0900



HOUSTON INSTRUMENT
A DIVISION OF AMETEK

Circle Reader Action No. 550

THIN FILMS
Deposition of pinhole-free CoSi_2 film
page 95 NPO-17447

Making a superconductive thin film
page 90 MFS-26093

TRANSISTORS
High-performance power-semiconductor packages
page 24 LEW-14818

TRANSLATING
AutoCAD-to-NASTRAN translator program
page 70 GSC-13217

TRANSMISSION EFFICIENCY
Measuring transmission efficiencies of mass spectrometers
page 58 NPO-18989

TURBOMACHINERY
Calculating flows in turbomachine channels
page 76 LEW-14705

TURBULENT BOUNDARY LAYER
Accuracy of hot-wire anemometry in supersonic turbulence
page 60 ARC-11802

TWO DIMENSIONAL FLOW
Algorithm for solution of Navier-Stokes equations
page 72 LEW-14856

U
ULTRASONIC TESTS
Quality evaluation by acousto-ultrasonic testing of composites
page 81 LEW-14709

V
VACUUM
Improved vacuum-tight connector
page 86 LEW-14720

VISION
Image-enhancement aid for the partially sighted
page 36 NPO-17307

Three-dimensional robotic vision system
page 43 MFS-27191

VITRIFICATION
Thermal analysis of reluctant glass formers
page 50 MFS-28283

VORTEX GENERATORS
Improved flow-controlling vortex generator
page 73 NPO-17277

W
WIND TUNNELS
Application of artificial intelligence to wind tunnels
page 103 ARC-12229

Classifieds

Classified advertising rates and specifications are as follows: Set in 6 point light type face, with up to five words at beginning of copy in bold caps. Count box numbers as six words.

50 words or less \$ 180
100 words \$ 250

Check or money order must accompany order to: Classified Advertising Manager, NASA Tech Briefs, Suite 921, 41 East 42nd Street, New York, NY 10017-5391.

ELECTRONIC COMPONENTS — Make Mouser Electronics your factory-authorized source for over 80 electronic component manufacturers. The FREE Mouser catalog offers 17,000 items stocked in depth including capacitors, resistors, relays, connectors, potentiometers, transformers, lamps, switches, semiconductors, soldering equipment and more. Mouser Electronics, Box 699, Mansfield, TX 76063. 1-800-992-9943.

NTB:BASE Offers

NTB:BASE 12,000+ Solutions
from NASA Tech Briefs

In minutes you can search 25 years of NASA Tech Briefs to find innovations related to your current project. NASA may have already found a solution or may suggest other ways of resolving the problem. On the way to space NASA has had to solve thousands of problems in all engineering fields under the most extreme conditions. Put that wealth of technology to work for you.

• **PC-Compatible database.** Can be used on IBM PC/XT/AT or compatible with 256k-memory, DOS 2.0, double-sided disk drive.
• **Subscription cost**—each category cost only \$100.00. All six for \$500.00. Annual updates \$20.00 per category or \$100.00 for all six.

Enclosed is check for \$_____ for the following categories:

<input type="checkbox"/> A Electronics	<input type="checkbox"/> E Fabrication Technology
<input type="checkbox"/> B Physical Sciences	<input type="checkbox"/> F 3-in-1 (Mathematics & Information Sciences, Life Sciences and Computer Programs)
<input type="checkbox"/> C Mechanics	
<input type="checkbox"/> D Materials	
<input type="checkbox"/> * ALL CATEGORIES	

Format: ☐ 360K or ☐ 1.2M

Name _____
Company _____
Address _____
City _____ State _____ Zip _____
Phone _____ ☐ Request more information

NTBM Research Center
41 East 42nd St., NY, NY 10017-5391
212/490-3999

NTB:BASE
from NASA Tech Briefs


LIGHT MEASUREMENT

SYSTEMS


Radiometers



Spectro Radiometers



Photometers



Laser Power Meters



Integrating Spheres



APPLICATIONS

- COLORIMETRY
- LASER POWER
- PHOTOMETRY
- PHOTORESIST
- PHOTOTHERAPY
- RADIOMETRY
- TRANSMISSION REFLECTANCE
- UV CURING
- UV HAZARDS

Ask for All New
Light Measurement Catalog

international light inc
Specialists in Light Measurement

DEXTER INDUSTRIAL GREEN, NEWBURYPORT, MASS. 01950
TEL 617 465-5923 TELEX 94-7135
Write for name of sales representative in your area (over 40 countries worldwide).

Circle Reader Action No. 645

A Scientific MIRACLE...

and a
Work
Of
Art

EcoSphere

The world's first totally enclosed ecosystem. Originally developed by NASA, EcoSpheres are not only prototypes of future space colonies, but also elegant reminders of the potential for ecological balance on Earth. This carefree aquarium — a permanently sealed glass globe — contains live shrimp, algae, water, and air in bioregenerated balance. \$79.00 each plus shipping.

Rush me _____ EcoSpheres at \$79.00 each plus \$12.00 for overnight delivery. Total enclosed: \$_____


Name _____

Address _____

City _____ State _____ Zip _____

Mail with payment to: NASA Tech Briefs, Dept. F
41 East 42nd Street, New York, NY 10017

DIAMOND



WORKSTATION TRACKBALL

- low cost, compact, all-in-one unit
- direct plug-in replacement for all popular "mice"
- RS232 serial trans/rec lines, selective baud rate, dynamic resolution
- direct replacement units for **SUN, DEC, MASS-COMP, CAL-COMP, PCs, ATs, XTs** (IBM or compatibles)


Evergreen
SYSTEMS INTERNATIONAL
31336 Via Colinas
Westlake Village, CA 91362
(818) 991-7835 • Fax: (818) 991-4036

Circle Reader Action No. 573

Pressure, Flow & Temp. Switch

RELIABILITY

Specify Hydra-Electric



If you have special requirements, we can probably save you time and money by satisfying them with one of our standard models. They maintain their accuracy over many thousands of cycles. The "snap-action" disk spring eliminates most problems of aerospace pressure switches.

Ask for your copy of the H-E catalog.

Hydra-Electric Co.
3151 Kenwood St., Burbank, CA 91505
(213) 843-6211

Circle Reader Action No. 427

HPIB/RS-232 Intelligent Interfaces



Time savers... HP 9000/PC professional...


- Buffers, HPIB & RS232 • HP 200/300 Memory Boards
- HPIB--Centronics Converters • IEEE 488/PC Interface Cards...

All backed with a full ONE YEAR WARRANTY & 30 DAY MONEY BACK GUARANTEE!

call 800-842-0888

INTELLIGENT INTERFACES Inc.
P.O. Box 1486 • Stone Mountain, GA 30086

Circle Reader Action No. 679



41 STANDARD PACKAGES FOR TEMPERATURE ASSEMBLIES.

Specify your temperature probe assembly from 41 packages, 12 lead materials, 9 thread sizes, 6 assembly materials, 11 connectors, and 58 thermistors. All standard. If these don't meet your needs, we'll make a custom probe from your drawing. Send for our catalog. Or call toll-free, 800 343-4357 (513 767-7241).

YSI Incorporated
Yellow Springs, Ohio 45387 USA

Circle Reader Action No. 681



HOW TO PROTECT YOUR COMPUTER And Make It Last Longer

FREE money-saving literature. What you need to know about UPS — uninterruptible power systems. How to get complete protection from power line problems. 350VA through 15KVA models from the world's largest manufacturer of single-phase UPS. Best Power Technology, Inc. P.O. Box 280, Necedah, WI 54646
(608) 565-7200 ext. 3657
Toll Free (800) 356-5794 ext. 3657

Circle Reader Action No. 370

MIL-STD-45662A

calibration system requirements video training program

Partial list of topics:

- * System Survey & Audit
- * Calibration System Requirements
- * Revision "A" Changes
- * Significance of Revision "A"
- * Standard Procedures
- * Traceability
- * Calibration System Description
- * Adequacy of Calibration System
- * Measurement Standards
- * Measuring and Test Equipment

TWO HOUR VIDEO TRAINING PROGRAM AND REFERENCE MANUAL



FEDERAL PROCUREMENT SERVICES
a Division of Midwest Marketing Services
810 EAST STATE STREET
ROCKFORD, IL 61104
(800) 833-3776

Circle Reader Action 447

Software Version Control

PVCS™ (POLYTRON Version Control System) is the market leader in version control software. It helps you get control of development without spending all your time on tedious details. PVCS is available on multiple development platforms and supports heterogeneous networks. MS-DOS, MacMPW: Personal PVCS: \$149. Corporate PVCS: \$395. Network PVCS: \$1,284 5 User. PVCS packaged with PolyMake on OS/2, SunOS and VAX/VMS. OS/2: \$695. SunOS: \$795. VAX/VMS: \$995.

30 Day Money Back Guarantee

To Order: 1-800-547-4000 Dept. NTB
POLYTRON Corp., 1700 NW 167th Pl., Beaverton, OR 97006 (503) 645-1150, FAX (503) 645-4576, TELEX 325800 POLYTRON

POLYTRON
High Quality Software Since 1982

Circle Reader Action No. 458




FREE!
130
Page
Catalog

"Optics for Industry"

Free 130 page product catalog from Roly, world's largest supplier of "Off-the-Shelf" optics. 24-hour delivery of simple or compound lenses, filters, prisms, mirrors, beamsplitters, reticles, objectives, eyepieces plus thousands of other stock items. Roly also supplies custom products and coatings in prototype or production quantities. **ROLYN OPTICS Co.**, 706 Arrowgrand Circle, Covina, CA 91722-2199, (818) 915-5707, FAX (818) 915-1379

Circle Reader Action No. 551

Tachion-I™



The new high-speed CAMAC data acquisition and recording system with:

- up to 9.6 Mbyte/sec throughput to disk
- data storage from 200 Mbytes to 56 Gbytes
- up to 1280 analog channels per subsystem
- sampling rates to 100 KHz per channel
- all-digital recording for repeatable accuracy
- real-time monitoring of selected channels
- interfaces for ARINC-429 and MIL-STD-1553

Call us today!

KineticSystems Corporation
11 Maryknoll Drive, Lockport, Illinois 60441 (815) 838 0005

Circle Reader Action No. 324

Mission Accomplished

Borrowing a design tool from the Space Shuttle program, scientists at NASA's Ames Research Center have created a computer model of the blood flow through an artificial heart. The three-dimensional simulation will help medical researchers to better understand the heart's complex flow field and should lead to improved pump designs.


"Many of the present problems with artificial hearts are directly attributable to the fluid dynamics of the blood flow," said Dr. Stuart Rogers, an Ames research scientist. Embedded regions of turbulent flow can damage the red blood cells, he explained, while flow trapped in corners of the heart can breed clots that cause strokes.

"With increased knowledge of the fluid behavior," said Dr. Paul Kutler, Chief of Ames' Fluid Dynamics Division, "artificial heart manufacturers will be able to suggest configuration changes to improve the flow quality."

The NASA model applies a simulation technique called computational fluid dynamics (CFD). Originally developed to track fluid motion inside components of the Space Shuttle main engine, CFD involves the solution on supercomputers of complicated mathematical equations describing flow behavior. CFD solutions are "information rich," Kutler said, and offer the design engineer a complete picture of the given flow field. Moreover, geometry changes are performed easily in the computer, saving time and money in the design process.

Ames scientists, building on an existing 3D flow code used in aerospace and automotive research, created a time-accurate algorithm to predict the unsteady flow path and constructed geometry definition and grid generation packages that emulate the mechanical heart's pumping motion. Although the simulation of a single heartbeat requires four hours of data processing on a Cray 2 supercomputer, it provides otherwise unobtainable information. Kutler's group is working to speed up the

(Photo courtesy NASA)



calculations by refining the algorithm.

The CFD tool, now used to recreate the incompressible flow through one chamber of a Pennsylvania State artificial heart, may be applied to several other experimental heart designs. Potentially the biggest benefit is in development of the total artificial heart scheduled for clinical testing in the early 1990's.

Ames researchers next plan to simulate the flow surrounding the valve openings in the Penn State model. "By combining the valve calculations with our present work on the heart chamber," explained Dr. Dochan Kwak, an Ames scientist, "we'll have a complete flow analysis package for artificial heart manufacturers."

"Spinback" Potential

NASA's loan of space technology to this research project—which involves the Ames Center, Pennsylvania State University, and Stanford University—will be repaid with interest, according to Kutler, who anticipates "spinback" applications of the enhanced code by NASA and the aerospace community. "It's useful anywhere you have unsteady flows with moving boundaries," he said, "such as inside a jet engine."


NASA hopes to use the code to model flow in the shuttle engine's fuel and oxidizer pumps, while the Navy wants to apply it to study the flow field around submarine propellers.

This simulation shows vorticity magnitude contours on the inside surface of the heart chamber. The fluid, a water-glycerin solution used by experimentors to represent blood, is being pumped out through the open valve by a piston.

"This code was written for completely generalized coordinates," said Dr. Rogers, "so it can easily be taken from one problem and put on to another."

Developers of the Penn State heart are applying the CFD technology pioneered to date to analyze blood flow behavior and compare it with their experimental observations. The simulation is a first step, Rogers said, towards computer-aided design of mechanical hearts. □


(Photo courtesy Pennsylvania State University)



An electromechanical device powered by inductance from an external battery, the Penn State artificial heart features a cylindrical chamber with two openings on the side for valves.

TECPLOT™

LETS YOU SEE THINGS DIFFERENTLY...



AT THE SAME TIME.

TOTAL INTEGRATION.

TECPLOT is the first fully-integrated plotting software that provides the capabilities needed by engineers in one interactive, easy-to-use program. TECPLOT supports a variety of 2D plots, including flooded contours, vectors, streamlines, as well as X-Y line plots. TECPLOT lets you display your data *each* of these ways on the screen at the same time...in full color or monochrome.

EASY TO USE.

TECPLOT is a friendly, menu-driven application that takes the plodding out of plotting. TECPLOT allows you to totally customize your plots interactively, using a mouse.

30-DAY MONEY-BACK GUARANTEE.

We're so convinced you'll like TECPLOT, we're offering you a 30-day, no questions asked, money-back guarantee.

TECPLOT CONFIGURATIONS:	PCs	WORKSTATIONS*
TECPLOT/2D (Full Product)	\$495	\$1695
TECPLOT/LP (Line plotting only)	\$195	\$795

* Apollo Computer, Inc., Sun Microsystems, Inc., Silicon Graphics, Inc., and others.

AMTEC

13103 Travis View Loop
Austin, TX 78732
(512) 343-5075

TECPLOT is a trademark of Amtec Engineering, Inc.

Advertiser's Index

Acrosystems	(RAC 315)	97
Aerospatiale	(RAC 658-660)	29, 31, 33
Algore Interactive Systems, Inc.	(RAC 361)	68
Amco Engineering Co.	(RAC 500)	11
Amtec Engineering, Inc.	(RAC 403)	118
Anorad Corporation	(RAC 508, 509)	6
Astro-Med, Inc.	(RAC 305)	65
Automation Gages	(RAC 433)	111
Aviation Week Video	(RAC 310)	114
BEI Motion Systems	(RAC 327)	2
Best Power Technology, Inc.	(RAC 370)	116
Blue M	(RAC 384)	66
Brueel & Kjaer Instruments, Inc.	(RAC 319)	21
Cabtron Systems, Inc.	(RAC 654)	27
Cambridge Technology, Inc.	(RAC 411)	111
Cerac Incorporated	(RAC 416)	108
Comtran Integrated Software	(RAC 480)	110
DataMyte Corporation	(RAC 465)	80-81
David Sarnoff Research Center	(RAC 604)	114
DSP Development Corp.	(RAC 652)	52
DuPont Vespel	(RAC 582)	41-42
Eighteen Eight Laboratories	(RAC 675)	78
Emcor Products/Crenlo, Inc.	(RAC 460)	3
Evergreen Systems International	(RAC 573)	116
Federal Procurement Services	(RAC 447)	116
Fluoramics	(RAC 364)	COV III
Grafpoint	(RAC 686)	95
Heath Company	(RAC 653)	60
Houston Instrument	(RAC 550)	114
Hydra-Electric Co.	(RAC 427)	116
IBM Corporation		4-5
Illbruck	(RAC 466)	53
Instrument Technology, Inc.	(RAC 354)	104
Intel Corporation	(RAC 331)	15, 17
Intelligent Interfaces Inc.	(RAC 679)	116
International Light, Inc.	(RAC 645)	115
InvenTech Expo	(RAC 653)	12
Kevex X-Ray Tube Division	(RAC 531)	61
Kewaunee Scientific Corporation	(RAC 430)	45
Kinetic Systems Corporation	(RAC 324)	116
Krenz Electronics Inc.	(RAC 436)	47
Lakeshore Cryotronics, Inc.	(RAC 579)	60
Lindberg/Blue M	(RAC 671)	62
MACSYMA/SYMBOLICS	(RAC 524)	105
Martin Marietta		COV II-1
MathSoft, Inc.	(RAC 628)	49
The Mathworks, Inc.	(RAC 503)	8
McDonnell Douglas	(RAC 501)	COV IV
MetraByte Corporation	(RAC 606)	109
Molecu Wire Corp.	(RAC 388)	57
Motorola Inc.	(RAC 655)	9
Numerical Algorithms Group	(RAC 377)	113
Newport Corporation	(RAC 510)	7
Nicolet Instruments	(RAC 696)	18
Novotechnik	(RAC 334)	79
Oedetics Kode Division	(RAC 346)	25
Panasonic Industrial Co.	(RAC 380)	37
Parker Hannifin Corporation	(RAC 558)	88-89
Physical Acoustics Corporation	(RAC 425)	53
Pixilink Corporation	(RAC 490)	71
Plasticorp	(RAC 691)	59
Polytron Corp.	(RAC 458)	116
Pratt & Whitney		87
QSI Corporation	(RAC 545)	110
Quantitative Technology Corp.	(RAC 570)	51
Rexham Industrial	(RAC 369)	46
RGB Technology	(RAC 467)	10
Roland Digital Group	(RAC 513)	77
Rolyn Optics Company	(RAC 551)	116
RR Software, Inc.	(RAC 564)	69
Stanford Research Systems	(RAC 391)	32
Taconic Plastics Ltd.	(RAC 613)	63
TEAC Corporation of America	(RAC 344)	23
Teledyne Relays	(RAC 537)	35
TWA Cargo	(RAC 438)	19
21st Century Science & Technology	(RAC 651)	108
Vernitech	(RAC 396)	109
Wardwell Braiding Machine Co.	(RAC 396)	104
YSI Incorporated	(RAC 681)	116
Zircar	(RAC 595)	39

*RAC stands for Reader Action Card. For further information on these advertisers, please circle the RAC number on the Reader Action Card elsewhere in this issue. This index has been compiled as a service to our readers and advertisers. Every precaution is taken to ensure its accuracy, but the publisher assumes no liability for errors or omissions.

Calm down your computer!



TIRED OF "FLAKY FLOPPIES"? GOT THE PRINTER JITTERS?

*Here's how **Tufoil**® Compu-lube® saved the day!*

There's an old saying that the majority of the failures in modern electronic devices are mechanical. You could take that one step further and say that mechanical failures usually are the result of poor or old-fashioned sticky, dirty lubricants.

Our tests have shown that nearly 50% of troublesome 5 1/4" floppy disk drives are brought back to life by putting **TUFOIL**® COMPU-LUBE® on the internal guide - ways and bearings.

The same thing happens for dot matrix printers that are used frequently. When you put a few drops on the ways, mis-indexing and chatter vanish. You'll be amazed at how COMPU-LUBE® smooths them down.

- Your machine will quiet down instantly and start to whiz along like it used to.
- Error messages will stop plaguing you on your monitor.

lubricant could save that floppy drive or printer you were going to throw away.

**Order toll-free now
1-800-922-0075**

Blister packed in 1 ounce squeeze bottles with a long flexible 3" nozzle to poke into those "impossible" places...easy to use!

Don't delay!



Would you put vacuum tubes in your computer? Of course not! So be careful and don't use lubricants that were developed back in that ancient era.

TUFOIL COMPU-LUBE® It's one of the TUFOIL family of patented lubricants.

They are so advanced that we call **TUFOIL** "The Transistor of Lubrication.®" No other lubricant even comes close.

A well known Federal laboratory tested **TUFOIL** and found a steel on steel surface friction of .029 (Teflon on Teflon is .04). **That's slipperier than Teflon.**

So save yourself big bucks! A wee drop or two of our space-age

YES...RUSH MY COMPU-LUBE®

- ☐ ONE--\$9.95 + \$2.00 shipping
☐ CASE(12)--\$114 *Freight Free*

My check or money order for \$ _____ is enclosed.
Charge my credit card:

☐ Am. Express ☐ Master Card ☐ Visa
Card No. _____

Exp. Date _____

Name _____

Address _____

City _____

State _____ Zip _____

(N.J. residents please add 6% sales tax). Canadians:
Call for the name of our Canadian distributor.

Fluoramics, Inc.

103 Pleasant Avenue
Upper Saddle River, N.J. 07458
201-825-8110

FLUON® IS REG. T.M. of ICI Americas Inc.
TELFON® is reg. T.M. of DuPont®
TUFOIL® is reg. T.M. of Fluoramics



"We use one of the largest vacuum chambers in the world to test our nose cones. The testing lets us see exactly what will happen when the cone is explosively separated to release a satellite into orbit.

But we needed a better way to control the nose cone during separation, to keep the cone from getting damaged or from causing any damage to the walls of the chamber.

Well, I climb mountains in my spare time. Crazy as it may seem, that's how I got the answer to our problem. I figured we could get the control by hooking up the kind of rip-stitch shock absorbers that climbers use to stop their falls.

The whole team pitched in and made the idea work. We count on each other. And that can be as exciting as mountain climbing."

—*Chas Fuld, Space Systems Development, Manager Test Engineer (2nd from left) with Fred Eckhardt, Senior Engineer-Scientist (left), Dick Durant, Senior Engineer-Scientist (right), Bob Frenchick, Senior Engineer-Scientist (3rd from left)*

MCDONNELL DOUGLAS
A company of leaders.